

User Manual

Autonomous Navigation Solutions

Inertial Sense, Inc.

©2022

Table of Contents

1. Overview	5
1.1 IMX-5 (IMU, AHRS, and GPS-INS)	5
1.2 Features	6
1.3 Interfaces	7
1.4 Applications	7
2. Data Sheets	9
2.1 IMX-5 (IMU, AHRS, GNSS-INS)	9
2.2 GPX-1 (Multi-Band L1/L5 Dual GNSS Receiver)	9
2.3 uINS-3	9
3. Dimensions and Pinouts	10
3.1 IMX-5 Series	10
3.2 μ INS-3 Series	10
3.3 Hardware Design Files	10
4. Getting Started	11
4.1 Getting Started	11
4.2 IMX-5 Quick Start Guide	13
4.3 GPX-1 Quick Start Guide	14
5. IS Hardware	16
5.1 Hardware Integration: IMX-5 Module	16
5.2 Hardware Integration: GPX-1 Module	22
5.3 Hardware Integration: RUG-3-IMX-5 (Rugged-3)	31
5.4 Hardware Integration: IG-1-IMX-5	37
5.5 Hardware Integration: IG-2 (IMX5 + GPX1)	44
5.6 Hardware Integration: IK-1 (IMX5 or GPX1)	51
5.7 Hardware Design Files	57
5.8 Reflow Soldering	58
6. IS Software	60
6.1 CLTool	60
6.2 EvalTool	65
6.3 SDK	79
6.4 Log Inspector	81
7. Communication Protocols	84
7.1 Protocol Overview	84
7.2 Data Sets (DIDs)	85
7.3 Inertial Sense Binary (ISB) Protocol	159

7.4 NMEA 0183 (ASCII) Protocol	165
7.5 SPI Protocol	183
7.6 CAN Protocol	186
8. GNSS - RTK	194
8.1 Multi-band GNSS	194
8.2 External NMEA GNSS	220
8.3 GNSS Antennas	222
8.4 GNSS Satellite Constellations	227
8.5 RTK Positioning	228
8.6 Dual GNSS RTK Compassing	244
9. Dead Reckoning	251
9.1 Ground Vehicle Dead Reckoning	251
9.2 IMX Dead Reckoning Examples	254
10. General Configuration	260
10.1 Infield Calibration	260
10.2 Platform Configuration	263
10.3 IMU INS GNSS Configuration	264
10.4 System Configuration	269
10.5 Time Synchronization	270
10.6 Zero Motion Command	274
10.7 UART Interface	275
11. SDK	276
11.1 Inertial Sense SDK	276
11.2 Example Projects	278
12. Data Logging/Plotting	295
12.1 Data Logging/Plotting	295
12.2 Logging	298
12.3 Plotting	300
13. Reference	301
13.1 IMX-5.0 Bootloader	301
13.2 Coordinate Frames	302
13.3 Definitions	307
13.4 IMU Specifications	309
13.5 Interference Considerations	310
13.6 Magnetometer	312
14. User Manual PDF	314
15. Frequently Asked Questions	315
15.1 What is a Tactical Grade IMU?	315

15.2	Why the name change from <i>uINS</i> to <i>IMX</i> ?	316
15.3	What is Inertial Navigation?	317
15.4	What does an Inertial Navigation System (INS) offer over GPS alone?	317
15.5	Our Sensors - IMU vs AHRS vs INS	317
15.6	How long can the IMX dead reckoning estimate position without GPS?	318
15.7	Can the IMX estimate position without GPS?	318
15.8	How does the IMX estimate roll/pitch during airborne coordinate turns (acceleration only in the Z axis and not in the X and Y axes)?	318
15.9	How does vibration affect navigation accuracy?	318
15.10	Can the IMX operate underwater?	318
15.11	Can the IMX operate at >4g acceleration?	319
15.12	Customer Support	319
16.	Troubleshooting	320
16.1	Firmware Troubleshooting	320
16.2	Chip Erase	324
16.3	IMX Firmware Troubleshooting	328

Software Release 2.4.1 - 11 April 2025

Older (non-current) versions of the User Manual can be found on GitHub under the specific [release tags](#).



INERTIALSENSE
autonomous navigation solutions

1. Overview

1.1 IMX-5 (IMU, AHRS, and GPS-INS)



The **IMX-5™** is a 10-DOF sensor module consisting of a tactical grade Inertial Measurement Unit (IMU), magnetometer, and barometer. Output includes angular rate, linear acceleration, magnetic vector, and barometric pressure and altitude. IMU calibration consists of bias, scale factor, cross-axis alignment, and temperature compensation. The IMX-5 includes Attitude

Heading Reference System (**AHRS**) sensor fusion to estimate roll, pitch, and heading. Adding GNSS input to the IMX-5 enables onboard Inertial Navigation System (**INS**) sensor fusion for roll, pitch, heading, velocity, and position.

The **RUG-3-IMX-5™** series adds a rugged aluminum enclosure and RS232, RS485, and CAN bus to the IMX-5.

The **RUG-3-IMX-5-RTK™** includes a multi-frequency GNSS receiver with RTK precision position enabling INS sensor fusion for roll, pitch, heading, velocity, and position.

The **RUG-3-IMX-5-Dual™** includes two multi-frequency GNSS receivers with RTK precision position and dual GNSS heading/compass.

The **Inertial Sense SDK** is an open-source software development kit for quick integration to configure and communicate with Inertial Sense products. The SDK includes data logger, math libraries, and interface for Linux, Windows, and embedded platforms.

1.2 Features


- **Tactical Grade IMU**
- **Gyro: 1.5 °/hr Bias Instability, 0.16 °/√hr ARW**
- **Accel: 19 µg Bias Instability, 0.02 m/s/√hr VRW**
- **0.04° Dynamic Roll/Pitch**
- **0.13° Dynamic Heading**
- **Surface Mount Reflowable (PCB Module)**
- Up to 1KHz IMU Output Data Rate
- Small Form Factor: 15.6 x 12.5 x 2.9 mm
- Light Weight: 0.8 g
- Low power consumption: <110mW
- External GNSS Support (Multi-Band)
- Attitude (Roll, Pitch, Yaw, Quaternions), Velocity, and Position UTC Time Synchronized
- Triple Redundant IMUs Calibrated for Bias, Scale Factor, Cross-axis Alignment, and G-sensitivity
- -40°C to 85°C Sensor Temperature Calibration
- Binary and NMEA Protocol
- Barometric Pressure and Humidity
- Strobe In/Out Data Sync (Camera Shutter Event)
- Fast Integration with SDK and Example Software

1.3 Interfaces

	IMX Module	EVB-2	Rugged
USB	Yes	Yes	Yes
TTL/UART	Yes	Yes	Yes
RS232/RS422/RS485	No	Yes	Yes
CAN	Yes	Yes	Yes
SPI	Yes	Yes	Yes
Integrated XBee Radio (RTK)	No	Yes (Option)	No
WiFi/BTLE	No	Yes	No
GPS Antenna Ports (Dual=Compassing)	No	Dual (Option)	Dual (Option)

1.4 Applications

- Drone Navigation
- Unmanned Vehicle Payloads
- Stabilized Platforms
- Antenna and Camera Pointing
- First Responder and Personnel Tracking
- Pedestrian and Auto Outdoor / Indoor Navigation
- Health, Fitness, and Sport Monitors
- Hand-held Devices
- Robotics and Ground Vehicles
- Maritime



Inertial Sense, Inc.

3000 S Sierra Vista Way Suite 5, Provo, UT 84606 USA

Phone 801-610-6771

Email support@inertialsense.com

Website: InertialSense.com

© 2014-2025 Inertial Sense

Inertial Sense®, Inertial Sense logo and combinations thereof are registered trademarks or trademarks of Inertial Sense, Inc. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Inertial Sense products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Inertial Sense products. EXCEPT AS SET FORTH IN THE INERTIAL SENSE TERMS AND CONDITIONS OF SALES LOCATED ON THE INERTIAL SENSE WEBSITE, INERTIAL SENSE ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL INERTIAL SENSE BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF INERTIAL SENSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Inertial Sense makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Inertial Sense does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Inertial Sense products are not suitable for, and shall not be used in, automotive applications. Inertial Sense products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life. SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Inertial Sense products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death (“Safety-Critical Applications”) without an Inertial Sense officer’s specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Inertial Sense products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Inertial Sense as military-grade.

2. Data Sheets

2.1 IMX-5 (IMU, AHRS, GNSS-INS)

[Download Datasheet](#)

2.2 GPX-1 (Multi-Band L1/L5 Dual GNSS Receiver)

[Download Datasheet](#)

2.3 uINS-3

[Download Datasheet](#)

3. Dimensions and Pinouts

3.1 IMX-5 Series

3.1.1 IMX-5 (Module)

[Download PDF](#)

3.1.2 GPX-1 (Module)

[Download PDF](#)

3.1.3 RUG-3-IMX-5-IMU

[Download PDF](#)

3.1.4 RUG-3-IMX-5-Dual

[Download PDF](#)

3.1.5 IG-1-IMX-5-Dual (Module)

[Download PDF](#)

3.2 μ INS-3 Series

3.2.1 μ INS-3 (Module)

[Download PDF](#)

3.2.2 RUG-2.0

[Download PDF](#)

3.2.3 RUG-1.1

[Download PDF](#)


3.3 Hardware Design Files

The Inertial Sense hardware design files are available on our [IS-hdw repository](#) to facilitate product hardware development and integration.

- **Products** - 3D models and resources for the IMX, Rugged, EVB, and products useful for CAD and circuit board designs. Libraries for schematic and layout designs for printed circuit board.

4. Getting Started

4.1 Getting Started



The Inertial Sense Development platform was designed to provide a method of rapid evaluation and integration. The following steps will provide a simple method to begin basic integration.

4.1.1 1. Install Software

Inertial Sense software provides a way to view, manipulate, stream, and record the data generated by an IMX-5, GPX-1, and the accompanying products.

- **EvalTool (Windows and Linux)**

The EvalTool is a graphical Windows-based desktop program that allows users to explore, configure, and test functionality of the Inertial Sense products in real-time. Download the EvalTool installer from the Inertial Sense [releases](#) page. Run the .exe file and follow the instructions to complete the installation.

- **CLTool (Windows, Linux, and OS X)**

The CLTool is a command line utility that can be used to read and display data, update firmware, and log data from Inertial Sense products. CLTool must be compiled from our source code. Follow the instructions on the [CLTool](#) page.

- **SDK (Windows, Linux)**

Software development kit to interface with Inertial Sense products. Download the file named "Source code" from our [releases](#) page. The extracted folder contains code libraries as well as example projects.

4.1.2 2. Connect Hardware

Select the evaluation product from the list below to view instructions on basic connection to a computer.

- [IMX-5 PCB Module](#)
- [GPX-1 PCB Module](#)
- [Rugged-3 Units](#)
- [IG-1 Units](#)
- [IG-2 Units](#)
- [IK-1 Units](#)

4.1.3 3. Configuring Settings

The following sections contain instructions for basic configuration of IMX-5 based products and GPX-1 based products respectively:

- [IMX-5 Basic Configuration](#)
- [GPX-1 Basic Configuration](#)

4.1.4 4. Evaluation and Testing

Once a connection to the unit has been established, please follow one of the following guides to get started with the software tool of choice:

- [EvalTool](#)
- [CLTool](#)
- [SDK Example Projects](#)

4.2 IMX-5 Quick Start Guide

4.2.1 Basic Configuration

The configuration settings found in DID_FLASH_CONFIG are used to configure the various features of the device. These can be modified directly to the appropriate values using either the [EvalTool](#), the [CLTool](#), or the [SDK](#). However, it is convenient initially to configure the main features by modifying the settings in the GPS and General tabs with the Settings tab of the EvalTool.

The antenna offset should also be configured by going to the Data Sets Tab and selecting DID_FLASH_CONFIG. The values of each field can then be edited. Modify the following fields after identifying the [antenna positions](#):

1. gps1AntOffset[X-Z] - Position offset of sensor frame with respect to GPS1 antenna.
2. gps2AntOffset[X-Z] - Position offset of sensor frame with respect to GPS2 antenna.

IMX-5 data sets can then be requested by one of several methods:

1. Requesting NMEA data using the [ASCE](#) command. There is a convenient tool in the lower left corner of the Data Logs tab of the EvalTool.
2. Request data using the SDK commands: [SDK Function](#)
3. Use the EvalTool to modify the value of DID_GPX_RMC.bits as outlined in the [SDK](#).

4.2.2 Demonstration Videos

Rugged-3-G2 GPS Compassing Configuration Demo

Rugged-3-G2 RS-485/422 Configuration Demo

4.2.3 Troubleshooting

If at any time issues are encountered, please check the troubleshooting sections of this manual.

4.3 GPX-1 Quick Start Guide



4.3.1 Basic Configuration

Note

When the GPX-1 is paired with an IMX-5, the IMX-5 will configure the GPX-1 automatically based on the configuration of the IMX-5. No further action is required.

The GPX-1 should be connected to a host via a communications port: USB, UART, or SPI.

The configuration settings found in `DID_GPX_FLASH_CONFIG` are used to configure the various features of the device. These can be modified directly to the appropriate values using either the [EvalTool](#), the [CLTool](#), or the [SDK](#).

Configure the antenna offsets. This can be done easily in the EvalTool by going to the Data Sets Tab and selecting `DID_GPX_FLASH_CONFIG`. The values of each field can then be edited. Modify the following fields after identifying the [antenna positions](#):

1. `gps1AntOffset[X-Z]` - Position offset of sensor frame with respect to GPS1 antenna.
2. `gps2AntOffset[X-Z]` - Position offset of sensor frame with respect to GPS2 antenna.

GNSS data sets can then be requested by one of several methods:

1. Requesting NMEA data using the [ASCE](#) command. There is a convenient tool in the lower left corner of the Data Logs tab of the EvalTool.
2. Request data using the SDK commands: [SDK Function](#)
3. Use the EvalTool to modify the value of DID_GPX_RMC.bits as outlined in the [SDK](#).


5. IS Hardware

5.1 Hardware Integration: IMX-5 Module



5.1.1 Pinout

The IMX-5 module is pin compatible with the uINS-3.



TOP VIEW

Pin	Name	I/O	Description
0	Not Connected	-	Not connected internally. Connect to ground (GND).
1	USB_P	I/O	USB Data Positive Line
2	USB_N	I/O	USB Data Negative Line
3	VBKUP	I	GNSS backup supply voltage. (1.4V to 3.6V) enables GNSS hardware backup mode for hot or warm startup (faster GNSS lock acquisition). MUST connect VBKUP to VCC if no backup battery is used.
4	G1/Rx2/RxCAN/ SCL	I/O	GPIO1 Serial 2 input (TTL) Serial input pin from CAN transceiver* I2C SCL line
5	G2/Tx2/TxCAN/ SDA/STROBE	I/O	GPIO2 Serial 2 output (TTL) Serial output pin to CAN transceiver* I2C SDA line Strobe time sync input
6	G6/Rx1/MOSI	I/O	GPIO6 Serial 1 input (TTL) SPI MOSI
7	G7/Tx1/MISO	I/O	GPIO7 Serial 1 output (TTL) SPI MISO
8	G8/CS/STROBE	I/O	GPIO8 SPI CS Strobe time sync input
9	G5/SCLK/STROBE	I/O	GPIO5 SPI SCLK Strobe time sync input
10	G9/nSPI_EN/ STROBE /STROBE_OUT/ DRDY	I/O	GPIO9 SPI Enable: Hold LOW during boot to enable SPI on G5-G8 Strobe time sync input or output. SPI data ready alternate location
11,21,P	GND	-	Supply ground
12	nRESET	I	System reset on logic low. May be left unconnected if not used.
13	G14/SWCLK	I/O	GPIO14
14	G13/DRDY/XSDA	I/O	GPIO13 SPI Data Ready Alt I2C SDA
15	G12/SWO/XSCL	I/O	GPIO12 Alt I2C SCL
16	G11/SWDIO	I/O	GPIO11
17	G10/BOOT_MODE	I/O	Leave unconnected. BOOT MODE used in manufacturing. !!! WARNING !!! Asserting a logic high (+3.3V) will cause the IMX to reboot into ROM bootloader (DFU) mode.
18	G4/Rx0	I/O	GPIO4 Serial 0 input (TTL)


Pin	Name	I/O	Description
19	G3/Tx0	I/O	GPIO3 Serial 0 output (TTL)
20	G15/GNSS_PPS	I	Input for GNSS PPS for time synchronization pulse.
22	VCC	I	3.3V supply input

*External transceiver required for CAN interface.

5.1.2 Application

Serial Interface

The following schematic demonstrates a typical setup for the IMX-5 module. A rechargeable lithium backup battery enables the GNSS to perform a warm or hot start. If no backup battery is connected, VBKUP (pin 3) should be connected to VCC and the module will perform a cold start on power up. If the system processor is not capable of updating the IMX firmware, it is recommended to add a header to an alternate IMX serial port for firmware updates via an external computer. The reset line is not necessary for typical use.




The following are recommended components for the typical application. Equivalent or better components may be used.

Designator	Manufacturer	Manufacturer #	Description
BAT1	Panasonic	ML-614S/FN	BATTERY LITHIMU 3V RECHARGABLE SMD
D1	Panasonic	DB2J31400L	DIODE SCHOTTKY 30V 0.03A SMINI2
R1			RES 1.00K OHM 1/16W 1%
C1			CAP CER .10UF 50V X7R 10%

SPI Interface

The SPI interface is enabled by holding the pin 10 low during boot up.




5.1.3 Manufacturing

Soldering

The IMX-5 can be reflow soldered. Reflow information can be found in the [Reflow Information](#) page of this manual.

Tape Packaging

The IMX-5 modules are available in **cut tape** as well as **tape and reel** packaging. The follow image shows the feed direction and illustrates the orientation of the IMX-5 module on the tape:



The feed direction to the pick and place pick-up is shown by the orientation of the IMX-5 pin 1 location. With pin 1 location on the bottom of the tape, the feed direction into the pick and place pick-up is from the reel (located to the right of the figure) towards the left.

The dimensions of the tapes for the IMX-5 are shown in the drawing below:

5.1.4 Hardware Design

Recommend PCB Footprint and Layout

A single ceramic 100nF decoupling capacitor should be placed between and in close proximity to the IMX pins 21 and 22 (GND and Vcc). It is recommended that this capacitor be on the same side of the PCB as the IMX and that there not be any vias between the capacitor and the Vcc and GND pins. The default forward direction is indicated in the PCB footprint figure and on the IMX shield as the X axis. The forward direction is reconfigurable in software as necessary.

[Download PDF](#)

5.1.5 Design Files

Open source hardware design files, libraries, and example projects for the IMX module are found at the [Inertial Sense Hardware Design repository](#) hosted on GitHub. These include schematic and layout files for printed circuit board designs, and 3D step models of the InertialSense products usable for CAD and circuit board designs.



Reference Design Projects

The EVB-2 and IG-1 circuit board projects serve as reference designs that illustrate implementation of the IMX PCB module.

[EVB-2 evaluation board](#)


[IG-1 module](#)

5.2 Hardware Integration: GPX-1 Module



5.2.1 Pinout

The GPX-1 module footprint and pinout similar that of the IMX-5 such that the common power and interface pins are at the same location. The GPX-1 is extended to accommodate additional GNSS inputs and output. The GPX-1 is designed to work in conjunction with the IMX-5.



TOP VIEW


Pin	Name	Type	Description
0	GND	Power	Supply ground on center pads.
1	USB_P	I/O	USB full-speed Positive Line. USB will be supported in future firmware updates.
2	USB_N	I/O	USB full-speed Negative Line. USB will be supported in future firmware updates.
3	VBKUP	Power	Backup supply voltage input (1.75V to 3.6V). Future firmware updates will use voltage applied on this pin to backup GNSS ephemeris, almanac, and other operating parameters for a faster startup when VCC is applied again. This pin MUST be connected to a backup battery or VCC.
4	G1/Rx2/RxCAN/ SCL	I/O	GPIO1 Serial 2 input (TTL) Serial input pin from CAN transceiver* I2C SCL line
5	G2/Tx2/TxCAN/ SDA/STROBE	I/O	GPIO2 Serial 2 output (TTL) Serial output pin to CAN transceiver* I2C SDA line Strobe time sync input
6	G6/Rx1/MOSI	I/O	GPIO6 Serial 1 input (TTL) SPI MOSI
7	G7/Tx1/MISO	I/O	GPIO7 Serial 1 output (TTL) SPI MISO
8	G8/CS/STROBE	I/O	GPIO8 SPI CS Strobe time sync input
9	G5/SCLK/ STROBE	I/O	GPIO5 SPI SCLK Strobe time sync input
10	G9/nSPI_EN/ STROBE /STROBE_OUT/ DRDY	I/O	GPIO9 SPI Enable: Hold LOW during boot to enable SPI on G5-G8 Strobe time sync input or output. SPI data ready alternate location
11,13,15,31	GND	Power	Supply ground
12	GNSS1_RF	I	GNSS1 antenna RF input. Use an active antenna or LNA with a gain of 15-25dB. Place the LNA as close to the antenna as possible. Filtered 3.3V from VCC is injected onto the pad to power active antennas (power injection can be disabled in software). Connect to ground with 5V-14V TVS diode for ESD and surge protection (e.g. Littlefuse PESD0402-140).
14	GNSS2_RF	I	GNSS2 antenna RF input. Same requirements as GNSS1_RF
16	VCC_RF	O	Supply output for GNSS active antenna. Connect VCC_RF through 33-120nH inductor (e.g. Murata LQW15ANR12J00D, 110mA max) to GNSS1_RF and GNSS2_RF to inject DC supply for active antenna(s). VCC_RF is supplied from VAUX through an onboard 1A load switch and

Pin	Name	Type	Description
			10 ohm resistor. Disable by setting <code>GPX_SYS_CFG_BITS_DISABLE_VCC_RF</code> (0x00000001) in <code>DID_GPX_FLASH_CFG.sysCfgBits</code> .
20	G20/LNA-EN	I/O	GPIO20
21	GNSS2_PPS	O	GNSS2 PPS time synchronization output pulse (1Hz, 10% duty cycle)
22	nRESET	I	System reset on logic low. May be left unconnected if not used.
23	G14/SWCLK	I/O	GPIO14
24	G13/DRDY/ XSDA	I/O	GPIO13 SPI Data Ready Alt I2C SDA
25	G12/XSCL	I/O	GPIO12 Alt I2C SCL
26	G11/SWDIO	I/O	GPIO11
27	G10/ BOOT_MODE	I/O	Leave unconnected. BOOT MODE used in manufacturing. !!! WARNING !!! Asserting a logic high (+3.3V) will cause the IMX to reboot into ROM bootloader (DFU) mode.
28	G4/Rx0	I/O	GPIO4 Serial 0 input (TTL)
29	G3/Tx0	I/O	GPIO3 Serial 0 output (TTL)
30	GNSS1_PPS	O	GNSS1 PPS time synchronization output pulse (1Hz, 10% duty cycle)
32	VCC	Power	1.8V to 3.3V supply input.
38	G16/QDEC0.A	I/O	GPIO16
39	G17/QDEC0.B	I/O	GPIO17
40	VAUX	Power	Input supplies for the USB and VCC_RF (GNSS antenna supply). Connect to +3.3V (3.0V to 3.6V) to supply USB and VCC_RF. Can be left floating if USB or VCC_RF are not needed.
41	G18/QDEC1.A	I/O	GPIO18
42	G19/QDEC1.B	I/O	GPIO19


*External transceiver required for CAN interface.

5.2.2 Application


GNSS-INS Block Diagram



Typical Application: GPX-1 IMX-5



Designator	Manufacturer	Part Number	Description
D1, D2	Littlefuse	PESD0402-140	TVS DIODE 14VWM 40VC 0402
I1, I4	Murata	LQW15ANR12J00D	FIXED IND 120NH 110MA 2.66OHM SM



5.2.3 Layout Guidance

GNSS_RF Trace

The GNSS_RF trace should be designed to work in the combined GNSS L1 + L5 signal band.

For FR-4 PCB material with a dielectric permittivity of for example 4.2, the trace width for the 50 Ω line impedance can be calculated.

A grounded co-planar RF trace is recommended as it provides the maximum shielding from noise with adequate vias to the ground layer.

The RF trace must be shielded by vias to ground along the entire length of the trace and the ZEDF9P RF_IN pad should be surrounded by vias as shown in the figure below.

[INSERT LAYOUT FIGURE HERE]

5.2.4 Design Guidance

Backup Battery

For achieving a minimal Time To First Fix (TTFF) after a power down (warm starts, hot starts), make sure to connect a backup battery to V_BCKP.

- Verify your battery backup supply can provide the battery backup current specified in the ZEDF9P datasheet.
- Allow all I/O including UART and other interfaces to float/high impedance in battery backup mode (battery back-up connected with VCC removed).

RF Front-end Circuit Options

Important

Active antenna(s) are required for the GPX-1.


5.2.5 Manufacturing

Soldering

The GPX-1 can be reflow soldered. Reflow information can be found in the [Reflow Information](#) page of this manual.

Tape Packaging

The GPX-5 modules are available in **cut tape** as well as **tape and reel** packaging. The follow image shows the feed direction and illustrates the orientation of the GPX-1 module on the tape:



The feed direction to the pick and place pick-up is shown by the orientation of the GPX-1 pin 1 location. With pin 1 location on the bottom of the tape, the feed direction into the pick and place pick-up is from the reel (located to the right of the figure) towards the left.

The dimensions of the tapes for the GPX-1 are shown in the drawing below:

5.2.6 Hardware Design

Recommend PCB Footprint and Layout

A single ceramic 100nF decoupling capacitor should be placed between and in close proximity to the module pins 31 and 32 (GND and Vcc). It is recommended that this capacitor be on the same side of the PCB as the GPX and that there not be any vias between the capacitor and the Vcc and GND pins.

[Download PDF](#)

5.2.7 Design Files


Open source hardware design files, libraries, and example projects for the GPX module are found at the [Inertial Sense Hardware Design repository](#) hosted on GitHub. These include schematic and layout files for printed circuit board designs, and 3D step models of the InertialSense products usable for CAD and circuit board designs.



Reference Design Projects

Coming soon

5.3 Hardware Integration: RUG-3-IMX-5 (Rugged-3)



The **RUG-3-IMX-5** series adds a rugged aluminum enclosure and RS232, RS485, and CAN bus to the IMX-5.

The **RUG-3-IMX-5-RTK** includes a multi-frequency GNSS receiver with RTK precision position enabling INS sensor fusion for roll, pitch, heading, velocity, and position.

The **RUG-3-IMX-5-Dual** includes two multi-frequency GNSS receivers with RTK precision position and dual GNSS heading/compass.

- Integrated CAN transceiver, RS232, RS485, TTL serial, USB, and SPI interfaces.
- Dual onboard multi-band GNSS receiver(s).
- Dual antenna ports for GPS compassing.

5.3.1 Features

- **Tactical Grade IMU**
- **Gyro: 1.5 °/hr Bias Instability, 0.16 °/√hr ARW**
- **Accel: 19 µg Bias Instability, 0.02 m/s/√hr VRW**
- **INS, AHRS**
- **Dynamic: 0.04° Roll/Pitch, 0.13° Heading**
- **Static: 0.1° Roll/Pitch, 0.5° Heading**
- Up to 1KHz IMU Output Data Rate
- Dual onboard multi-band (L1/L2/E5) GNSS receivers
- Dual MMCX antenna ports for GPS compassing
- Size: 25.4 x 25.4 x 20.0 mm
- Light weight: 14g
- Low power consumption: <1500mW
- UART x3, RS232, RS485, CAN, and SPI interfaces
- Integrated CAN and RS232 / RS485 transceivers
- Voltage regulation for 4V - 20V input

5.3.2 Applications

- Drone Navigation
- Unmanned Vehicle Payloads
- Ground and Aerial Survey
- Automotive Navigation
- Stabilized Platforms
- Antenna and Camera Pointing
- First Responder and Trackers
- Health, Fitness, and Sport Monitors
- Robotics and Ground Vehicles
- Maritime

5.3.3 Connecting Your Unit

For the purposes of basic evaluation, the easiest interface available on the rugged is the included USB to Gecko connector cable, included in the evaluation kit. The cable provides power and communications with the installed module via USB virtual communications port.

GPS Antenna Ports

If using GPS with the module, connect an appropriate antenna to MMCX port **1 (GPS1)**. If the module is used for RTK compassing, connect a second antenna to MMCX port **2, (GPS2)**.

5.3.4 Pinout

**Warning**


The pin numbering of the Rugged main connector does not match that of the connector manufacturer. Please refer to the drawings in the Dimensions and Pinouts page for the correct pin numbering.

The following table shows the Rugged-3 pinout. Note that pin function can change based on changing DID_FLASH_CONFIG.platformConfig (see [I/O Configuration](#) below).

Rugged Pin	IMX Pin	Name	I/O	Description
1		GND	PWR	-
2	G9	G9_STROBE	I/O	G9-Strobe time sync input. (Includes 3K ohm series resistor)
3		VIN	PWR	4V-20V supply voltage input
4		USB.D+	I/O	USB Data Positive Line
5		GPS_PPS	O	GPS PPS time synchronization output pulse (1Hz, 10% duty cycle)
6		USB.D-	I/O	USB Data Negative Line
7	G3	Tx0	O	Serial 0 output (TTL or RS232)
	G2	485Tx1+	O	Serial 1 output+ (RS485/RS422)
	G5	SCLK	I	SPI clock
8	G2	Tx2	O	Serial 2 output (TTL)
	G2	485Tx1-	O	Serial 1 output- (RS485/RS422)
	G7	Tx1, MISO	O	Serial 1 output (TTL or RS232), SPI MISO
9	G4	Rx0	I	Serial 0 input (TTL or RS232)
	G1	485Rx1-	I	Serial 1 input- (RS485/RS422)
	G8	CS, G8_STROBE	I	SPI chip select, G8-Strobe time sync input
10	G1	Rx2	I	Serial 2 input (TTL)
	G1	485Rx1+	I	Serial 1 input+ (RS485/RS422)
	G6	Rx1, MOSI	I	Serial 1 input (TTL or RS232), SPI MOSI
11	G1	CANL [*]	I/O	High level (CAN bus)
	G1	Rx2 ^{**}	I	Serial 2 input (TTL) ^{**}
12	G2	CANH [*]	I/O	Low level (CAN bus) [*]
	G2	Tx2, G2_STROBE ^{**}	I/O	Serial 2 output (TTL) ^{**} , G2-Strobe time sync input ^{**}

* The CAN bus is enabled by default on pins 11,12 (R16,R17 removed and R14,R15 loaded with 0402 zero ohm jumpers).

** To disable CAN bus and enable Serial2 TTL or STROBE on pins 11,12, remove R14,R15 and load R16,R17 with 0402 zero ohm jumpers.



5.3.5 I/O Configuration

The Rugged 3 "MAIN" connector pinout can be configured for USB, TTL, RS232, RS485, and CAN by setting the

`DID_FLASH_CONFIG.platformConfig`.

RUG-3 Pin IMX Pin	7,9 G3,G4 (G5,G8)	8,10 G1,G2	11,12 G1,G2	GPS1	GPS2
I/O Preset					
1 *	S0-RS232		CAN	S1	
2	S0-TTL		CAN	S1	
3	S0-TTL	S2-TTL or G2-STROBE		S1	
4	S0-RS232	S1-RS232		S2	
5	S1-RS485	S1-RS485		S2	S0
6	SPI or G8-STROBE	SPI		S2	S0
7 **		S1-RS232		S2	S0
8			CAN	S1	S0
9		S2-TTL		S1	S0

* RUG-3-G0 default

** RUG-3-G2 default

5.3.6 Hardware Versions

The following outlines differences in the RUG-3 hardware versions.

RUG-3.1

Use platform config RUG-3 with this hardware version.

- GPS1 PPS line connected to IMX G15 (pin 20).
- RS485 Tx pins polarity swapped between pins 7,8 (from RUG-2)

RUG-2.1 (RUG-3.0)

Use platform config RUG-2.1 with this hardware version.

- GPS1 PPS line connected to IMX G9 (pin 10).
- MAIN pin 5 is connected to IMX G15 (pin 20).
- MAIN pin 5 is not connected to GPS1 PPS.

5.3.7 Related Parts

Part	Manufacturer	Manufacturer #	Description
Main Connector	Harwin	G125-FC11205L0-0150L	1.25MM F/F 12POS 26AWG 150MM
GPS antenna SMA adapter	Crystek Corporation	CCSMX-FBM-RG178-6	6" MMCX to SMA GPS antenna adaptor cable.
GPS antenna SMA adapter	Crystek Corporation	CCSMX1-FBM-RG178-6	6" R/A MMCX to SMA GPS antenna adaptor cable.

See the [Multi-Band GNSS page](#) for GNSS antenna options.

5.3.8 Using with Inertial Sense Software

Please return to the [getting started](#) page to get started programming, updating firmware, viewing data, and logging.

5.4 Hardware Integration: IG-1-IMX-5



The Inertial Sense IG-1 is a PCB module with IMX-5 and dual ublox ZED-F9P multi-frequency GNSS receivers.

- Surface mount reflowable.
- Onboard dual GNSS for simultaneous RTK positioning and GPS compassing.
- Micro USB and 14 pin I/O header for convenient evaluation.


5.4.1 Connecting Your Unit

For the purposes of basic evaluation, the easiest interface available on the IG-1 is by using a micro-USB cable. A cable included in the evaluation kit. The cable provides power and communications with the installed module via USB virtual communications port.


5.4.2 Pinout

Module Pinout

TOP VIEW



Header H1 Pinout



The module and header H1 have the same pinout assignment for pins 1-14. All pins 15 and above are only on the module.

Module & H1 Pin	Name	I/O	Description
 1	GND	PWR	-
 2	VIN	PWR	4V-20V supply voltage input
 3	+3.3V	PWR	Regulated 3.3V supply input/output.
 4	Reserved		Not Connected
 5	G1/Rx2/RxCAN/SCL	I/O	GPIO1 Serial 2 input (TTL) Serial input pin from CAN transceiver* I2C SCL line6
 6	G2/Tx/TxCAN/SDA/ STROBE	I/O	GPIO2 Serial 2 output (TTL) Serial output pin to CAN transceiver* I2C SDA line Strobe time sync input
 7	G3/Tx0	I/O	GPIO3 Serial 0 output (TTL)
 8	G4/Rx0	I/O	GPIO4 Serial 0 input (TTL)
 9	G5/SCLK/STROBE	I/O	GPIO5 SPI SCLK Strobe time sync input
 10	G6/Rx1/MOSI	I/O	GPIO6 Serial 1 input (TTL) SPI MOSI
 11	G7/Tx1/MISO	I/O	GPIO7 Serial 1 output (TTL) SPI MISO
 12	G8/CS/STROBE	I/O	GPIO8 SPI CS Strobe time sync input
 13	G9/nSPI_EN/ STROBE /STROBE_OUT/ SPI_DRDY	I/O	GPIO9 SPI Enable: Hold LOW during boot to enable SPI on G5-G8 Strobe time sync input or output. SPI data ready alternate location.
 14	GPS_TIMEPULSE	O	GPS1 PPS UTC time synchronization signal.
15	GND	I/O	-
16	VBAT	I/O	GPS backup supply voltage. (1.4V to 3.6V) enables GPS hardware backup mode for hot or warm startup (faster GPS lock acquisition). MUST connect GPS_VBAT to VCC if no backup battery is used.
17	G10/BOOT_MODE	I/O	Leave unconnected. BOOT MODE used in manufacturing. !!! WARNING !!! Asserting a logic high (+3.3V) will cause the IMX to reboot into ROM bootloader (DFU) mode.
18	G11	I/O	GPIO11

Module & H1 Pin	Name	I/O	Description
19	G12	I/O	GPIO12 GPS reset
20	G13/DRDY	I/O	GPIO13 SPI data ready
21	G14/SWCLK	I/O	GPIO14
22	nRESET	I	System reset on logic low. May be left unconnected if not used.
23	GND	PWR	-
24	USB_N	I/O	USB Data Negative Line
25	USB_P	I/O	USB Data Positive Line
26	GPS1_RX2	I	Ublox ZED-F9P RXD2 (GPS1)
27	GPS1_TX2	O	Ublox ZED-F9P TXD2 (GPS1)
28	GPS2_RX2	I	Ublox ZED-F9P RXD2 (GPS2)
29	GPS2_TX2	O	Ublox ZED-F9P TXD2 (GPS2)
30	+3.3V	PWR	Regulated 3.3V supply input/output.
31	GPS2_TIMEPULSE	O	GPS2 PPS UTC time synchronization signal.
32-36	NC	-	Not connected internally
37-69	GND	PWR	-

5.4.3 Hardware Versions

The following outlines differences in the IG-1.x hardware versions.

IG-1.2

- GPS1 ZED-F9P RXD2/TXD2 lines connected to IG-1 pins 26, 27.
- GPS2 ZED-F9P RXD2/TXD2 lines connected to IG-1 pins 28, 29.
- GPS1 ZED-F9P PPS (TIMEPULSE) line connected to IG-1 pin 31.
- IG-1 pins 32-36 are not connected internally (not connected to ground).

IG-1.1

- GPS1 PPS line connected to IMX TIMEPULSE G15 (pin 20).
- IG-1 pins 26-36 are connected to ground.

IG-1.0

- GPS1 PPS line connected to IMX G8 (pin 8).
- IG-1 pins 26-36 are connected to ground.

5.4.4 Schematic

[Download Schematic](#)

5.4.5 Hardware Design

Recommend PCB Footprint and Layout

The default forward direction is indicated in the PCB footprint figure and on the silkscreen as the X axis. The forward direction is reconfigurable in software as necessary.

[Download PDF](#)

5.4.6 Soldering

The IMX-5 can be reflow soldered. Reflow information can be found in the [Reflow Information](#) section of this manual.

5.4.7 Design Files

Open source hardware design files, libraries, and example projects for the IMX module are found at the [Inertial Sense Hardware Design repository](#) hosted on GitHub. These include schematic and layout files for printed circuit board designs, and 3D step models of the InertialSense products usable for CAD and circuit board designs.



Reference Design Projects

The IG-1 circuit board projects serve as reference designs that illustrate implementation of the IMX PCB module.

[IG-1 module](#)

5.4.8 Related Parts

Part	Manufacturer	Manufacturer #	Description
H1	JST	GHR-14V-S	14 pin connector 1.25mm pitch for IMX I/O connection.

5.5 Hardware Integration: IG-2 (IMX5 + GPX1)



The Inertial Sense IG-2 is a PCB module with IMX-5 and GPX-1 multi-frequency GNSS receiver.


- Surface mount reflowable.
- Onboard dual GNSS for simultaneous RTK positioning and GPS compassing.
- Micro USB and 14 pin I/O header for convenient evaluation.


5.5.1 Connecting Your Unit

For the purposes of basic evaluation, the easiest interface available on the IG-2 is by using a micro-USB cable. A cable included in the evaluation kit. The cable provides power and communications with the installed module via USB virtual communications port.











5.5.2 Pinout

Module Pinout

**Header H1 Pinout**



The IG-2 module and IG-2 header H1 have the same pinout assignment for pins 1-14. Because H1 only has 14 pins, pins 15 and above listed in the following table are only on the IG-2 module.

IG-2 Module & IG-2 H1 Pin	Name	I/O	Description
 1	GND	PWR	-
 2	VIN	PWR	4V-20V supply voltage input
 3	+3.3V	PWR	Regulated 3.3V supply input/output.
 4	Reserved		Not Connected
 5	G1/Rx2/RxCAN/SCL	I/O	IMX GPIO1 Serial 2 input (TTL) Serial input pin from CAN transceiver* I2C SCL line6
 6	G2/Tx2/TxCAN/SDA/ STROBE	I/O	IMX GPIO2 Serial 2 output (TTL) Serial output pin to CAN transceiver* I2C SDA line Strobe time sync input
 7	G3/Tx0	I/O	IMX GPIO3 Serial 0 output (TTL)
 8	G4/Rx0	I/O	IMX GPIO4 Serial 0 input (TTL)
 9	G5/SCLK/STROBE	I/O	IMX GPIO5 SPI SCLK Strobe time sync input
 10	G6/Rx1/MOSI	I/O	IMX GPIO6 Serial 1 input (TTL) SPI MOSI
 11	G7/Tx1/MISO	I/O	IMX GPIO7 Serial 1 output (TTL) SPI MISO
 12	G8/CS/STROBE	I/O	IMX GPIO8 SPI CS Strobe time sync input
 13	G9/nSPI_EN/ STROBE /STROBE_OUT/ SPI_DRDY	I/O	IMX GPIO9 SPI Enable: Hold LOW during bootup to enable SPI on G5-G8 Strobe time sync input or output. SPI data ready alternate location.
 14	GPS.TIMEPULSE	O	GPS PPS UTC time synchronization signal.
15	GND	PWR	-
16	VBAT	I/O	GPS backup supply voltage. (1.4V to 3.6V) enables GPS hardware backup mode for hot or warm startup (faster GPS lock acquisition). MUST connect GPS_VBAT to VCC if no backup battery is used.
17	G10/BOOT_MODE	I/O	Leave unconnected. IMX BOOT MODE used in manufacturing. !!! WARNING !!! Asserting a logic high (+3.3V) will cause the IMX to reboot into ROM bootloader (DFU) mode.

IG-2 Module & IG-2 H1 Pin	Name	I/O	Description
18	G11	I/O	IMX GPIO11
19	G12	I/O	IMX GPIO12 GPS reset
20	G13/DRDY	I/O	IMX GPIO13 SPI data ready
21	G14/SWCLK	I/O	IMX GPIO14
22	nRESET	I	System reset (IMX and GPX) on logic low. May be left unconnected if not used.
23	GND	PWR	-
24	USB_N	I/O	IMX USB Data Negative Line
25	USB_P	I/O	IMX USB Data Positive Line
26	GPX_G16/QDEC0A	I/O	GPX GPIO16
27	GPX_G17/QDEC0B	I/O	GPX GPIO17
28	GPX_G18/QDEC1A	I/O	GPX GPIO18
29	GPX_G19/QDEC1B	I/O	GPX GPIO19
30	+3.3V	PWR	Regulated 3.3V supply input/output.
31	GPX_G10_BOOT	I/O	GPX GPIO10
32	GPX_G5/SCLK	I/O	GPX GPIO5 GPX SPI clock
33	GPX_G6/Rx1/MOSI	I/O	GPX GPIO6 GPX Serial 1 input (TTL) GPX SPI MOSI
34	GPX_G7/Tx1/MISO	I/O	GPX GPIO7 GPX Serial 1 output (TTL) GPX SPI MISO
35	GPX_G8/CS	I/O	GPX GPIO8 GPX SPI chip select
36	GPX_G9/SPI_EN	I/O	GPX GPIO9 GPX SPI Enable: Hold LOW during bootup to enable SPI on G5-G8
37-47	GND	PWR	-

5.5.3 Schematic

[Download Schematic](#)

5.5.4 Hardware Design

Recommend PCB Footprint and Layout

The default forward direction is indicated in the PCB footprint figure and on the silkscreen as the X axis. The forward direction is reconfigurable in software as necessary.


[Download PDF](#)

5.5.5 Soldering

The IMX-5 can be reflow soldered. Reflow information can be found in the [Reflow Information](#) section of this manual.

5.5.6 Design Files

Open source hardware design files, libraries, and example projects for the IMX module are found at the [Inertial Sense Hardware Design repository](#) hosted on GitHub. These include schematic and layout files for printed circuit board designs, and 3D step models of the InertialSense products usable for CAD and circuit board designs.



Reference Design Projects

The EVB-2, IG-1, and IG-2 circuit board projects serve as reference designs that illustrate implementation of the IMX PCB module.

[EVB-2 evaluation board](#)


[IG-1 module](#)

[IG-2 module](#)

5.5.7 Related Parts

Part	Manufacturer	Manufacturer #	Description
H1	JST	GHR-14V-S	14 pin connector 1.25mm pitch for IMX I/O connection.

5.6 Hardware Integration: IK-1 (IMX5 or GPX1)



The Inertial Sense IK-1 is a breakout evaluation board for either the IMX-5 or GPX-1 multi-frequency GNSS receiver.


- 0.1" pitch header for convenient interface.
- Interfaces with standard breadboard.
- Onboard Micro USB connector
- Onboard voltage regulation.
- Dual U.FL connectors for GPX GNSS antennas.

5.6.1 Connecting Your Unit

For the purposes of basic evaluation, the easiest interface available on the IK-1 is by using a micro-USB cable. A cable included in the evaluation kit. The cable provides power and communications with the installed module via USB virtual communications port.

5.6.2 Pinout

Module Pinout



The IK-1 module pinout is as follows

IK1	IMX	GPX	Name	Type	Description
1-3	11,21	11,13,15,31	GND	Power	Supply ground
4	-	20	G20/LNA-EN	I/O	GPIO20, GPX LNA enable
5	-	21	GNSS2_PPS	O	GNSS2 PPS time synchronization output pulse (1Hz, 10% duty cycle)
6	1	1	USB_P	I/O	USB full-speed Positive Line. USB will be supported in future firmware updates.
7	2	2	USB_N	I/O	USB full-speed Negative Line. USB will be supported in future firmware updates.
8	3	3	VBKUP	Power	Backup supply voltage input (1.75V to 3.6V). Future firmware updates will use voltage applied on this pin to backup GNSS ephemeris, almanac, and other operating parameters for a faster startup when VCC is applied again. This pin MUST be connected to a backup battery or VCC.
9	4	4	G1/Rx2/RxCAN/ SCL	I/O	GPIO1 Serial 2 input (TTL) Serial input pin from CAN transceiver* I2C SCL line
10	5	5	G2/Tx2/TxCAN/ SDA/STROBE	I/O	GPIO2 Serial 2 output (TTL) Serial output pin to CAN transceiver* I2C SDA line Strobe time sync input
11	6	6	G6/Rx1/MOSI	I/O	GPIO6 Serial 1 input (TTL) SPI MOSI
12	7	7	G7/Tx1/MISO	I/O	GPIO7 Serial 1 output (TTL) SPI MISO
13	8	8	G8/CS/STROBE	I/O	GPIO8 SPI CS Strobe time sync input
14	9	9	G5/SCLK/ STROBE	I/O	GPIO5 SPI SCLK Strobe time sync input
15	10	10	G9/nSPI_EN/ STROBE /STROBE_OUT/ DRDY	I/O	GPIO9 SPI Enable: Hold LOW during boot to enable SPI on G5-G8 Strobe time sync input or output. SPI data ready alternate location
17	12	22	nRESET	I	System reset on logic low. May be left unconnected if not used.
18	13	23	G14/SWCLK	I/O	GPIO14
19	14	24	G13/DRDY/ XSDA	I/O	GPIO13 SPI Data Ready Alt I2C SDA


IK1	IMX	GPX	Name	Type	Description
20	15	25	G12/XSCL	I/O	GPIO12 Alt I2C SCL
21	16	26	G11/SWDIO	I/O	GPIO11
22	17	27	G10/ BOOT_MODE	I/O	Leave unconnected. BOOT MODE used in manufacturing. !!! WARNING !!! Asserting a logic high (+3.3V) will cause the IMX to reboot into ROM bootloader (DFU) mode.
23	18	28	G4/Rx0	I/O	GPIO4 Serial 0 input (TTL)
24	19	29	G3/Tx0	I/O	GPIO3 Serial 0 output (TTL)
25	20	30	GNSS1_PPS	O	GNSS1 PPS time synchronization output pulse (1Hz, 10% duty cycle)
27	22	32	VCC	Power	1.8V to 3.3V supply input.
28	-	38	G16/QDEC0.A	I/O	GPIO16
29	-	39	G17/QDEC0.B	I/O	GPIO17
30	-	40	VAUX	Power	Input supplies for the USB and VCC_RF (GNSS antenna supply). Connect to +3.3V (3.0V to 3.6V) to supply USB and VCC_RF. Can be left floating if USB or VCC_RF are not needed.
31	-	41	G18/QDEC1.A	I/O	GPIO18
32	-	42	G19/QDEC1.B	I/O	GPIO19
U.FL1	-	12	GNSS1_RF	I	GNSS1 antenna RF input. Use an active antenna or LNA with a gain of 15-25dB. Place the LNA as close to the antenna as possible. Filtered 3.3V from VCC is injected onto the pad to power active antennas (power injection can be disabled in software). Connect to ground with 5V-14V TVS diode for ESD and surge projection (e.g. Littelfuse PESD0402-140).
U.FL2	-	14	GNSS2_RF	I	GNSS2 antenna RF input. Same requirements as GNSS1_RF

5.6.3 Schematic

[Download Schematic](#)

5.6.4 Design Files

Open source hardware design files, libraries, and example projects for the IMX module are found at the [Inertial Sense Hardware Design repository](#) hosted on GitHub. These include schematic and layout files for printed circuit board designs, and 3D step models of the InertialSense products usable for CAD and circuit board designs.



Reference Design Projects

The EVB-2, IG-1, IG-2, and IK-1 circuit board projects serve as reference designs that illustrate implementation of the IMX PCB module.

[EVB-2 evaluation board](#)

[IG-1 module](#)

[IG-2 module](#)

[IK-1 module](#)

5.6.5 Related Parts

Part	Manufacturer	Manufacturer #	Description
-------------	---------------------	-----------------------	--------------------

5.7 Hardware Design Files

The Inertial Sense hardware design files are available on our [IS-hdw repository](#) to facilitate product hardware development and integration.


- **PCB Libraries** - Schematic and layout files for printed circuit board designs.
- **Products** - 3D models and resources for the IMX, Rugged, EVB, and products useful for CAD and circuit board designs.

5.8 Reflow Soldering

Use of "No Clean" soldering paste is recommended as it does not require cleaning after the soldering process. The following examples of paste meet these criteria.

Solder	Details
Soldering Paste	OM338 SAC405 / Nr.143714 (Cookson Electronics)
Allow Specification	Sn 95.5/ Ag 4/ Cu 0.5 (95.5% Tin/ 4% Silver/ 0.5% Copper)
Melting temperatures	217 °C

5.8.1 The following reflow profile is recommended for soldering:



Phase	Name	Recommended	Details
Preheat			
	dT/dt	3°C/sec	Preheat Temperature Rise Rate
	T _s MIN	150°C	Preheat Minimum Temperature
	T _s MAX	200°C	Preheat Maximum Temperature
	t _s Preheat	60 - 120 sec	Time Spent Between Preheat MIN and Max temperatures
Reflow			
	T _L	217°C	Reflow Liquidus temperatures
	T _p	245°C	Reflow Peak temperatures
	t _L	40-60 sec	Time Spent above Reflow Liquidus temperatures
Cooling			
	dT/dt	4°C/sec	Maximum Cooling Temperature Fall Rate

 **Important**

A convection soldering oven is highly recommended over an infrared type radiation oven as it allows precision control of the temperature and all parts will be heated evenly.

 **Warning**

The IMX should be located on the topside of a PCB during reflow to avoid falling off.

Care should be taken to not disturb the components on the IMX during reflow as the solder on the IMX will also reflow.

The part must not be soldered with a damp heat process.

6. IS Software

6.1 CLTool

6.1.1 Overview

The Inertial Sense CLTool is a command line utility that can be used to read and display data, update firmware, and log data from Inertial Sense products. Additionally, CLTool serves as example source code that demonstrates integration of the Inertial Sense SDK into your own source code. The CLTool can be compiled in Linux, Mac, Windows and embedded platforms.

6.1.2 Help Menu

```
# Command line utility for communicating, logging, and updating firmware with Inertial Sense product line.

EXAMPLES
cltool -c /dev/ttyS2 -did DID_INS_1 DID_GPS1_POS DID_PIMU      # stream DID messages
cltool -c /dev/ttyS2 -did 4 13 3                               # stream same as line above
cltool -c /dev/ttyS2 -did 3=5                                 # stream DID_PIMU at startupNavDtMs x 5
cltool -c /dev/ttyS2 -presetPPD                               # stream post processing data (PPD) with INS2
cltool -c /dev/ttyS2 -presetPPD -lon -lts=1                   # stream PPD + INS2 data, logging, dir timestamp
cltool -c /dev/ttyS2 -edit DID_FLASH_CONFIG                   # edit DID_FLASH_CONFIG message
cltool -c /dev/ttyS2 -baud=115200 -did 5 13=10                # stream at 115200 bps, GPS streamed at 10x startupGPSDtMs
cltool -c * -baud=921600                                       # 921600 bps baudrate on all serial ports
cltool -rp logs/20170117_222549                               # replay log files from a folder
cltool -c /dev/ttyS2 -rover=RTCM3:192.168.1.100:7777:mount:user:password # Connect to RTK NTRIP base

EXAMPLES (Firmware Update)
cltool -c /dev/ttyS2 -ufpkg fw/IS-firmware.fpkg
cltool -c /dev/ttyS2 -uf fw/IS_IMX-5.hex -ub fw/IS_bootloader-STM32L4.hex -uv

OPTIONS (General)
-h --help                Display this help menu.
-c DEVICE_PORT           Select the serial port. Set DEVICE_PORT to "*" for all ports or "*4" for only first four available.
-baud=BAUDRATE           Set serial port baudrate. Options: 115200, 230400, 460800, 921600 (default)
-magRecal[n]             Recalibrate magnetometers: 0=multi-axis, 1=single-axis
-q                       Quiet mode, no display.
-reset                   Issue software reset.
-s                       Scroll displayed messages to show history.
-stats                   Display statistics of data received.
-survey=[s],[d]          Survey-in and store base position to reflLa: s=[2=3D, 3=float, 4=fix], d=durationSec
-ufpkg FILEPATH          Update firmware using firmware package file (.fpgk) at FILEPATH.
-uf FILEPATH             Update application firmware using .hex file FILEPATH. Add -baud=115200 for systems w/ baud rate limits.
-ub FILEPATH             Update bootloader using .bin file FILEPATH if version is old. Must be used along with option -uf.
-fb                      Force bootloader update regardless of the version.
-uv                      Run verification after application firmware update.
-sysCmd=[c]             Send DID_SYS_CMD c (see eSystemCommand) preceded by unlock command then exit the program.
-factoryReset            Reset IMX flash config to factory defaults.
-romBootloader           Reboot into ROM bootloader mode. Requires power cycle and reloading bootloader and firmware.
-v                       Print version information.

OPTIONS (Message Streaming)
-did [DID#<=PERIODMULT> DID#<=PERIODMULT> ...] Stream 1 or more datasets and display w/ compact view.
-edit [DID#<=PERIODMULT>] Stream and edit 1 dataset.
Each DID# can be the DID number or name and appended with <=PERIODMULT> to decrease message frequency.
Message period = source period x PERIODMULT. PERIODMULT is 1 if not specified.
Common DIDs: DID_INS_1, DID_INS_2, DID_INS_4, DID_PIMU, DID_IMU, DID_GPS1_POS,
DID_GPS2_RTK_CMP_REL, DID_BAROMETER, DID_MAGNETOMETER, DID_FLASH_CONFIG (see data_sets.h for complete list)
-dids                   Print list of all DID datasets
-persistent              Save current streams as persistent messages enabled on startup
-presetPPD               Stream preset post processing datasets (PPD)
-presetINS2              Stream preset INS2 datasets

OPTIONS (Logging to file, disabled by default)
-lon                     Enable logging
-lt=TYPE                 Log type: raw (default), dat, kml or csv
-lp PATH                 Log data to path (default: ./IS_logs)
-lms=PERCENT             Log max space in percent of free space (default: 0.5)
-lmf=BYTES               Log max file size in bytes (default: 5242880)
-lts=0                   Log sub folder, 0 or blank for none, 1 for timestamp, else use as is
-r                       Replay data log from default path
-rp PATH                 Replay data log from PATH
-rs=SPEED                Replay data log at x SPEED. SPEED=0 runs as fast as possible.

OPTIONS (Read flash configuration from command line)
-flashCfg                # List all "keys" and "values"
"-flashCfg=[key][key][key]" # List select values

OPTIONS (Write flash configuration from command line)
"-flashCfg=[key]=[value][key]=[value]" # Set key / value pairs in flash config.
# Surround with "quotes" when using pipe operator.

EXAMPLES
cltool -c /dev/ttyS2 -flashCfg # Read from device and print all keys and values
```



```

cltool -c /dev/ttyS2 "-flashCfg=insOffset[1]=1.2]=ser2BaudRate=115200" # Set multiple values

OPTIONS (RTK Rover / Base)
-rover=[type]:[IP or URL]:[port]:[mountpoint]:[username]:[password]
  As a rover (client), receive RTK corrections. Examples:
  -rover=TCP:RTCM3:192.168.1.100:7777:mountpoint:username:password (NTRIP)
  -rover=TCP:RTCM3:192.168.1.100:7777
  -rover=TCP:UBLOX:192.168.1.100:7777
  -rover=SERIAL:RTCM3:/dev/ttyS2:57600 (port, baud rate)
-base=[IP]:[port] As a Base (server), send RTK corrections. Examples:
  -base=TCP::7777 (IP is optional)
  -base=TCP:192.168.1.43:7777
  -base=SERIAL:/dev/ttyS2:921600

```

6.1.3 Compile & Run (Linux/Mac)

1. You must have cmake installed on your machine. To do this, download the cmake application at <https://cmake.org/download/>. Then, using the command line, you will need to install cmake with either of the following commands depending on your platform:

```

Mac:
sudo "/Applications/CMake.app/Contents/bin/cmake-gui" --install

Linux:
sudo apt-get install cmake

```

2. Create build directory

```

cd cltool
mkdir build

```

3. Run cmake from within build directory

```

cd build
cmake ..

```

4. Compile using make

```

make

```

5. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```

sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)

```

6. Run executable

```

cd build
./cltool

```

6.1.4 Compile & Run (Windows CMake CL)

1. Install CMake for Windows
2. Create build directory ``bash cd cltool mkdir build
3. Run cmake from within build directory

```

cd build
cmake ..

```

4. Compile

```

cmake --build .

```

5. Run executable

```

cd Release (or Debug depending on CMake configuration you selected)
cltool.exe

```

6.1.5 Compile & Run (Windows CMake Visual Studio)

Windows Visual Studio supports CMake projects. Follow the instructions provided by Microsoft: <https://learn.microsoft.com/en-us/cpp/build/cmake-projects-in-visual-studio?view=msvc-170>

6.1.6 Updating Firmware with CLTool

Updating using Firmware Package

Updating firmware using a firmware package file provides a simple method to update multiple devices in one process. This include the ability to update an IMX-GPX module pair in one step. The cltool only needs know the file path of the firmware package file and the serial port of the device to be updated. The file extension for a firmware package is `.fpkg`.

NOTE: Updating the IMX firmware using a firmware package currently not supported and will become available in a future update.

```
cltool -c DEVICE_PORT -ufpkg FILEPATH
```

The following is a specific example of using a firmware package file:

```
cltool -c /dev/ttyACM0 -ufpkg IS-firmware_2.0.3_2024-03-18_213925.fpkg
```

Updating using Single Firmware File (Legacy Mode)

The CLTool can be used to update device firmware with the following options. This is the legacy firmware update methods that works only with the IMX-5.0 and earlier products (uINS-3, EVB-2, etc.).

```
cltool -c DEVICE_PORT -uf [FW_FILEPATH] -ub [BL_FILEPATH] -uv
```

Options	Description
<code>-c DEVICE_PORT</code>	Specifies the device serial or USB port (i.e. <code>/dev/ttyACM0</code>).
<code>-uf [FW_FILEPATH]</code>	Specifies the application firmware file path.
<code>-ub [BL_FILEPATH]</code>	(Optional) Specified the bootloader firmware file. The bootloader is only updated if the version of the file provided is newer than the bootloader version currently on the device.
<code>-uv</code>	(Optional) Run verification after application firmware update.

The following is a specific example:

```
cltool -c /dev/ttyS2 -uf fw/IS_IMX-5.hex -ub fw/IS_bootloader-STM32L4.hex -uv
```

Note: The firmware can only be updated at the following baud rates: 300000, 921600, 460800, 230400, 115200

6.1.7 Logging with CLTool

The CLTool can be used to log data to file with the following options:

```
cltool -c DEVICE_PORT -lon -lt=LOG_TYPE -lp DIRECTORY
```

Options	Description
<code>-lon</code>	Enable logging.
<code>-lt=LOG_TYPE</code>	Specifies the log file type to be written. LOG_TYPE can be <code>raw</code> , <code>dat</code> , or <code>csv</code> .
<code>-lp DIRECTORY</code>	(Optional) Specifies the path where log files will be written. When not specified, the default location will be the current working directory.

Log File Types

Log Type	Description
raw	Binary file containing byte for byte data received over the serial ports. All packets remain in their native form. Used for logging InertialSense binary (ISB), NMEA, RTCM3, uBlox UBX binary and SPARTN, and any other packet formats. Recommended for logging all data formats and post processing.
dat	Binary file containing InertialSense binary (ISB) DID data sets in "chunk" groups containing data in serial order as they appear over the serial port. Default file format. Recommended for post processing.
csv	Comma-Separated Values - Plain text file that uses specific structuring to arrange tabular data. Its basic format involves separating each data field (or cell in a table) with a comma and each record (or row) is on a new line. This simple format allows for ease in data import and export between programs that handle tabular data, such as databases and spreadsheets.

The following is an example of enabling the logger with type raw and specifying the output directory:

```
./cltool -c /dev/ttyACM0 -lon -lt=raw -lp /media/usbdrive/data
```

6.1.8 Command Line Options


Navigate to the directory `/cpp/SDK/cltool/build` and run the CLTool with the help option, "`-h`"

```
./cltool -h
```

to display the command line options

6.1.9 Command Line Options in MS Visual Studio

When using MS Visual Studio IDE, command line arguments can be supplied by right clicking the project in the solution explorer and then selecting **Configuration Properties -> Debugging -> Command Arguments** (see image below).



6.2 EvalTool


6.2.1 Overview

The EvalTool (Evaluation Tool) is a desktop GUI application that allows you to explore and test functionality of the Inertial Sense products in real-time. It has scrolling plots, 3D model representation, table views of all data, data logger, and firmware updating interface for the IMX, uAHRS, or uIMU. The EvalTool can simultaneously interface with multiple Inertial Sense devices.

6.2.2 Download and Install

The EvalTool Windows desktop app installer (.exe) can be downloaded from the [Inertial Sense releases](#) page.

6.2.3 Getting Started



With a device connected to your computer:

1. Connect your INS to your computer using directions in the IS Hardware section of this guide corresponding to the correct model.
2. Open the **Settings > Serial Ports** tab.
3. Click the **Find All** button, or open the port to your device by checking the **Open** checkbox.
4. The status box in the **Port** column will turn green and the **Link** status bar will turn green while data is being received from the device.
5. You can specify the serial port baud rate using the **Baud Rate** dropdown menu when using a serial interface like RS232.

DATA LOGGING STEPS

In order to log data from your INS device, follow the steps listed below:

1. Connected your device to the EvalTool and open the port.
2. Go to the **Data Logs** tab.
3. Enable the data that you would like collected in the **Data Streams** area:
 - a. Select one of the **RMC Preset** menu options. This automatically enables standard messages commonly used for logging. **PPD** (Post Processed Data) is the recommended default.
 - b. Enable any of the **DID** messages listed below by checking the **On** checkbox and setting the **Period Mult**.
4. Configure and enable logging in the **Data Log** area:
 - a. The **Open Folder** button opens the log directory in a file explorer window where logs are saved.
 - b. The **Format** dropdown menu selects the output log file format (.raw .dat .csv .kml).
 - c. Press **Log** to start recording a new log.
5. The data you are currently recording will be shown in the “Log Summary” sub-tab.
6. When you are finished recording data, press “Disable”. Your data will be saved in the location shown in “Open Folder”.


6.2.4 Info Bar

The Info Bar can be seen from any tab and shows basic connection information for the unit selected.



1. Link Status - Shows Packets being Transmitted and Received. counts to 99 then resets to 0.
2. Error Message - Shows error messages for the selected unit. The kinds of messages vary from data packets lost to system had a reset.
3. RTK Base Messages - The number in this field will increment as your rover unit continues to receive RTK messages from your base station. Use this field as the main signifier that RTK messages are coming through.
4. Currently selected unit - The unit with the serial number shown here will have its live data shown on each tab in EvalTool.

6.2.5 Update Firmware



1. Go to the **Settings > Serial Port** tab.
2. Open the Ports of the units you would like to update. If the units don't open up, you may have to change the baud rate.
3. Click **Update Firmware**.
4. Select the update type using the drop down menu:

Update Type	Description
FwPkg (.fpkg)	Batch firmware update method for updating multiple devices in one process. The .fpkg file contains multiple firmware files and instructions for sequencing firmware updates for all available devices. NOTE: IMX-5 firmware update is not yet supported but will be in a future update.
GPX-1 (.bin)	GPX-1 firmware update.
IMX-5.0 (.hex)	(Legacy mode) IMX-5.0 firmware update that used the legacy InertialSense bootloader (ISB).

1. Select the firmware file by clicking on the ellipsis (three dots) button next to the file name and navigating to and opening the file.

1. For the IMX-5.0 update type, you can optionally select the bootloader .bin file. The bootloader will only be updated if the selected file is newer than the bootloader on the connected unit.


1. Click **Start**.

1. Wait for the progress to reach 100% and click **Done**.

*Note: The firmware can only be updated at the following baud rates: 300000, 921600, 460800, 230400, 115200.


6.2.6 Tab Descriptions

INS Tab




1. Attitude Plot and Table - shows the Roll, Pitch, and Yaw values of the selected unit. Hover the cursor of the radio buttons to see more descriptions.
2. Velocity Plot and Table - U,V,W velocities.
3. LLA Plot and Table - Tabular values and plot of Latitude, Longitude, and Altitude.
4. Simulation - Real-time, simulated image of the INS orientation.
5. GPS Summary - Strength of GPS signal and accuracy.
6. Mag Recal Button - Allows you to calibrate your units about either a single axis (for heavy, ground based vehicles) or multi-axes.
7. BIT (Built-In Test) Button - Runs a system of checks on your unit.
8. Link Messages - shows the performance information on connected units and displays error messages.

Sensors Tab




1. Gyros Plot and Table - Gyroscopic data on the selected unit. Includes standard deviation.
2. Accelerometers Plot and Table - Accelerometer data on the selected unit. Includes standard deviation.
3. Magnetometers Plot and Table - Magnetometer data on the selected unit. Includes standard deviation.
4. Barometer Plot and Table - Barometric, temperature, and humidity data on the selected unit. Includes standard deviation.

GPS Tab



1. GPS CNO Signal Strength - Bar graphs of each satellite being used in your solution and its strength in dBHz(CNO).
2. Position Accuracy Plot and Table - RTK mode and status. Includes number of satellites used in the RTK solution (max and mean).
3. Satellites Used Table - The GNSS ID for each satellite seen by your unit and the subsequent connection details.

Map Tab



1. Track Active - Tracks all units on window view.
2. Zoom to Fit - Zooms your window view around each unit being used.
3. Manual - Requires manual movement of the window view.
4. Location of Units - GPS location of each of your units. Shows RTK, GPS ublox, and INS solution.

Data Sets Tab

The screenshot shows the 'Data Sets' tab in the 'Inertial Sense - EvalTool' application. The interface is divided into two main sections: a list of Data Identifiers (DIDs) on the left and a table of variables for the selected DID on the right.

Variables Table:

Variable	SN60339	Units	Description
week	2306	week	Weeks since Jan 6, 1980
timeOfWeek	255218.1018	s	Time of week since Sunday morning, GMT
insStatus	0x43035D77		INS Status flags [0,0,MagStatus,SolStatus, NavMode,GpsMagUsed,Variance,VarianceCoarse]
hdwStatus	0x00180050		Hdw Status flags [Fault,BIT,RxErrCount,ComErr, SenSatHist,SensorSat,GpsSatRx,Motion]
theta[0] roll	1.131	°	Euler angle - roll
theta[1] pitch	-0.046	°	Euler angle - pitch
theta[2] yaw	21.523	°	Euler angle - yaw
uvw[0]	0.003	m/s	Velocity in body frame
uvw[1]	0.001	m/s	
uvw[2]	-0.001	m/s	
ned[0] north	9.375	m	North offset from reference LLA
ned[1] east	25.039	m	East offset from reference LLA
ned[2] down	-4.499	m	Down offset from reference LLA
lla[0] latitude	40.05570297	°	WGS84 coordinate - latitude
lla[1] longitude	-111.65863007	°	WGS84 coordinate - longitude
lla[2] altitude	1418.9828	m	WGS84 coordinate - ellipsoid altitude

The status bar at the bottom of the window displays the following information: Link: Tx 83, Rx 75; Log OFF; BASE: 39 (1.1 KB/s); SN60339 H:5.0.4 F:2.0.3 C:2.0.0.0.

1. List of DIDs (Data Identifiers) - The data identifiers that you might need to view for measurements. See the User Manual (Binary Protocol Data Sets) for a detailed description of frequently used DIDs.
2. List of Variables within DIDs - shows what is recorded in each DID in real-time.

Data Logs

The screenshot shows the 'Inertial Sense - EvalTool' application window. The 'Data Logs' tab is active. On the left, the 'Data Streams' section contains a table of Data IDs (DIDs) and their configurations. The 'RMC Presets' dropdown is set to 'PPD'. Below the table is an 'NMEA Command' field with the text '\$ ASCE,0,3,2,1,1,6,1' and a 'Send' button. On the right, the 'Data Log' section shows 'Logging: 1.3 MB @ 11.7 KB/s' and a 'Log PPD' button. Below this is a 'Format' dropdown set to 'Raw packet (.raw)'. The 'Log Summary' section displays a table of logged data. At the bottom right, the 'File Conversion Utility' section has buttons for 'Options', 'Select Directory', and 'Send', along with input fields for 'Input Type' (Raw packet (.raw)) and 'Output Type' (Comma separated (.csv)).

DID	Name	On	Period Mult.	Count	dt (ms)
-1	CONFIG	<input checked="" type="checkbox"/>	1		
12	DID_FLASH_CONFIG	<input type="checkbox"/>	100	12	9965
121	DID_GPX_FLASH_CFG	<input type="checkbox"/>	100		
-1	SOLUTION	<input checked="" type="checkbox"/>	1		
4	DID_INS_1	<input type="checkbox"/>	14		
5	DID_INS_2	<input checked="" type="checkbox"/>	14	1188	98
65	DID_INS_3	<input type="checkbox"/>	14		
66	DID_INS_4	<input type="checkbox"/>	14		
10	DID_SYS_PARAMS	<input type="checkbox"/>	100	12	9971
-1	SENSORS	<input checked="" type="checkbox"/>	1		
3	DID_PIMU	<input checked="" type="checkbox"/>	1	8313	14
58	DID_IMU	<input type="checkbox"/>	1		
96	DID_IMU3_RAW	<input type="checkbox"/>	1		
97	DID_IMU_RAW	<input type="checkbox"/>	1		
52	DID_MAGNETOMETER	<input checked="" type="checkbox"/>	1	11638	10
53	DID_BAROMETER	<input checked="" type="checkbox"/>	1	5819	20
71	DID_WHEEL_ENCODER	<input type="checkbox"/>	1		
54	DID_GPS1_RTK_POS	<input type="checkbox"/>	1		
22	DID_GPS1_RTK_POS_MISC	<input type="checkbox"/>	1		
21	DID_GPS1_RTK_POS_REL	<input checked="" type="checkbox"/>	1	582	200

DID	Count	Name	dt (ms)
12	12	DID_FLASH_CONFIG	9965
5	1187	DID_INS_2	98
10	12	DID_SYS_PARAMS	9971
3	8312	DID_PIMU	14
52	11638	DID_MAGNETOMETER	10
53	5818	DID_BAROMETER	20
21	582	DID_GPS1_RTK_POS_REL	200
13	582	DID_GPS1_POS	200
14	582	DID_GPS2_POS	200
30	582	DID_GPS1_VEL	200
31	582	DID_GPS2_VEL	200
1	12	DID_DEV_INFO	9965
48	554	DID_INL2_STATES	210

DATA STREAMS

This area allow users to enable streaming of various DIDs.

1. RMC Presets Button - Enable a group of data sets. PPD (post process data) is the preferred preset for post processing and debug analysis.
2. Save Persistent Button - Save currently enabled data streams to automatically begin streaming after system restart. To clear persistent streams, first stop streaming and then click Save Persistent.
3. Stop Streaming - Stops all data streams. Any streams previously saved as persistent will begin streaming at startup.

DATA LOG

1. Enable/Disable Button - Starts/stops a log of all currently streaming data and saves it to a sub-folder with the current time-stamp within your "Logs" folder.
2. Open Folder Button - Opens the "Logs" folder where your previous logs are saved.
3. Format Dropdown - Select the file output type of the data log , such as .raw , .dat , .csv, or .kml.


Log Format	Description
Raw packet (.raw)	Binary file containing byte for byte data received over the serial ports. All packets remain in their native form. Used for logging InertialSense binary (ISB), NMEA, RTCM3, uBlox UBX binary and SPARTN, and any other packet formats. Recommended for logging all data formats and post processing.
Serial binary (.dat)	Binary file containing InertialSense binary (ISB) DID data sets in "chunk" groups containing data in serial order as they appear over the serial port. Default file format. Recommended for post processing.
Comma separated (.csv)	Plain text file that uses specific structuring to arrange tabular data. Its basic format involves separating each data field (or cell in a table) with a comma and each record (or row) is on a new line. This simple format allows for ease in data import and export between programs that handle tabular data, such as databases and spreadsheets.

4. Summary Window - Shows the log directly path, the elapsed time the data log has been running, the total size of the log file, and a list currently recording DIDs with corresponding dt (time between measurements).
5. File Conversion Utility - Enables you to convert the data log file type in a specified directory. (e.g. .dat to .csv)

Settings Tab


The Settings tab has 3 sub tabs and they are as follows:

Settings - Serial Ports Tab



1. Open All - Opens all of the ports shown.
2. Close All - Closes all of the ports shown.
3. Find Devices - Determines which peripherals into your computer are Inertial Sense units, and opens those ports while closing the others.
4. Baud Rate - The rate at which data will be communicated over your data channel.
5. Update Firmware - Allows you to update your unit's firmware when an update is released from Inertial Sense.
6. Port Status - Shows a list of all connected comports and basic information for each of them. Clicking the check box opens the port.

Settings - General Tab




1. Software Reset - Allows the user to issue a reset to the unit. has options for all open comports and only the currently connected unit.
2. Zero Motion - Allows the user to informs the EKF that the system is stationary on the ground and is used to aid in IMU bias estimation which can reduce drift in the INS attitude.
3. DID_Flash_Config - Gives the user option to disable or enable different features normally found in the "Data Sets" tab. For more information about the Flash Config see [Data sets](#).

Settings - GPS Tab

1. IMX Parameters - Shows flash config settings commonly used when setting up RTK units
2. Status - Shows information important to using RTK.
3. Rover/Base Mode - Used in setup of RTK Rovers and RTK base Stations.
4. Message Window - Shows confirmation messages and Flash Config writes.

About Tab

The about tab shows version information for the EvalTool and connected device. It also provides helpful links to online documentation and software release information.



6.3 SDK

Overview

The Inertial Sense open source software development kit (SDK) provides quick integration for communication with the Inertial Sense product line, including the μ IMU, μ AHRS, and μ INS. It includes data logger, math libraries, and serial port interface for Linux and Windows environments.

6.3.1 C vs. C++ Implementation

The Inertial Sense SDK provides both C and C++ programming language implementation. The following compares differences between these implementations.

C

- Easier implementation
- Light weight
- Smaller code size
- Minimal subset of SDK files
- Recommended for smaller projects that require lower memory usage.
- SDK files: ISComm.c

C++

- Object oriented device representation
- Fully integrated support for:
 - Commutations: single or multiple data type callback functions.
 - Serial port handling included
 - Datalogging
 - Firmware update (bootloader)
- Recommended for typical to advanced C++ applications and production level integration.
- SDK files: InertialSense.cpp

6.3.2 Installing and Configuring Visual Studio

The SDK example projects can be conveniently compiled using gcc with cmake or Visual Studio. The following sections outline how to setup Visual Studio for use with the SDK example projects.

Installing


The SDK example projects can be compiled using the Community (free) version of Visual Studio. Windows SDK should be installed in addition to Visual Studio, as an added option in the Visual Studio installer or using the separate Windows SDK installer.

- [Visual Studio](#)
- Windows SDK - Can be installed using option in Visual Studio Installer or using [separate Windows SDK installer](#).

Configuring

When compiling an Inertial Sense SDK example project in Visual Studio, the currently installed version of Windows SDK must be selected in the project properties, as illustrated below:

Project properties > General > Windows SDK Version > [Currently Installed Version]



6.3.3 SDK Example Projects Overview

Example Project	Language	Description
NMEA Communications	C	How to use SDK for NMEA NMEA communications.
Binary Communications	C	How to use SDK for binary communications.
Firmware Update	C	How to use bootloader for embedded firmware update.
Data Logger	C++	How to use SDK data logging.
CLTool	C++	Open source project illustrating how to use the InertialSense C++ class. It combines all SDK capabilities including serial communications, data logging to file, and embedded firmware update.

6.3.4


6.4 Log Inspector

6.4.1 Overview

Log Inspector is an open source python utility for viewing and scrubbing InertialSense data log (.dat) files.

6.4.2 Getting Started

Log Inspector can open and plot .dat PPD log files. The lower left hand corner file browser allows you to enter a "working directory" in the directory field. The whole directory containing the desired is selected from the directory tree. Once the log is opened, the buttons in the upper left hand corner are used to graph various data sets.



6.4.3 Standard data sets

- POS NED Map - Used to plot INS position data in NED frame.
- POS NED - INS position in NED frame.
- POS LLA - INS and GNSS position in LLA.
- GPS LLA - GNSS LLA position.
- Vel NED - Velocity in NED frame.
- Vel UVW - Velocity in body frame.
- Attitude - Euler angle attitude in degrees.
- Heading - Heading data from magnetometer, INS, and RTK.
- INS Status - Plots of status flags vs time.
- HDW Status - plots of hardware status flags vs time.

6.4.4 Building

Note - logInspector requires Python 3.

Navigate to the Inertial Sense SDK directory

```
pip3 install logInspector/ # (this will return an error message, but will install all the dependencies you need)
cd logInspector
python3 setup.py build_ext --inplace
```

Create a config file.

```
C:\Users\[USER]\Documents\Inertial_Sense\log_inspector.yaml
```

Add the following or similar contents to this file.

```
directory: C:\Users\\Documents\Inertial_Sense\Logs\20181116_SKI\morning_run_1\back\20181116_175352
log_directory: C:\Users\\Documents\Inertial_Sense\Logs
serials: ["ALL"]
```

6.4.5 Running

To run logInspector open a shell and navigate to the logInspector directory and enter the following commands:

```
python3 logInspector.py
```

6.4.6 Other Directory Contents

The *logInspector* also contains some example implementations for dealing with log files directly in python.

logReader

This python module is responsible for loading the log file through a pybind11 interface. All the data in the log is eventually put in the `log.data` array.

logPlotter

This python module is responsible for creating plots. Adding new plots is easy, data is directly accessed using the member `logReader` object.

logInspector

A pyqt5 GUI which uses logPlotter to generate plots.

7. Communication Protocols

7.1 Protocol Overview

The Inertial Sense products support binary and NMEA protocol for communication.

7.1.1 Binary vs. NMEA

The following table compares the differences and advantages between the binary and NMEA protocols.

	NMEA Protocol	Binary Protocol
Data Efficient	No. Numbers must be converted to IEEE float and integers for application. Data occupies more memory.	Numbers are in floating point and integer binary format used in computers. Data occupies less memory.
Human Readable	Yes	No
Complexity	Packet are easier to parse.	Packet encoding, decoding, and parsing are MORE complicated. Using SDK is recommended.
SDK Support	Yes, less	Yes, more
Data Access	Limited to sensor and INS output.	Comprehensive access to all data and configuration settings.
Recommended Use	Rapid prototypes and simple projects. Devices supporting NMEA.	Moderate to advanced applications.
Apps and Examples	NMEA Communications Example	EvalTool , CLTool , Binary Communications Example , Fimrware Update Example , Data Logger Example

7.2 Data Sets (DIDs)

7.2.1 Data Sets (DIDs)

Data Sets in the form of C structures are available through binary protocol and provide access to system configuration and output data. The data sets are defined in SDK/src/data_sets.h of the InertialSense SDK.

INS / AHRS Output

DID_INS_1

INS output: euler rotation w/ respect to NED, NED position from reference LLA.

ins_1_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
insStatus	uint32_t	INS status flags (eInsStatusFlags). Copy of DID_SYS_PARAMS.insStatus
hdwStatus	uint32_t	Hardware status flags (eHdwStatusFlags). Copy of DID_SYS_PARAMS.hdwStatus
theta	float[3]	Euler angles: roll, pitch, yaw in radians with respect to NED
uvw	float[3]	Velocity U, V, W in meters per second. Convert to NED velocity using "vectorBodyToReference(uvw, theta, vel_ned)".
lla	double[3]	WGS84 latitude, longitude, height above ellipsoid (degrees,degrees,meters)
ned	float[3]	North, east and down (meters) offset from reference latitude, longitude, and altitude to current latitude, longitude, and altitude

DID_INS_2

INS output: quaternion rotation w/ respect to NED, ellipsoid altitude

ins_2_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
insStatus	uint32_t	INS status flags (eInsStatusFlags). Copy of DID_SYS_PARAMS.insStatus
hdwStatus	uint32_t	Hardware status flags (eHdwStatusFlags). Copy of DID_SYS_PARAMS.hdwStatus
qn2b	float[4]	Quaternion body rotation with respect to NED: W, X, Y, Z
uvw	float[3]	Velocity U, V, W in meters per second. Convert to NED velocity using "quatRot(vel_ned, qn2b, uvw)".
lla	double[3]	WGS84 latitude, longitude, height above ellipsoid in meters (not MSL)

DID_INS_3

Inertial navigation data with quaternion NED to body rotation and ECEF position.

ins_3_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
insStatus	uint32_t	INS status flags (eInsStatusFlags). Copy of DID_SYS_PARAMS.insStatus
hdwStatus	uint32_t	Hardware status flags (eHdwStatusFlags). Copy of DID_SYS_PARAMS.hdwStatus
qn2b	float[4]	Quaternion body rotation with respect to NED: W, X, Y, Z
uvw	float[3]	Velocity U, V, W in meters per second. Convert to NED velocity using "quatRot(vel_ned, qn2b, uvw)".
lla	double[3]	WGS84 latitude, longitude, height above ellipsoid in meters (not MSL)
msl	float	height above mean sea level (MSL) in meters

DID_INS_4

INS output: quaternion rotation w/ respect to ECEF, ECEF position.

ins_4_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
insStatus	uint32_t	INS status flags (eInsStatusFlags). Copy of DID_SYS_PARAMS.insStatus
hdwStatus	uint32_t	Hardware status flags (eHdwStatusFlags). Copy of DID_SYS_PARAMS.hdwStatus
qe2b	float[4]	Quaternion body rotation with respect to ECEF: W, X, Y, Z
ve	float[3]	Velocity in ECEF (earth-centered earth-fixed) frame in meters per second
ecef	double[3]	Position in ECEF (earth-centered earth-fixed) frame in meters

Inertial Measurement Unit (IMU)

DID_IMU

Inertial measurement unit data down-sampled from IMU rate (DID_FLASH_CONFIG.startupImuDtMs (1KHz)) to navigation update rate (DID_FLASH_CONFIG.startupNavDtMs) as an anti-aliasing filter to reduce noise and preserve accuracy. Minimum data period is DID_FLASH_CONFIG.startupNavDtMs (1KHz max).

imu_t

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding gps.towOffset
status	uint32_t	IMU Status (eImuStatus)
I	imus_t	Inertial Measurement Unit (IMU)

DID_IMU_RAW

IMU data averaged from DID_IMU3_RAW. Use this IMU data for output data rates faster than DID_FLASH_CONFIG.startupNavDtMs. Otherwise we recommend use of DID_IMU or DID_PIMU as they are oversampled and contain less noise.

`imu_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
status	uint32_t	IMU Status (eImuStatus)
I	imus_t	Inertial Measurement Unit (IMU)

DID_PIMU

Preintegrated IMU (a.k.a. Coning and Sculling integral) in body/IMU frame. Updated at IMU rate. Also known as delta theta delta velocity, or preintegrated IMU (PIMU). For clarification, the name "Preintegrated IMU" or "PIMU" throughout our User Manual. This data is integrated from the IMU data at the IMU update rate (`startupImuDtMs`, default 1ms). The PIMU integration period (`dt`) and INS NAV update data period are the same. `DID_FLASH_CONFIG.startupNavDtMs` sets the NAV output period at startup. The minimum NAV update and output periods are found here: https://docs.inertialsense.com/user-manual/application-config/imu_ins_gnss_configuration/#navigation-update-and-output-periods. If a faster output data rate for IMU is desired, `DID_IMU_RAW` can be used instead. PIMU data acts as a form of compression, adding the benefit of higher integration rates for slower output data rates, preserving the IMU data without adding filter delay and addresses antialiasing. It is most effective for systems that have higher dynamics and lower communications data rates. The minimum data period is `DID_FLASH_CONFIG.startupImuDtMs` or 4, whichever is larger (250Hz max). The PIMU value can be converted to IMU by dividing PIMU by `dt` (i.e. $IMU = PIMU / dt$)

`pimu_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
dt	float	Integral period in seconds for delta theta and delta velocity. This is configured using <code>DID_FLASH_CONFIG.startupNavDtMs</code> .
status	uint32_t	IMU Status (eImuStatus)
theta	float[3]	IMU delta theta (gyroscope {p,q,r} integral) in radians in sensor frame
vel	float[3]	IMU delta velocity (accelerometer {x,y,z} integral) in m/s in sensor frame

Sensor Output

DID_BAROMETER

Barometric pressure sensor data

`barometer_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
bar	float	Barometric pressure in kilopascals
mslBar	float	MSL altitude from barometric pressure sensor in meters
barTemp	float	Temperature of barometric pressure sensor in Celsius
humidity	float	Relative humidity as a percent (%rH). Range is 0% - 100%

DID_MAGNETOMETER

Magnetometer sensor output

magnetometer_t

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding gps.towOffset
mag	float[3]	Magnetometers

DID_MAG_CAL

Magnetometer calibration

mag_cal_t

Field	Type	Description
state	uint32_t	Mag recalibration state. COMMANDS: 1=multi-axis, 2=single-axis, 101=abort, STATUS: 200=running, 201=done (see eMagCalState)
progress	float	Mag recalibration progress indicator: 0-100 %
declination	float	Magnetic declination estimate

DID_SYS_SENSORS

System sensor information

sys_sensors_t

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding gps.towOffset
temp	float	Temperature in Celsius
pqr	float[3]	Gyros in radians / second
acc	float[3]	Accelerometers in meters / second squared
mag	float[3]	Magnetometers
bar	float	Barometric pressure in kilopascals
barTemp	float	Temperature of barometric pressure sensor in Celsius
msslBar	float	MSL altitude from barometric pressure sensor in meters
humidity	float	Relative humidity as a percent (%rH). Range is 0% - 100%
vin	float	EVB system input voltage in volts. uINS pin 5 (G2/AN2). Use 10K/1K resistor divider between Vin and GND.
ana1	float	ADC analog input in volts. uINS pin 4, (G1/AN1).
ana3	float	ADC analog input in volts. uINS pin 19 (G3/AN3).
ana4	float	ADC analog input in volts. uINS pin 20 (G4/AN4).

GPS / GNSS

DID_GPS1_POS

GPS 1 position data. This comes from DID_GPS1_RCVR_POS or DID_GPS1_RTK_POS, depending on whichever is more accurate.

gps_pos_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag
ecef	double[3]	Position in ECEF {x,y,z} (m)
lla	double[3]	Position - WGS84 latitude, longitude, height above ellipsoid (not MSL) (degrees, m)
hMSL	float	Height above mean sea level (MSL) in meters
hAcc	float	Horizontal accuracy in meters
vAcc	float	Vertical accuracy in meters
pDop	float	Position dilution of precision (unitless)
cnoMean	float	Average of all non-zero satellite carrier to noise ratios (signal strengths) in dBHz
towOffset	double	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.
leapS	uint8_t	GPS leap second (GPS-UTC) offset. Receiver's best knowledge of the leap seconds offset from UTC to GPS time. Subtract from GPS time of week to get UTC time of week. (18 seconds as of December 31, 2016)
satsUsed	uint8_t	Number of satellites used
cnoMeanSigma	uint8_t	Standard deviation of cnoMean over past 5 seconds (dBHz x10)
reserved	uint8_t	Reserved for future use

DID_GPS1_RCVR_POS

GPS 1 position data from GNSS receiver.

gps_pos_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag
ecef	double[3]	Position in ECEF {x,y,z} (m)
lla	double[3]	Position - WGS84 latitude, longitude, height above ellipsoid (not MSL) (degrees, m)
hMSL	float	Height above mean sea level (MSL) in meters
hAcc	float	Horizontal accuracy in meters
vAcc	float	Vertical accuracy in meters
pDop	float	Position dilution of precision (unitless)
cnoMean	float	Average of all non-zero satellite carrier to noise ratios (signal strengths) in dBHz
towOffset	double	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.
leapS	uint8_t	GPS leap second (GPS-UTC) offset. Receiver's best knowledge of the leap seconds offset from UTC to GPS time. Subtract from GPS time of week to get UTC time of week. (18 seconds as of December 31, 2016)
satsUsed	uint8_t	Number of satellites used
cnoMeanSigma	uint8_t	Standard deviation of cnoMean over past 5 seconds (dBHz x10)
reserved	uint8_t	Reserved for future use

DID_GPS1_RTK_POS

GPS RTK position data

gps_pos_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag
ecef	double[3]	Position in ECEF {x,y,z} (m)
lla	double[3]	Position - WGS84 latitude, longitude, height above ellipsoid (not MSL) (degrees, m)
hMSL	float	Height above mean sea level (MSL) in meters
hAcc	float	Horizontal accuracy in meters
vAcc	float	Vertical accuracy in meters
pDop	float	Position dilution of precision (unitless)
cnoMean	float	Average of all non-zero satellite carrier to noise ratios (signal strengths) in dBHz
towOffset	double	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.
leapS	uint8_t	GPS leap second (GPS-UTC) offset. Receiver's best knowledge of the leap seconds offset from UTC to GPS time. Subtract from GPS time of week to get UTC time of week. (18 seconds as of December 31, 2016)
satsUsed	uint8_t	Number of satellites used
cnoMeanSigma	uint8_t	Standard deviation of cnoMean over past 5 seconds (dBHz x10)
reserved	uint8_t	Reserved for future use

DID_GPS1_RTK_POS_MISC

RTK precision position related data.

gps_rtk_misc_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
accuracyPos	float[3]	Accuracy - estimated standard deviations of the solution assuming a priori error model and error parameters by the positioning options. []: standard deviations {ECEF - x,y,z} or {north, east, down} (meters)
accuracyCov	float[3]	Accuracy - estimated standard deviations of the solution assuming a priori error model and error parameters by the positioning options. []: Absolute value of means square root of estimated covariance NE, EU, UN
arThreshold	float	Ambiguity resolution threshold for validation
gDop	float	Geometric dilution of precision (meters)
hDop	float	Horizontal dilution of precision (meters)
vDop	float	Vertical dilution of precision (meters)
baseLla	double[3]	Base Position - latitude, longitude, height (degrees, meters)
cycleSlipCount	uint32_t	Cycle slip counter
roverGpsObservationCount	uint32_t	Rover gps observation element counter
baseGpsObservationCount	uint32_t	Base station gps observation element counter
roverGlonassObservationCount	uint32_t	Rover glonass observation element counter
baseGlonassObservationCount	uint32_t	Base station glonass observation element counter
roverGalileoObservationCount	uint32_t	Rover galileo observation element counter
baseGalileoObservationCount	uint32_t	Base station galileo observation element counter
roverBeidouObservationCount	uint32_t	Rover beidou observation element counter
baseBeidouObservationCount	uint32_t	Base station beidou observation element counter
roverQzsObservationCount	uint32_t	Rover qzs observation element counter
baseQzsObservationCount	uint32_t	Base station qzs observation element counter
roverGpsEphemerisCount	uint32_t	Rover gps ephemeris element counter
baseGpsEphemerisCount	uint32_t	Base station gps ephemeris element counter
roverGlonassEphemerisCount	uint32_t	Rover glonass ephemeris element counter
baseGlonassEphemerisCount	uint32_t	Base station glonass ephemeris element counter
roverGalileoEphemerisCount	uint32_t	Rover galileo ephemeris element counter
baseGalileoEphemerisCount	uint32_t	Base station galileo ephemeris element counter
roverBeidouEphemerisCount	uint32_t	Rover beidou ephemeris element counter
baseBeidouEphemerisCount	uint32_t	Base station beidou ephemeris element counter
roverQzsEphemerisCount	uint32_t	Rover qzs ephemeris element counter
baseQzsEphemerisCount	uint32_t	Base station qzs ephemeris element counter
roverSbasCount	uint32_t	Rover sbas element counter
baseSbasCount	uint32_t	Base station sbas element counter
baseAntennaCount	uint32_t	Base station antenna position element counter

Field	Type	Description
ionUtcAlmCount	uint32_t	Ionosphere model, utc and almanac count
correctionChecksumFailures	uint32_t	Number of checksum failures from received corrections
timeToFirstFixMs	uint32_t	Time to first RTK fix.

DID_GPS1_RTK_POS_REL

RTK precision position base to rover relative info.

gps_rtk_rel_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
differentialAge	float	Age of differential (seconds)
arRatio	float	Ambiguity resolution ratio factor for validation
baseToRoverVector	float[3]	Vector from base to rover (m) in ECEF - If Compassing enabled, this is the 3-vector from antenna 2 to antenna 1
baseToRoverDistance	float	Distance from base to rover (m)
baseToRoverHeading	float	Angle from north to baseToRoverVector in local tangent plane. (rad)
baseToRoverHeadingAcc	float	Accuracy of baseToRoverHeading. (rad)
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag

DID_GPS1_SAT

GPS 1 GNSS satellite information: sat identifiers, carrier to noise ratio, elevation and azimuth angles, pseudo range residual.

gps_sat_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
numSats	uint32_t	Number of satellites in the sky
sat	gps_sat_sv_t[50]	Satellite information list

DID_GPS1_VEL

GPS 1 velocity data

gps_vel_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
vel	float[3]	GPS Velocity. Velocity is in ECEF {vx,vy,vz} (m/s) if status bit GPS_STATUS_FLAGS_GPS_NMEA_DATA (0x00008000) is NOT set. Velocity is in local tangent plane with no vertical velocity {vNorth, vEast, 0} (m/s) if status bit GPS_STATUS_FLAGS_GPS_NMEA_DATA (0x00008000) is set.
sAcc	float	Speed accuracy in meters / second
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag

DID_GPS1_VERSION

GPS 1 version info

gps_version_t

Field	Type	Description
swVersion	uint8_t[30]	Software version
hwVersion	uint8_t[10]	Hardware version
extension	gps_extension_ver_t[6]	Extension 30 bytes array description

DID_GPS2_POS

GPS 2 position data

gps_pos_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag
ecef	double[3]	Position in ECEF {x,y,z} (m)
lla	double[3]	Position - WGS84 latitude, longitude, height above ellipsoid (not MSL) (degrees, m)
hMSL	float	Height above mean sea level (MSL) in meters
hAcc	float	Horizontal accuracy in meters
vAcc	float	Vertical accuracy in meters
pDop	float	Position dilution of precision (unitless)
cnoMean	float	Average of all non-zero satellite carrier to noise ratios (signal strengths) in dBHz
towOffset	double	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.
leapS	uint8_t	GPS leap second (GPS-UTC) offset. Receiver's best knowledge of the leap seconds offset from UTC to GPS time. Subtract from GPS time of week to get UTC time of week. (18 seconds as of December 31, 2016)
satsUsed	uint8_t	Number of satellites used
cnoMeanSigma	uint8_t	Standard deviation of cnoMean over past 5 seconds (dBHz x10)
reserved	uint8_t	Reserved for future use

DID_GPS2_RTK_CMP_MISC

RTK Dual GNSS RTK compassing related data.

gps_rtk_misc_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
accuracyPos	float[3]	Accuracy - estimated standard deviations of the solution assuming a priori error model and error parameters by the positioning options. []: standard deviations {ECEF - x,y,z} or {north, east, down} (meters)
accuracyCov	float[3]	Accuracy - estimated standard deviations of the solution assuming a priori error model and error parameters by the positioning options. []: Absolute value of means square root of estimated covariance NE, EU, UN
arThreshold	float	Ambiguity resolution threshold for validation
gDop	float	Geometric dilution of precision (meters)
hDop	float	Horizontal dilution of precision (meters)
vDop	float	Vertical dilution of precision (meters)
baseLla	double[3]	Base Position - latitude, longitude, height (degrees, meters)
cycleSlipCount	uint32_t	Cycle slip counter
roverGpsObservationCount	uint32_t	Rover gps observation element counter
baseGpsObservationCount	uint32_t	Base station gps observation element counter
roverGlonassObservationCount	uint32_t	Rover glonass observation element counter
baseGlonassObservationCount	uint32_t	Base station glonass observation element counter
roverGalileoObservationCount	uint32_t	Rover galileo observation element counter
baseGalileoObservationCount	uint32_t	Base station galileo observation element counter
roverBeidouObservationCount	uint32_t	Rover beidou observation element counter
baseBeidouObservationCount	uint32_t	Base station beidou observation element counter
roverQzsObservationCount	uint32_t	Rover qzs observation element counter
baseQzsObservationCount	uint32_t	Base station qzs observation element counter
roverGpsEphemerisCount	uint32_t	Rover gps ephemeris element counter
baseGpsEphemerisCount	uint32_t	Base station gps ephemeris element counter
roverGlonassEphemerisCount	uint32_t	Rover glonass ephemeris element counter
baseGlonassEphemerisCount	uint32_t	Base station glonass ephemeris element counter
roverGalileoEphemerisCount	uint32_t	Rover galileo ephemeris element counter
baseGalileoEphemerisCount	uint32_t	Base station galileo ephemeris element counter
roverBeidouEphemerisCount	uint32_t	Rover beidou ephemeris element counter
baseBeidouEphemerisCount	uint32_t	Base station beidou ephemeris element counter
roverQzsEphemerisCount	uint32_t	Rover qzs ephemeris element counter
baseQzsEphemerisCount	uint32_t	Base station qzs ephemeris element counter
roverSbasCount	uint32_t	Rover sbas element counter
baseSbasCount	uint32_t	Base station sbas element counter
baseAntennaCount	uint32_t	Base station antenna position element counter

Field	Type	Description
ionUtcAlmCount	uint32_t	Ionosphere model, utc and almanac count
correctionChecksumFailures	uint32_t	Number of checksum failures from received corrections
timeToFirstFixMs	uint32_t	Time to first RTK fix.

DID_GPS2_RTK_CMP_REL

Dual GNSS RTK compassing / moving base to rover (GPS 1 to GPS 2) relative info.

gps_rtk_rel_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
differentialAge	float	Age of differential (seconds)
arRatio	float	Ambiguity resolution ratio factor for validation
baseToRoverVector	float[3]	Vector from base to rover (m) in ECEF - If Compassing enabled, this is the 3-vector from antenna 2 to antenna 1
baseToRoverDistance	float	Distance from base to rover (m)
baseToRoverHeading	float	Angle from north to baseToRoverVector in local tangent plane. (rad)
baseToRoverHeadingAcc	float	Accuracy of baseToRoverHeading. (rad)
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag

DID_GPS2_SAT

GPS 2 GNSS satellite information: sat identifiers, carrier to noise ratio, elevation and azimuth angles, pseudo range residual.

gps_sat_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
numSats	uint32_t	Number of satellites in the sky
sat	gps_sat_sv_t[50]	Satellite information list

DID_GPS2_VEL

GPS 2 velocity data

gps_vel_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
vel	float[3]	GPS Velocity. Velocity is in ECEF {vx,vy,vz} (m/s) if status bit GPS_STATUS_FLAGS_GPS_NMEA_DATA (0x00008000) is NOT set. Velocity is in local tangent plane with no vertical velocity {vNorth, vEast, 0} (m/s) if status bit GPS_STATUS_FLAGS_GPS_NMEA_DATA (0x00008000) is set.
sAcc	float	Speed accuracy in meters / second
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags, NMEA input flag

DID_GPS2_VERSION

GPS 2 version info

gps_version_t

Field	Type	Description
swVersion	uint8_t[30]	Software version
hwVersion	uint8_t[10]	Hardware version
extension	gps_extension_ver_t[6]	Extension 30 bytes array description

DID_GPS_RTK_OPT

RTK options - requires little endian CPU.

gps_rtk_opt_t

Field	Type	Description
mode	int32_t	positioning mode (PMODE_???)
soltype	int32_t	solution type (0:forward,1:backward,2:combined)
nf	int32_t	number of frequencies (1:L1,2:L1+L2,3:L1+L2+L5)
navsys	int32_t	navigation systems
elmin	double	elevation mask angle (rad)
snrmin	int32_t	Min snr to consider satellite for rtk
snrrange	int32_t	AR mode (0:off,1:continuous,2:instantaneous,3:fix and hold,4:ppp-ar)
modear	int32_t	GLONASS AR mode (0:off,1:on,2:auto cal,3:ext cal)
glomodear	int32_t	GPS AR mode (0:off,1:on)
gpsmodear	int32_t	SBAS AR mode (0:off,1:on)
sbsmodear	int32_t	BeiDou AR mode (0:off,1:on)
bdsmodear	int32_t	AR filtering to reject bad sats (0:off,1:on)
arfilter	int32_t	obs outage count to reset bias
maxout	int32_t	reject count to reset bias
maxrej	int32_t	min lock count to fix ambiguity
minlock	int32_t	min sats to fix integer ambiguities
minfixsats	int32_t	min sats to hold integer ambiguities
minholdsats	int32_t	min sats to drop sats in AR
mindropsats	int32_t	use stdev estimates from receiver to adjust measurement variances
rcvstds	int32_t	min fix count to hold ambiguity
minfix	int32_t	max iteration to resolve ambiguity
armaxiter	int32_t	dynamics model (0:none,1:velociy,2:accel)
dynamics	int32_t	number of filter iteration
niter	int32_t	interpolate reference obs (for post mission)
intpref	int32_t	rover position for fixed mode
rovpos	int32_t	base position for relative mode
refpos	int32_t	code/phase error ratio
eratio	double[]	measurement error factor
err	double[5]	initial-state std [0]bias,[1]iono [2]trop
std	double[3]	process-noise std [0]bias,[1]iono [2]trop [3]acch [4]accv [5] pos
prn	double[6]	satellite clock stability (sec/sec)
selkstab	double	AR validation threshold
thresar	double[8]	elevation mask of AR for rising satellite (rad)
elmaskar	double	elevation mask to hold ambiguity (rad)
elmaskhold	double	slip threshold of geometry-free phase (m)

Field	Type	Description
thresslip	double	variance for fix-and-hold pseudo measurements (cycle ²)
thresdop	double	gain used for GLO and SBAS sats to adjust ambiguity
varholdamb	double	max difference of time (sec)
gainholdamb	double	reset sat biases after this long trying to get fix if not acquired
maxtdiff	double	reject thresholds of NIS
fix_reset_base_msgs	int	reject threshold of gdop
maxinno	double[2]	baseline length constraint {const,sigma before fix, sigma after fix} (m)
maxnis_lo	double	maximum error wrt ubx position (triggers reset if more than this far) (m)
maxnis_hi	double	rover position for fixed mode {x,y,z} (ecef) (m)
maxgdop	double	base position for relative mode {x,y,z} (ecef) (m)
baseline	double[3]	max averaging epochs
max_baseline_error	double	output single by dgps/float/fix/ppp outage
reset_baseline_error	double	velocity constraint in compassing mode {var before fix, var after fix} (m ² /s ²)

GPX

DID_GPX_DEV_INFO

GPX device information

dev_info_t

Field	Type	Description
reserved	uint16_t	Reserved bits
hardwareType	uint8_t	Hardware Type: 1=uINS, 2=EVB, 3=IMX, 4=GPX (see eIsHardwareType)
reserved2	uint8_t	Unused
serialNumber	uint32_t	Serial number
hardwareVer	uint8_t[4]	Hardware version
firmwareVer	uint8_t[4]	Firmware (software) version
buildNumber	uint32_t	Build number
protocolVer	uint8_t[4]	Communications protocol version
repoRevision	uint32_t	Repository revision number
manufacturer	char[24]	Manufacturer name
buildType	uint8_t	Build type (Release: 'a'=ALPHA, 'b'=BETA, 'c'=RELEASE CANDIDATE, 'r'=PRODUCTION RELEASE, 'd'=developer/debug)
buildYear	uint8_t	Build date year - 2000
buildMonth	uint8_t	Build date month
buildDay	uint8_t	Build date day
buildHour	uint8_t	Build time hour
buildMinute	uint8_t	Build time minute
buildSecond	uint8_t	Build time second
buildMillisecond	uint8_t	Build time millisecond
addInfo	char[24]	Additional info
firmwareMD5Hash	uint32_t[4]	Firmware MD5 hash

DID_GPX_FLASH_CFG

GPX flash configuration

gpx_flash_cfg_t

Field	Type	Description
size	uint32_t	Size of this struct
checksum	uint32_t	Checksum, excluding size and checksum
key	uint32_t	Manufacturer method for restoring flash defaults
ser0BaudRate	uint32_t	Serial port 0 baud rate in bits per second
ser1BaudRate	uint32_t	Serial port 1 baud rate in bits per second
ser2BaudRate	uint32_t	Serial port 2 baud rate in bits per second
startupGPSDtMs	uint32_t	GPS measurement (system input data) update period in milliseconds set on startup. 200ms minimum (5Hz max).
gps1AntOffset	float[3]	X,Y,Z offset in meters in Sensor Frame to GPS 1 antenna.
gps2AntOffset	float[3]	X,Y,Z offset in meters in Sensor Frame to GPS 2 antenna.
gnssSatSigConst	uint16_t	Satellite system constellation used in GNSS solution. (see eGnssSatSigConst) 0x0003=GPS, 0x000C=QZSS, 0x0030=Galileo, 0x00C0=Beidou, 0x0300=GLONASS, 0x1000=SBAS
dynamicModel	uint8_t	Dynamic platform model (see eDynamicModel). Options are: 0=PORTABLE, 2=STATIONARY, 3=PEDESTRIAN, 4=GROUND VEHICLE, 5=SEA, 6=AIRBORNE_1G, 7=AIRBORNE_2G, 8=AIRBORNE_4G, 9=WRIST. Used to balance noise and performance characteristics of the system. The dynamics selected here must be at least as fast as your system or you experience accuracy error. This is tied to the GPS position estimation model and intend in the future to be incorporated into the INS position model.
debug	uint8_t	Debug
gpsTimeSyncPeriodMs	uint32_t	Time between GPS time synchronization pulses in milliseconds. Requires reboot to take effect.
gpsTimeUserDelay	float	(sec) User defined delay for GPS time. This parameter can be used to account for GPS antenna cable delay.
gpsMinimumElevation	float	Minimum elevation of a satellite above the horizon to be used in the solution (radians). Low elevation satellites may provide degraded accuracy, due to the long signal path through the atmosphere.
RTKCfgBits	uint32_t	RTK configuration bits (see eRTKConfigBits).
gnssCn0Minimum	uint8_t	(dBHz) GNSS CN0 absolute minimum threshold for signals. Used to filter signals in RTK solution.
gnssCn0DynMinOffset	uint8_t	(dBHz) GNSS CN0 dynamic minimum threshold offset below max CN0 across all satellites. Used to filter signals used in RTK solution. To disable, set gnssCn0DynMinOffset to zero and increase gnssCn0Minimum.
reserved1	uint8_t[2]	Reserved
sysCfgBits	uint32_t	System configuration bits (see eGpxSysConfigBits).
reserved2	uint32_t	Reserved

DID_GPX_RMC

GPX rmc

rnc_t

Field	Type	Description
bits	uint64_t	Data stream enable bits for the specified ports. (see RMC_BITS_...)
options	uint32_t	Options to select alternate ports to output data, etc. (see RMC_OPTIONS_...)

DID_GPX_STATUS

GPX status

gpx_status_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	Status (eGpxStatus)
grmcBitsSer0	uint64_t	GRMC BITS (see GRMC_BITS_...)
grmcBitsSer1	uint64_t	(see NMEA_MSG_ID...)
grmcBitsSer2	uint64_t	Hardware status flags (eGPXHdwStatusFlags)
grmcBitsUSB	uint64_t	MCU temperature (GPX_INVALID_MCU_TEMP if not available)
grmcNMEABitsSer0	uint64_t	Nav output period (ms).
grmcNMEABitsSer1	uint64_t	Flash config checksum used with host SDK synchronization
grmcNMEABitsSer2	uint64_t	RTK Mode bits (see eRTKConfigBits)
grmcNMEABitsUSB	uint64_t	port

Raw GPS Data

Raw GPS data is contained in the `DID_GPS1_RAW`, `DID_GPS2_RAW`, and `DID_GPS_BASE_RAW` messages of type `gps_raw_t`. The actual raw data is contained in the union member `gps_raw_t.data` and should be interpreted based on the value of `gps_raw_t.dataType` (i.e. as observation, ephemeris, SBAS, or base station position).

DID_GPS1_RAW

GPS raw data for rover (observation, ephemeris, etc.) - requires little endian CPU. The contents of data can vary for this message and are determined by `dataType` field. RTK positioning or RTK compassing must be enabled to stream this message.

gps_raw_t

Field	Type	Description
receiverIndex	uint8_t	Receiver index (1=RECEIVER_INDEX_GPS1, 2=RECEIVER_INDEX_EXTERNAL_BASE, or 3=RECEIVER_INDEX_GPS2)
dataType	uint8_t	Type of data (eRawDataType: 1=observations, 2=ephemeris, 3=glonassEphemeris, 4=SBAS, 5=baseAntenna, 6=IonosphereModel)
obsCount	uint8_t	Number of observations in data (obsd_t) when dataType==1 (raw_data_type_observation).
reserved	uint8_t	Reserved
data	uGpsRawData	Interpret based on dataType (see eRawDataType)

DID_GPS2_RAW

GPS raw data for rover (observation, ephemeris, etc.) - requires little endian CPU. The contents of data can vary for this message and are determined by `dataType` field. RTK positioning or RTK compassing must be enabled to stream this message.

gps_raw_t

Field	Type	Description
receiverIndex	uint8_t	Receiver index (1=RECEIVER_INDEX_GPS1, 2=RECEIVER_INDEX_EXTERNAL_BASE, or 3=RECEIVER_INDEX_GPS2)
dataType	uint8_t	Type of data (eRawDataType: 1=observations, 2=ephemeris, 3=glonassEphemeris, 4=SBAS, 5=baseAntenna, 6=IonosphereModel)
obsCount	uint8_t	Number of observations in data (obsd_t) when dataType==1 (raw_data_type_observation).
reserved	uint8_t	Reserved
data	uGpsRawData	Interpret based on dataType (see eRawDataType)

DID_GPS_BASE_RAW

GPS raw data for base station (observation, ephemeris, etc.) - requires little endian CPU. The contents of data can vary for this message and are determined by dataType field. RTK positioning or RTK compassing must be enabled to stream this message.

gps_raw_t

Field	Type	Description
receiverIndex	uint8_t	Receiver index (1=RECEIVER_INDEX_GPS1, 2=RECEIVER_INDEX_EXTERNAL_BASE, or 3=RECEIVER_INDEX_GPS2)
dataType	uint8_t	Type of data (eRawDataType: 1=observations, 2=ephemeris, 3=glonassEphemeris, 4=SBAS, 5=baseAntenna, 6=IonosphereModel)
obsCount	uint8_t	Number of observations in data (obsd_t) when dataType==1 (raw_data_type_observation).
reserved	uint8_t	Reserved
data	uGpsRawData	Interpret based on dataType (see eRawDataType)

RAW GPS DATA BUFFER UNION

uGpsRawData

Field	Type	Description
obs	obsd_t[]	Satellite observation data
eph	eph_t	Satellite non-GLONASS ephemeris data (GPS, Galileo, Beidou, QZSS)
gloEph	geph_t	Satellite GLONASS ephemeris data
sbas	sbsmsg_t	Satellite-Based Augmentation Systems (SBAS) data
sta	sta_t	Base station information (base position, antenna position, antenna height, etc.)
ion	ion_model_utc_alm_t	Ionosphere model and UTC parameters
buf	uint8_t[1000]	Byte buffer

GPS GALILEO QZSS EPHEMERIS

eph_t

Field	Type	Description
sat	int32_t	Satellite number in RTKlib notation. GPS: 1-32, GLONASS: 33-59, Galileo: 60-89, SBAS: 90-95
iode	int32_t	IODE Issue of Data, Ephemeris (ephemeris version)
iodc	int32_t	IODC Issue of Data, Clock (clock version)
sva	int32_t	SV accuracy (URA index) IRN-IS-200H p.97
svh	int32_t	SV health GPS/QZS (0:ok)
week	int32_t	GPS/QZS: gps week, GAL: galileo week
code	int32_t	GPS/QZS: code on L2. (00 = Invalid, 01 = P Code ON, 11 = C/A code ON, 11 = Invalid). GAL/CMP: data sources
flag	int32_t	GPS/QZS: L2 P data flag (indicates that the NAV data stream was commanded OFF on the P-code of the in-phase component of the L2 channel). CMP: nav type
toe	gtime_t	Time Of Ephemeris, ephemeris reference epoch in seconds within the week (s)
toc	gtime_t	clock data reference time (s) (20.3.4.5)
ttr	gtime_t	T_trans (s)
A	double	Orbit semi-major axis (m)
e	double	Orbit eccentricity (non-dimensional)
i0	double	Orbit inclination angle at reference time (rad)
OMG0	double	Longitude of ascending node of orbit plane at weekly epoch (rad)
omg	double	Argument of perigee (rad)
M0	double	Mean anomaly at reference time (rad)
deln	double	Mean Motion Difference From Computed Value (rad)
OMGd	double	Rate of Right Ascension (rad/s)
idot	double	Rate of Inclination Angle (rad/s)
crc	double	Amplitude of the Cosine Harmonic Correction Term to the Orbit Radius (m)
crs	double	Amplitude of the Sine Harmonic Correction Term to the Orbit Radius (m)
cuc	double	Amplitude of the Cosine Harmonic Correction Term to the Argument of Latitude (rad)
cus	double	Amplitude of the Sine Harmonic Correction Term to the Argument of Latitude (rad)
cic	double	Amplitude of the Cosine Harmonic Correction Term to the Angle of Inclination (rad)
cis	double	Amplitude of the Sine Harmonic Correction Term to the Angle of Inclination (rad)
toes	double	Time Of Ephemeris, ephemeris reference epoch in seconds within the week (s), same as above but represented as double type. Note that toe is computed as $eph \rightarrow toe = gst2time(week, eph \rightarrow toes)$. This is the expiration time and is generally ~2 hours ahead of current time.
fit	double	Fit interval (h) (0: 4 hours, 1: greater than 4 hours)
f0	double	SV clock offset, af0 (s)
f1	double	SV clock drift, af1 (s/s, non-dimensional)
f2	double	SV clock drift rate, af2 (1/s)
tgd	double[4]	Group delay parameters GPS/QZS: $tgd[0]$ = TGD (IRN-IS-200H p.103). Galileo: $tgd[0]$ = BGD E5a/E1, $tgd[1]$ = BGD E5b/E1. Beidou: $tgd[0]$ = BGD1, $tgd[1]$ = BGD2

Field	Type	Description
Adot	double	Adot for CNAV, not used
ndot	double	First derivative of mean motion n (second derivative of mean anomaly M), ndot for CNAV (rad/s/s). Not used.

GLONASS EPHEMERIS

geph_t

Field	Type	Description
sat	int32_t	Satellite number in RTKlib notation. GPS: 1-32, GLONASS: 33-59, Galileo: 60-89, SBAS: 90-95
iode	int32_t	IODE (0-6 bit of tb field)
frq	int32_t	satellite frequency number
svh	int32_t	satellite health
sva	int32_t	satellite accuracy
age	int32_t	satellite age of operation
toe	gtime_t	Ephemeris reference epoch in seconds within the week in GPS time gpst (s)
tof	gtime_t	message frame time in gpst (s)
pos	double[3]	satellite position (ecef) (m)
vel	double[3]	satellite velocity (ecef) (m/s)
acc	double[3]	satellite acceleration (ecef) (m/s ²)
taun	double	SV clock bias (s)
gamn	double	relative frequency bias
dtaun	double	delay between L1 and L2 (s)

SBAS

sbsmsg_t

Field	Type	Description
week	int32_t	reception time - week
tow	int32_t	reception time - tow
prn	int32_t	SBAS satellite PRN number
msg	uint8_t[29]	SBAS message (226bit) padded by 0
reserved	uint8_t[3]	reserved for alignment

STATION PARAMETERS

sta_t

Field	Type	Description
delttype	int32_t	antenna delta type (0:enu,1:xyz)
pos	double[3]	station position (ecef) (m)
del	double[3]	antenna position delta (e/n/u or x/y/z) (m)
hgt	double	antenna height (m)
stationId	int32_t	station id

SATELLITE OBSERVATION

obs_t

Field	Type	Description
n	uint32_t	number of observation slots used
nmax	uint32_t	number of observation slots allocated
data	obsd_t	observation data buffer

SATELLITE INFORMATION

gps_sat_sv_t

Field	Type	Description
gnssId	uint8_t	GNSS identifier (see eSatSvGnssId)
svId	uint8_t	Satellite identifier
elev	int8_t	(deg) Elevation (range: ± 90)
azim	int16_t	(deg) Azimuth (range: ± 180)
cno	uint8_t	(dBHz) Carrier to noise ratio (signal strength)
status	uint16_t	(see eSatSvStatus)

INERTIAL MEASUREMENT UNIT (IMU)

imus_t

Field	Type	Description
pqr	float[3]	Gyroscope P, Q, R in radians / second
acc	float[3]	Acceleration X, Y, Z in meters / second squared

Configuration

DID_FLASH_CONFIG

Flash memory configuration

nvm_flash_cfg_t

Field	Type	Description
size	uint32_t	Size of group or union, which is <code>nvm_group_x_t + padding</code>
checksum	uint32_t	Checksum, excluding size and checksum
key	uint32_t	Manufacturer method for restoring flash defaults
startupImuDtMs	uint32_t	IMU sample (system input) period in milliseconds set on startup. Cannot be larger than <code>startupNavDtMs</code> . Zero disables sensor/IMU sampling.
startupNavDtMs	uint32_t	Navigation filter (system output) output period in milliseconds set on startup. Used to initialize <code>sysParams.navOutputPeriodMs</code> .
ser0BaudRate	uint32_t	Serial port 0 baud rate in bits per second
ser1BaudRate	uint32_t	Serial port 1 baud rate in bits per second
insRotation	float[3]	Rotation in radians about the X,Y,Z axes from Sensor Frame to Intermediate Output Frame. Order applied: Z,Y,X.
insOffset	float[3]	X,Y,Z offset in meters from Intermediate Output Frame to INS Output Frame.
gps1AntOffset	float[3]	X,Y,Z offset in meters in Sensor Frame to GPS 1 antenna.
dynamicModel	uint8_t	INS dynamic platform model (see <code>eDynamicModel</code>). Options are: 0=PORTABLE, 2=STATIONARY, 3=PEDESTRIAN, 4=GROUND VEHICLE, 5=SEA, 6=AIRBORNE_1G, 7=AIRBORNE_2G, 8=AIRBORNE_4G, 9=WRIST. Used to balance noise and performance characteristics of the system. The dynamics selected here must be at least as fast as your system or you experience accuracy error. This is tied to the GPS position estimation model and intend in the future to be incorporated into the INS position model.
debug	uint8_t	Debug
gnssSatSigConst	uint16_t	Satellite system constellation used in GNSS solution. (see <code>eGnssSatSigConst</code>) 0x0003=GPS, 0x000C=QZSS, 0x0030=Galileo, 0x00C0=Beidou, 0x0300=GLONASS, 0x1000=SBAS
sysCfgBits	uint32_t	System configuration bits (see <code>eSysConfigBits</code>).
refLla	double[3]	Reference latitude, longitude and height above ellipsoid for north east down (NED) calculations (deg, deg, m)
lastLla	double[3]	Last latitude, longitude, HAE (height above ellipsoid) used to aid GPS startup (deg, deg, m). Updated when the distance between current LLA and lastLla exceeds <code>lastLlaUpdateDistance</code> .
lastLlaTimeOfWeekMs	uint32_t	Last LLA GPS time since week start (Sunday morning) in milliseconds
lastLlaWeek	uint32_t	Last LLA GPS number of weeks since January 6 th , 1980
lastLlaUpdateDistance	float	Distance between current and last LLA that triggers an update of lastLla
ioConfig	uint32_t	Hardware interface configuration bits (see <code>eIoConfig</code>).
platformConfig	uint32_t	Hardware platform specifying the IMX carrier board type (i.e. RUG, EVB, IG) and configuration bits (see <code>ePlatformConfig</code>). The platform type is used to simplify the GPS and I/O configuration process. Bit <code>PLATFORM_CFG_UPDATE_IO_CONFIG</code> is excluded

Field	Type	Description
		from the flashConfig checksum and from determining whether to upload.
gps2AntOffset	float[3]	X,Y,Z offset in meters in Sensor Frame origin to GPS 2 antenna.
zeroVelRotation	float[3]	Euler (roll, pitch, yaw) rotation in radians from INS Sensor Frame to Intermediate ZeroVelocity Frame. Order applied: heading, pitch, roll.
zeroVelOffset	float[3]	X,Y,Z offset in meters from Intermediate ZeroVelocity Frame to Zero Velocity Frame.
gpsTimeUserDelay	float	(sec) User defined delay for GPS time. This parameter can be used to account for GPS antenna cable delay.
magDeclination	float	Earth magnetic field (magnetic north) declination (heading offset from true north) in radians
gpsTimeSyncPeriodMs	uint32_t	Time between GPS time synchronization pulses in milliseconds. Requires reboot to take effect.
startupGPSDtMs	uint32_t	GPS measurement (system input) update period in milliseconds set on startup. 200ms minimum (5Hz max).
RTKCfgBits	uint32_t	RTK configuration bits (see eRTKConfigBits).
sensorConfig	uint32_t	Sensor config to specify the full-scale sensing ranges and output rotation for the IMU and magnetometer (see eSensorConfig)
gpsMinimumElevation	float	Minimum elevation of a satellite above the horizon to be used in the solution (radians). Low elevation satellites may provide degraded accuracy, due to the long signal path through the atmosphere.
ser2BaudRate	uint32_t	Serial port 2 baud rate in bits per second
wheelConfig	wheel_config_t	Wheel encoder: euler angles describing the rotation from imu to left wheel
magInterferenceThreshold	float	Magnetometer interference sensitivity threshold. Typical range is 2-10 (3 default) and 1000 to disable mag interference detection.
magCalibrationQualityThreshold	float	Magnetometer calibration quality sensitivity threshold. Typical range is 10-20 (10 default) and 1000 to disable mag calibration quality check, forcing it to be always good.
gnssCn0Minimum	uint8_t	(dBHz) GNSS CN0 absolute minimum threshold for signals. Used to filter signals in RTK solution.
gnssCn0DynMinOffset	uint8_t	(dBHz) GNSS CN0 dynamic minimum threshold offset below max CN0 across all satellites. Used to filter signals used in RTK solution. To disable, set gnssCn0DynMinOffset to zero and increase gnssCn0Minimum.
reserved1	uint8_t[2]	Reserved
reserved2	uint32_t[2]	Reserved

DID_NMEA_BCAST_PERIOD

Set broadcast periods for NMEA messages

nmea_msgs_t

Field	Type	Description
options	uint32_t	Options: Port selection[0x0=current, 0x1=ser0, 0x2=ser1, 0x4=ser2, 0x8=USB, 0x100=preserve, 0x200=Persistent] (see RMC_OPTIONS_...)
nmeaBroadcastMsgs	nmeaBroadcastMsgPair_t[20]	NMEA message to be set. Up to 20 message ID/period pairs. Message ID of zero indicates the remaining pairs are not used. (see eNmeaMsgId)

DID_RMC

Realtime Message Controller (RMC). The data sets available through RMC are driven by the availability of the data. The RMC provides updates from various data sources (i.e. sensors) as soon as possible with minimal latency. Several of the data sources (sensors) output data at different data rates that do not all correspond. The RMC is provided so that broadcast of sensor data is done as soon as it becomes available. All RMC messages can be enabled using the standard Get Data packet format.

rmc_t

Field	Type	Description
bits	uint64_t	Data stream enable bits for the specified ports. (see RMC_BITS_...)
options	uint32_t	Options to select alternate ports to output data, etc. (see RMC_OPTIONS_...)

Command

DID_SYS_CMD

System commands. Both the command and invCommand fields must be set at the same time for a command to take effect.

system_command_t

Field	Type	Description
command	uint32_t	System commands (see eSystemCommand) 1=save current persistent messages, 5=zero motion, 97=save flash, 99=software reset. "invCommand" (following variable) must be set to bitwise inverse of this value for this command to be processed.
invCommand	uint32_t	Error checking field that must be set to bitwise inverse of command field for the command to take effect.

EVB-2

DID_EVB_FLASH_CFG

EVB configuration.

evb_flash_cfg_t

Field	Type	Description
size	uint32_t	Size of this struct
checksum	uint32_t	Checksum, excluding size and checksum
key	uint32_t	Manufacturer method for restoring flash defaults
cbPreset	uint8_t	Communications bridge preset. (see eEvb2ComBridgePreset)
reserved1	uint8_t[3]	Communications bridge forwarding
cbf	uint32_t[EVB2_PORT_COUNT]	Communications bridge options (see eEvb2ComBridgeOptions)
cbOptions	uint32_t	Config bits (see eEvbFlashCfgBits)
bits	uint32_t	Radio preamble ID (PID) - 0x0 to 0x9. Only radios with matching PIDs can communicate together. Different PIDs minimize interference between multiple sets of networks. Checked before the network ID.
radioPID	uint32_t	Radio network ID (NID) - 0x0 to 0x7FFF. Only radios with matching NID can communicate together. Checked after the preamble ID.
radioNID	uint32_t	Radio power level - Transmitter output power level. (XBee PRO SX 0=20dBm, 1=27dBm, 2=30dBm)
radioPowerLevel	uint32_t	WiFi SSID and PSK
wifi	evb_wifi_t[3]	Server IP and port
server	evb_server_t[3]	Encoder tick to wheel rotation conversion factor (in radians). Encoder tick count per revolution on 1 channel x gear ratio x 2pi.
encoderTickToWheelRad	float	CAN baudrate
CANbaud_kbps	uint32_t	CAN receive address
can_receive_address	uint32_t	EVB port for uINS communications and SD card logging. 0=uINS-Ser0 (default), 1=uINS-Ser1, SP330=5, 6=GPIO_H8 (use eEvb2CommPorts)
uinsComPort	uint8_t	EVB port for uINS aux com and RTK corrections. 0=uINS-Ser0, 1=uINS-Ser1 (default), 5=SP330, 6=GPIO_H8 (use eEvb2CommPorts)
uinsAuxPort	uint8_t	Enable radio RTK filtering, etc. (see eEvb2PortOptions)
reserved2	uint8_t[2]	Baud rate for EVB serial port H3 (SP330 RS233 and RS485/422).
portOptions	uint32_t	Baud rate for EVB serial port H4 (TLL to external radio).
h3sp330BaudRate	uint32_t	Baud rate for EVB serial port H8 (TLL).
h4xRadioBaudRate	uint32_t	Wheel encoder configuration (see eWheelCfgBits)
h8gpioBaudRate	uint32_t	Wheel update period. Sets the wheel encoder and control update period. (ms)

DID_EVB_STATUS

EVB monitor and log control interface.

evb_status_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
firmwareVer	uint8_t[4]	Firmware (software) version
evbStatus	uint32_t	Status (eEvbStatus)
loggerMode	uint32_t	Data logger control state. (see eEvb2LoggerMode)
loggerElapsedTimeMs	uint32_t	logger
wifiIpAddr	uint32_t	WiFi IP address
sysCommand	uint32_t	System command (see eSystemCommand). 99 = software reset
towOffset	double	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.

General

DID_BIT

System built-in self-test

bit_t

Field	Type	Description
command	uint8_t	BIT input command (see eBitCommand). Ignored when zero.
lastCommand	uint8_t	BIT last input command (see eBitCommand)
state	uint8_t	BIT current state (see eBitState)
reserved	uint8_t	Unused
hdwBitStatus	uint32_t	Hardware BIT status (see eHdwBitStatusFlags)
calBitStatus	uint32_t	Calibration BIT status (see eCalBitStatusFlags)
tcPqrBias	float	Temperature calibration bias
tcAccBias	float	Temperature calibration slope
tcPqrSlope	float	Temperature calibration linearity
tcAccSlope	float	Gyro error (rad/s)
tcPqrLinearity	float	Accelerometer error (m/s ²)
tcAccLinearity	float	Angular rate standard deviation
pqr	float	Acceleration standard deviation
acc	float	Self-test mode (see eBitTestMode)
pqrSigma	float	Self-test mode bi-directional variable used with testMode
accSigma	float	The hardware type detected (see "Product Hardware ID"). This is used to ensure correct firmware is used.

DID_CAN_CONFIG

Addresses for CAN messages

can_config_t

Field	Type	Description
can_period_mult	uint16_t[]	Broadcast period multiple - CAN time message. 0 to disable.
can_transmit_address	uint32_t[]	Transmit address.
can_baudrate_kbps	uint16_t	Baud rate (kbps) (See can_baudrate_t for valid baud rates)
can_receive_address	uint32_t	Receive address.

DID_DEV_INFO

Device information

dev_info_t

Field	Type	Description
reserved	uint16_t	Reserved bits
hardwareType	uint8_t	Hardware Type: 1=uINS, 2=EVB, 3=IMX, 4=GPX (see eIsHardwareType)
reserved2	uint8_t	Unused
serialNumber	uint32_t	Serial number
hardwareVer	uint8_t[4]	Hardware version
firmwareVer	uint8_t[4]	Firmware (software) version
buildNumber	uint32_t	Build number
protocolVer	uint8_t[4]	Communications protocol version
repoRevision	uint32_t	Repository revision number
manufacturer	char[24]	Manufacturer name
buildType	uint8_t	Build type (Release: 'a'=ALPHA, 'b'=BETA, 'c'=RELEASE CANDIDATE, 'r'=PRODUCTION RELEASE, 'd'=developer/debug)
buildYear	uint8_t	Build date year - 2000
buildMonth	uint8_t	Build date month
buildDay	uint8_t	Build date day
buildHour	uint8_t	Build time hour
buildMinute	uint8_t	Build time minute
buildSecond	uint8_t	Build time second
buildMillisecond	uint8_t	Build time millisecond
addInfo	char[24]	Additional info
firmwareMD5Hash	uint32_t[4]	Firmware MD5 hash

DID_DIAGNOSTIC_MESSAGE

Diagnostic message

diag_msg_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
messageLength	uint32_t	Message length, including null terminator
message	char[256]	Message data, max size of message is 256

DID_EVB_DEBUG_ARRAY

debug_array_t

Field	Type	Description
-------	------	-------------

DID_EVB_DEV_INFO

EVB device information

dev_info_t

Field	Type	Description
reserved	uint16_t	Reserved bits
hardwareType	uint8_t	Hardware Type: 1=uINS, 2=EVB, 3=IMX, 4=GPX (see eIsHardwareType)
reserved2	uint8_t	Unused
serialNumber	uint32_t	Serial number
hardwareVer	uint8_t[4]	Hardware version
firmwareVer	uint8_t[4]	Firmware (software) version
buildNumber	uint32_t	Build number
protocolVer	uint8_t[4]	Communications protocol version
repoRevision	uint32_t	Repository revision number
manufacturer	char[24]	Manufacturer name
buildType	uint8_t	Build type (Release: 'a'=ALPHA, 'b'=BETA, 'c'=RELEASE CANDIDATE, 'r'=PRODUCTION RELEASE, 'd'=developer/debug)
buildYear	uint8_t	Build date year - 2000
buildMonth	uint8_t	Build date month
buildDay	uint8_t	Build date day
buildHour	uint8_t	Build time hour
buildMinute	uint8_t	Build time minute
buildSecond	uint8_t	Build time second
buildMillisecond	uint8_t	Build time millisecond
addInfo	char[24]	Additional info
firmwareMD5Hash	uint32_t[4]	Firmware MD5 hash

DID_EVB_RTOS_INFO

EVB-2 RTOS information.

evb_rtos_info_t

Field	Type	Description
freeHeapSize	uint32_t	Heap high water mark bytes
mallocSize	uint32_t	Total memory allocated using RTOS pvPortMalloc()
freeSize	uint32_t	Total memory freed using RTOS vPortFree()
task	rtos_task_t[]	Tasks

DID_EVENT

did_event_t

Field	Type	Description
time	double	Time (uptime in seconds)
senderSN	uint32_t	Serial number
senderHdwId	uint16_t	Hardware: 0=Host, 1=uINS, 2=EVb, 3=IMX, 4=GPX (see "Product Hardware ID")
priority	int8_t	see eEventPriority
res8	uint8_t	see eEventMsgTypeID

DID_EVENT_HEADER_SIZE

did_event_t

Field	Type	Description
time	double	Time (uptime in seconds)
senderSN	uint32_t	Serial number
senderHdwId	uint16_t	Hardware: 0=Host, 1=uINS, 2=EVb, 3=IMX, 4=GPX (see "Product Hardware ID")
priority	int8_t	see eEventPriority
res8	uint8_t	see eEventMsgTypeID

DID_GPS1_SIG

GPS 1 GNSS signal information.

gps_sig_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
numSigs	uint32_t	Number of satellite signals in the following satellite signal list
sig	gps_sig_sv_t[100]	Satellite signal list

DID_GPS1_TIMEPULSE

GPS1 PPS time synchronization.

gps_timepulse_t

Field	Type	Description
-------	------	-------------

DID_GPS2_SIG

GPS 2 GNSS signal information.

gps_sig_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
numSigs	uint32_t	Number of satellite signals in the following satellite signal list
sig	gps_sig_sv_t[100]	Satellite signal list

DID_GPX_BIT

GPX BIT test

gpx_bit_t

Field	Type	Description
results	uint32_t	GPX built-in test status (see eGPXBit_results)
command	uint8_t	Command (see eGPXBit_CMD)
port	uint8_t	Port used with the test
testMode	uint8_t	Self-test mode (see eGPXBit_test_mode)
state	uint8_t	Built-in self-test state (see eGPXBit_state)
detectedHardwareId	uint16_t	The hardware ID detected (see "Product Hardware ID"). This is used to ensure correct firmware is used.
reserved	uint8_t[2]	Unused

DID_GPX_DEBUG_ARRAY

GPX debug

debug_array_t

Field	Type	Description
-------	------	-------------

DID_GPX_PORT_MONITOR

Data rate and status monitoring for each communications port.

port_monitor_t

Field	Type	Description
port	port_monitor_set_t[6]	Port monitor set

DID_GPX_RTOS_INFO

GPX RTOs info

`gpx_rtos_info_t`

Field	Type	Description
freeHeapSize	uint32_t	Heap high water mark bytes
mallocSize	uint32_t	Total memory allocated using RTOS pvPortMalloc()
freeSize	uint32_t	Total memory freed using RTOS vPortFree()
task	rtos_task_t[]	Tasks

`DID_GROUND_VEHICLE`

Static configuration for wheel transform measurements.

`ground_vehicle_t`

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
status	uint32_t	Ground vehicle status flags (eGroundVehicleStatus)
mode	uint32_t	Current mode of the ground vehicle. Use this field to apply commands. (see eGroundVehicleMode)
wheelConfig	wheel_config_t	Wheel transform, track width, and wheel radius.

`DID_IMU3_RAW`

Triple IMU data calibrated from DID_IMU3_UNCAL. We recommend use of DID_IMU or DID_PIMU as they are oversampled and contain less noise.

`imu3_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
status	uint32_t	IMU Status (eImuStatus)
I	imus_t[3]	Inertial Measurement Units (IMUs)

`DID_IMU3_UNCAL`

Uncalibrated triple IMU data. We recommend use of DID_IMU or DID_PIMU as they are calibrated and oversampled and contain less noise. Minimum data period is `DID_FLASH_CONFIG.startupImuDtMs` or 4, whichever is larger (250Hz max).

`imu3_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
status	uint32_t	IMU Status (eImuStatus)
I	imus_t[3]	Inertial Measurement Units (IMUs)

`DID_IMU_MAG`

DID_IMU + DID_MAGNETOMETER. Only one of DID_IMU_MAG or DID_PIMU_MAG should be streamed simultaneously.

`imu_mag_t`

Field	Type	Description
imu	imu_t	imu - raw or pre-integrated depending on data id
mag	magnetometer_t	mag

`DID_INFIELD_CAL`

Measure and correct IMU calibration error. Estimate INS rotation to align INS with vehicle.

`infield_cal_t`

Field	Type	Description
state	uint32_t	Used to set and monitor the state of the infield calibration system. (see <code>eInfieldCalState</code>)
status	uint32_t	Infield calibration status. (see <code>eInfieldCalStatus</code>)
sampleTimeMs	uint32_t	Number of samples used in IMU average. <code>sampleTimeMs = 0</code> means "imu" member contains the IMU bias from flash.
imu	imus_t[3]	Dual purpose variable. 1.) This is the averaged IMU sample when <code>sampleTimeMs != 0</code> . 2.) This is a mirror of the motion calibration IMU bias from flash when <code>sampleTimeMs = 0</code> .
calData	infield_cal_vaxis_t[3]	Collected data used to solve for the bias error and INS rotation. Vertical axis: 0 = X, 1 = Y, 2 = Z

`DID_INL2_MAG_OBS_INFO`

INL2 magnetometer calibration information.

inl2_mag_obs_info_t

Field	Type	Description
timeOfWeekMs	uint32_t	Timestamp in milliseconds
Ncal_samples	uint32_t	Number of calibration samples
ready	uint32_t	Data ready to be processed
calibrated	uint32_t	Calibration data present. Set to -1 to force mag recalibration.
auto_recal	uint32_t	Allow mag to auto-recalibrate
outlier	uint32_t	Bad sample data
magHdg	float	Heading from magnetometer
insHdg	float	Heading from INS
magInsHdgDelta	float	Difference between mag heading and (INS heading plus mag declination)
nis	float	Normalized innovation squared (likelihood metric)
nis_threshold	float	Threshold for maximum NIS
Wcal	float[9]	Magnetometer calibration matrix. Must be initialized with a unit matrix, not zeros!
activeCalSet	uint32_t	Active calibration set (0 or 1)
magHdgOffset	float	Offset between magnetometer heading and estimate heading
Tcal	float	Scaled computed variance between calibrated magnetometer samples.
bias_cal	float[3]	Calibrated magnetometer output can be produced using: $B_{cal} = W_{cal} * (B_{raw} - bias_{cal})$

DID_INL2_NED_SIGMA

Standard deviation of INL2 EKF estimates in the NED frame.

inl2_ned_sigma_t

Field	Type	Description
timeOfWeekMs	unsigned	Timestamp in milliseconds
StdPosNed	float[3]	NED position error sigma
StdVelNed	float[3]	NED velocity error sigma
StdAttNed	float[3]	NED attitude error sigma
StdAccBias	float[3]	Acceleration bias error sigma
StdGyrBias	float[3]	Angular rate bias error sigma
StdBarBias	float	Barometric altitude bias error sigma
StdMagDeclination	float	Mag declination error sigma

DID_INL2_STATES

INS Extended Kalman Filter (EKF) states

inl2_states_t

Field	Type	Description
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
qe2b	float[4]	Quaternion body rotation with respect to ECEF
ve	float[3]	(m/s) Velocity in ECEF frame
ecef	double[3]	(m) Position in ECEF frame
biasPqr	float[3]	(rad/s) Gyro bias
biasAcc	float[3]	(m/s ²) Accelerometer bias
biasBaro	float	(m) Barometer bias
magDec	float	(rad) Magnetic declination
magInc	float	(rad) Magnetic inclination

DID_INL2_STATUS

inl2_status_t

Field	Type	Description
-------	------	-------------

DID_IO

I/O

io_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
gpioStatus	uint32_t	General purpose I/O status

DID_MANUFACTURING_INFO

Manufacturing info

manufacturing_info_t

Field	Type	Description
serialNumber	uint32_t	Inertial Sense serial number
hardwareId	uint16_t	Hardware ID: This is a packed identifier, which includes the Hardware Type, hardwareVer Major, and hardwareVer Minor
lotNumber	uint16_t	Inertial Sense lot number
date	char[16]	Inertial Sense manufacturing date (YYYYMMDDHHMMSS)
key	uint32_t	Key - write: unlock manufacturing info, read: number of times OTP has been set, 15 max
platformType	int32_t	Platform / carrier board (ePlatformConfig::PLATFORM_CFG_TYPE_MASK). Only valid if greater than zero.
reserved	int32_t	Microcontroller unique identifier, 128 bits for SAM / 96 for STM32

DID_PIMU_MAG

DID_PIMU + DID_MAGNETOMETER. Only one of DID_IMU_MAG or DID_PIMU_MAG should be streamed simultaneously.

`pimu_mag_t`

Field	Type	Description
pimu	pimu_t	Preintegrated IMU
mag	magnetometer_t	Magnetometer

DID_PORT_MONITOR

Data rate and status monitoring for each communications port.

`port_monitor_t`

Field	Type	Description
port	port_monitor_set_t[6]	Port monitor set

DID_POSITION_MEASUREMENT

External position estimate

`pos_measurement_t`

Field	Type	Description
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
ecef	double[3]	Position in ECEF (earth-centered earth-fixed) frame in meters
psi	float	Heading with respect to NED frame (rad)

DID_REFERENCE_IMU

Raw reference or truth IMU used for manufacturing calibration and testing. Input from testbed.

`imu_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
status	uint32_t	IMU Status (<code>eImuStatus</code>)
I	imus_t	Inertial Measurement Unit (IMU)

DID_REFERENCE_MAGNETOMETER

Reference or truth magnetometer used for manufacturing calibration and testing

`magnetometer_t`

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding <code>gps.towOffset</code>
mag	float[3]	Magnetometers

DID_REFERENCE_PIMU

Reference or truth IMU used for manufacturing calibration and testing

pimu_t

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding gps.towOffset
dt	float	Integral period in seconds for delta theta and delta velocity. This is configured using DID_FLASH_CONFIG.startupNavDtMs.
status	uint32_t	IMU Status (eImuStatus)
theta	float[3]	IMU delta theta (gyroscope {p,q,r} integral) in radians in sensor frame
vel	float[3]	IMU delta velocity (accelerometer {x,y,z} integral) in m/s in sensor frame

DID_ROS_COVARIANCE_POSE_TWIST

INL2 EKF covariances matrix lower diagonals

ros_covariance_pose_twist_t

Field	Type	Description
timeOfWeek	double	GPS time of week (since Sunday morning) in seconds
covPoseLD	float[21]	(rad ² , m ²) EKF attitude and position error covariance matrix lower diagonal in body (attitude) and ECEF (position) frames
covTwistLD	float[21]	((m/s) ² , (rad/s) ²) EKF velocity and angular rate error covariance matrix lower diagonal in ECEF (velocity) and body (attitude) frames

DID_RTOS_INFO

RTOS information.

rtos_info_t

Field	Type	Description
freeHeapSize	uint32_t	Heap high water mark bytes
mallocSize	uint32_t	Total memory allocated using RTOS pvPortMalloc()
freeSize	uint32_t	Total memory freed using RTOS vPortFree()
task	rtos_task_t[]	Tasks

DID_RUNTIME_PROFILER

System runtime profiler

runtime_profiler_t

Field	Type	Description
-------	------	-------------

DID_SCOMP

sensor_compensation_t

Field	Type	Description
-------	------	-------------

DID_SENSORS_ADC

sys_sensors_adc_t

Field	Type	Description
-------	------	-------------

DID_SENSORS_ADC_SIGMA

sys_sensors_adc_t

Field	Type	Description
-------	------	-------------

DID_SENSORS_MCAL

Temperature compensated and motion calibrated IMU output.

sensors_w_temp_t

Field	Type	Description
imu3	imu3_t	(°C) Temperature of IMU. Units only apply for calibrated data.
temp	f_t[3]	(uT) Magnetometers. Units only apply for calibrated data.

DID_SENSORS_TCAL

Temperature compensated IMU output.

sensors_w_temp_t

Field	Type	Description
imu3	imu3_t	(°C) Temperature of IMU. Units only apply for calibrated data.
temp	f_t[3]	(uT) Magnetometers. Units only apply for calibrated data.

DID_SENSORS_TC_BIAS

sensors_t

Field	Type	Description
time	double	Time since boot up in seconds. Convert to GPS time of week by adding gps.towOffset
temp	float	Temperature in Celsius
pqr	float[3]	Gyros in radians / second
acc	float[3]	Accelerometers in meters / second squared
mag	float[3]	Magnetometers
bar	float	Barometric pressure in kilopascals
barTemp	float	Temperature of barometric pressure sensor in Celsius
mslBar	float	MSL altitude from barometric pressure sensor in meters
humidity	float	Relative humidity as a percent (%rH). Range is 0% - 100%
vin	float	EVB system input voltage in volts. uINS pin 5 (G2/AN2). Use 10K/1K resistor divider between Vin and GND.
ana1	float	ADC analog input in volts. uINS pin 4, (G1/AN1).
ana3	float	ADC analog input in volts. uINS pin 19 (G3/AN3).
ana4	float	ADC analog input in volts. uINS pin 20 (G4/AN4).

DID_SENSORS_UCAL

Uncalibrated IMU output.

sensors_w_temp_t

Field	Type	Description
imu3	imu3_t	(°C) Temperature of IMU. Units only apply for calibrated data.
temp	f_t[3]	(uT) Magnetometers. Units only apply for calibrated data.

DID_STROBE_IN_TIME

Timestamp for input strobe.

strobe_in_time_t

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
pin	uint16_t	Strobe input pin (i.e. G1, G2, G5, or G9)
count	uint16_t	Strobe serial index number

DID_SURVEY_IN

Survey in, used to determine position for RTK base station. Base correction output cannot run during a survey and will be automatically disabled if a survey is started.

survey_in_t

Field	Type	Description
state	uint32_t	State of current survey, eSurveyInStatus
maxDurationSec	uint32_t	Maximum time (milliseconds) survey will run if minAccuracy is not first achieved. (ignored if 0).
minAccuracy	float	Required horizontal accuracy (m) for survey to complete before maxDuration. (ignored if 0)
elapsedTimeSec	uint32_t	Elapsed time (seconds) of the survey.
hAccuracy	float	Approximate horizontal accuracy of the survey (m).
lla	double[3]	The current surveyed latitude, longitude, altitude (deg, deg, m)

DID_SYS_FAULT

System fault information. This is broadcast automatically every 10s if a critical fault is detected.

system_fault_t

Field	Type	Description
status	uint32_t	System fault status (see eSysFaultStatus)
g1Task	uint32_t	Fault Type at HardFault
g2FileNum	uint32_t	Multipurpose register - Line number of fault
g3LineNum	uint32_t	Multipurpose register - File number at fault
g4	uint32_t	Multipurpose register - at time of fault.
g5Lr	uint32_t	Multipurpose register - link register value at time of fault.
pc	uint32_t	Program Counter value at time of fault
psr	uint32_t	Program Status Register value at time of fault

DID_SYS_PARAMS

System parameters / info

sys_params_t

Field	Type	Description
timeOfWeekMs	uint32_t	GPS time of week (since Sunday morning) in milliseconds
insStatus	uint32_t	INS status flags (eInsStatusFlags)
hdwStatus	uint32_t	Hardware status flags (eHdwStatusFlags)
imuTemp	float	IMU temperature
baroTemp	float	Baro temperature
mcuTemp	float	MCU temperature (not available yet)
sysStatus	uint32_t	System status flags (eSysStatusFlags)
imuSamplePeriodMs	uint32_t	IMU sample period (ms). Zero disables sampling.
navOutputPeriodMs	uint32_t	Preintegrated IMU (PIMU) integration period and navigation/AHRS filter output period (ms).
sensorTruePeriod	double	Actual sample period relative to GPS PPS (sec)
flashCfgChecksum	uint32_t	Flash config checksum used with host SDK synchronization
navUpdatePeriodMs	uint32_t	Navigation/AHRS filter update period (ms)
genFaultCode	uint32_t	General fault code descriptor (eGenFaultCodes). Set to zero to reset fault code.
upTime	double	System up time in seconds (with double precision)

DID_WHEEL_ENCODER

Wheel encoder data to be fused with GPS-INS measurements, set DID_GROUND_VEHICLE for configuration before sending this message

wheel_encoder_t

Field	Type	Description
timeOfWeek	double	(Do not use, internal development only) Time of measurement in current GPS week
status	uint32_t	Status
theta_l	float	(Do not use, internal development only) Left wheel angle (rad)
theta_r	float	(Do not use, internal development only) Right wheel angle (rad)
omega_l	float	Left wheel angular rate (rad/s). Positive when wheel is turning toward the forward direction of the vehicle. Use WHEEL_CFG_BITS_DIRECTION_REVERSE_LEFT in DID_FLASH_CONFIG::wheelConfig to reverse this.
omega_r	float	Right wheel angular rate (rad/s). Positive when wheel is turning toward the forward direction of the vehicle. Use WHEEL_CFG_BITS_DIRECTION_REVERSE_RIGHT in DID_FLASH_CONFIG::wheelConfig to reverse this.
wrap_count_l	uint32_t	(Do not use, internal development only) Left wheel revolution count
wrap_count_r	uint32_t	(Do not use, internal development only) Right wheel revolution count

7.2.2 Enumerations and Defines

System status and configuration is made available through various enumeration and #defines.

General

DID_EVB_FLASH_CFG.CBPRESET

(eEvb2ComBridgePreset)

Field	Value
EVB2_CB_PRESET_NA	0
EVB2_CB_PRESET_ALL_OFF	1
EVB2_CB_PRESET_RS232	2
EVB2_CB_PRESET_RS232_XBEE	3
EVB2_CB_PRESET_RS422_WIFI	4
EVB2_CB_PRESET_SPI_RS232	5
EVB2_CB_PRESET_USB_HUB_RS232	6
EVB2_CB_PRESET_USB_HUB_RS422	7
EVB2_CB_PRESET_COUNT	8

DID_EVB_FLASH_CFG.PORTOPTIONS

(eEvb2PortOptions)

Field	Value
EVB2_PORT_OPTIONS_RADIO_RTK_FILTER	0x00000001
EVB2_PORT_OPTIONS_DEFAULT	EVB2_PORT_OPTIONS_RADIO_RTK_FILTER

DID_EVB_STATUS.LOGGERMODE

(eEvb2LoggerMode)

Field	Value
EVB2_LOG_NA	0
EVB2_LOG_CMD_START	2
EVB2_LOG_CMD_STOP	4
EVB2_LOG_CMD_PURGE	1002

DID_FLASH_CONFIG.GNSSATSIGCONST

(eGnssSatSigConst)

Field	Value
GNSS_SAT_SIG_CONST_GPS	0x0003
GNSS_SAT_SIG_CONST_QZS	0x000C
GNSS_SAT_SIG_CONST_GAL	0x0030
GNSS_SAT_SIG_CONST_BDS	0x00C0
GNSS_SAT_SIG_CONST_GLO	0x0300
GNSS_SAT_SIG_CONST_SBS	0x1000
GNSS_SAT_SIG_CONST_IRN	0x2000
GNSS_SAT_SIG_CONST_IME	0x4000

DID_FLASH_CONFIG.SENSORCONFIG

(eSensorConfig)

Field	Value
SENSOR_CFG_GYR_FS_250	0x00000000
SENSOR_CFG_GYR_FS_500	0x00000001
SENSOR_CFG_GYR_FS_1000	0x00000002
SENSOR_CFG_GYR_FS_2000	0x00000003
SENSOR_CFG_GYR_FS_4000	0x00000004
SENSOR_CFG_GYR_FS_MASK	0x00000007
SENSOR_CFG_GYR_FS_OFFSET	(int)0
SENSOR_CFG_ACC_FS_2G	0x00000000
SENSOR_CFG_ACC_FS_4G	0x00000001
SENSOR_CFG_ACC_FS_8G	0x00000002
SENSOR_CFG_ACC_FS_16G	0x00000003
SENSOR_CFG_ACC_FS_MASK	0x00000030
SENSOR_CFG_ACC_FS_OFFSET	(int)4
SENSOR_CFG_GYR_DLPF_250HZ	0x00000000
SENSOR_CFG_GYR_DLPF_184HZ	0x00000001
SENSOR_CFG_GYR_DLPF_92HZ	0x00000002
SENSOR_CFG_GYR_DLPF_41HZ	0x00000003
SENSOR_CFG_GYR_DLPF_20HZ	0x00000004
SENSOR_CFG_GYR_DLPF_10HZ	0x00000005
SENSOR_CFG_GYR_DLPF_5HZ	0x00000006
SENSOR_CFG_GYR_DLPF_MASK	0x00000F00
SENSOR_CFG_GYR_DLPF_OFFSET	(int)8
SENSOR_CFG_ACC_DLPF_218HZ	0x00000000
SENSOR_CFG_ACC_DLPF_218HZb	0x00000001
SENSOR_CFG_ACC_DLPF_99HZ	0x00000002
SENSOR_CFG_ACC_DLPF_45HZ	0x00000003
SENSOR_CFG_ACC_DLPF_21HZ	0x00000004
SENSOR_CFG_ACC_DLPF_10HZ	0x00000005
SENSOR_CFG_ACC_DLPF_5HZ	0x00000006
SENSOR_CFG_ACC_DLPF_MASK	0x0000F000
SENSOR_CFG_ACC_DLPF_OFFSET	(int)12
SENSOR_CFG_SENSOR_ROTATION_MASK	0x001F0000
SENSOR_CFG_SENSOR_ROTATION_OFFSET	(int)16
SENSOR_CFG_SENSOR_ROTATION_0_0_0	(int)0
SENSOR_CFG_SENSOR_ROTATION_0_0_90	(int)1

Field	Value
SENSOR_CFG_SENSOR_ROTATION_0_0_180	(int)2
SENSOR_CFG_SENSOR_ROTATION_0_0_N90	(int)3
SENSOR_CFG_SENSOR_ROTATION_90_0_0	(int)4
SENSOR_CFG_SENSOR_ROTATION_90_0_90	(int)5
SENSOR_CFG_SENSOR_ROTATION_90_0_180	(int)6
SENSOR_CFG_SENSOR_ROTATION_90_0_N90	(int)7
SENSOR_CFG_SENSOR_ROTATION_180_0_0	(int)8
SENSOR_CFG_SENSOR_ROTATION_180_0_90	(int)9
SENSOR_CFG_SENSOR_ROTATION_180_0_180	(int)10
SENSOR_CFG_SENSOR_ROTATION_180_0_N90	(int)11
SENSOR_CFG_SENSOR_ROTATION_N90_0_0	(int)12
SENSOR_CFG_SENSOR_ROTATION_N90_0_90	(int)13
SENSOR_CFG_SENSOR_ROTATION_N90_0_180	(int)14
SENSOR_CFG_SENSOR_ROTATION_N90_0_N90	(int)15
SENSOR_CFG_SENSOR_ROTATION_0_90_0	(int)16
SENSOR_CFG_SENSOR_ROTATION_0_90_90	(int)17
SENSOR_CFG_SENSOR_ROTATION_0_90_180	(int)18
SENSOR_CFG_SENSOR_ROTATION_0_90_N90	(int)19
SENSOR_CFG_SENSOR_ROTATION_0_N90_0	(int)20
SENSOR_CFG_SENSOR_ROTATION_0_N90_90	(int)21
SENSOR_CFG_SENSOR_ROTATION_0_N90_180	(int)22
SENSOR_CFG_SENSOR_ROTATION_0_N90_N90	(int)23
SENSOR_CFG_MAG_ODR_100_HZ	0x00200000
SENSOR_CFG_DISABLE_MAGNETOMETER	0x00400000
SENSOR_CFG_DISABLE_BAROMETER	0x00800000
SENSOR_CFG_IMU_FAULT_DETECT_MASK	0xFF000000
SENSOR_CFG_IMU_FAULT_DETECT_GYR	0x01000000
SENSOR_CFG_IMU_FAULT_DETECT_ACC	0x02000000
SENSOR_CFG_IMU_FAULT_DETECT_OFFLINE	0x04000000
SENSOR_CFG_IMU_FAULT_DETECT_LARGE_BIAS	0x08000000
SENSOR_CFG_IMU_FAULT_DETECT_SENSOR_NOISE	0x10000000

DID_FLASH_CONFIG.SYSCFGBITS

(eSysConfigBits)

Field	Value
UNUSED1	0x00000001
SYS_CFG_BITS_ENABLE_MAG_CONTINUOUS_CAL	0x00000002
SYS_CFG_BITS_AUTO_MAG_RECAL	0x00000004
SYS_CFG_BITS_DISABLE_MAG_DECL_ESTIMATION	0x00000008
SYS_CFG_BITS_DISABLE_LEDS	0x00000010
Magnetometer	multi-axis
SYS_CFG_BITS_MAG_RECAL_MODE_MASK	0x00000700
SYS_CFG_BITS_MAG_RECAL_MODE_OFFSET	8
SYS_CFG_BITS_MAG_ENABLE_WMM_DECLINATION	0x00000800
SYS_CFG_BITS_DISABLE_MAGNETOMETER_FUSION	0x00001000
SYS_CFG_BITS_DISABLE_BAROMETER_FUSION	0x00002000
SYS_CFG_BITS_DISABLE_GPS1_FUSION	0x00004000
SYS_CFG_BITS_DISABLE_GPS2_FUSION	0x00008000
SYS_CFG_BITS_DISABLE_AUTO_ZERO_VELOCITY_UPDATES	0x00010000
SYS_CFG_BITS_DISABLE_AUTO_ZERO_ANGULAR_RATE_UPDATES	0x00020000
SYS_CFG_BITS_DISABLE_INS_EKF	0x00040000
SYS_CFG_BITS_DISABLE_AUTO_BIT_ON_STARTUP	0x00080000
SYS_CFG_BITS_DISABLE_WHEEL_ENCODER_FUSION	0x00100000
SYS_CFG_BITS_UNUSED3	0x00200000
SYS_CFG_BITS_BOR_LEVEL_0	0x0
SYS_CFG_BITS_BOR_LEVEL_1	0x1
SYS_CFG_BITS_BOR_LEVEL_2	0x2
SYS_CFG_BITS_BOR_LEVEL_3	0x3
SYS_CFG_BITS_BOR_THRESHOLD_MASK	0x00C00000
SYS_CFG_BITS_BOR_THRESHOLD_OFFSET	22
SYS_CFG_USE_REFERENCE_IMU_IN_EKF	0x01000000
SYS_CFG_EKF_REF_POINT_STATIONARY_ON_STROBE_INPUT	0x02000000

DID_GPX_FLASH_CFG.SYSCFGBITS

(eGpxSysConfigBits)

Field	Value
GPX_SYS_CFG_BITS_DISABLE_VCC_RF	0x00000001
GPX_SYS_CFG_BITS_BOR_LEVEL_0	0x0
GPX_SYS_CFG_BITS_BOR_LEVEL_1	0x1
GPX_SYS_CFG_BITS_BOR_LEVEL_2	0x2
GPX_SYS_CFG_BITS_BOR_LEVEL_3	0x3
GPX_SYS_CFG_BITS_BOR_THRESHOLD_MASK	0x00C00000
GPX_SYS_CFG_BITS_BOR_THRESHOLD_OFFSET	22

DID_GPX_STATUS.HDWSTATUS
(eGPXHdwStatusFlags)

Field	Value
GPX_HDW_STATUS_GNSS1_SATELLITE_RX	0x00000001
GPX_HDW_STATUS_GNSS2_SATELLITE_RX	0x00000002
GPX_HDW_STATUS_GNSS1_TIME_OF_WEEK_VALID	0x00000004
GPX_HDW_STATUS_GNSS2_TIME_OF_WEEK_VALID	0x00000008
GPX_HDW_STATUS_GNSS1_RESET_COUNT_MASK	0x00000070
GPX_HDW_STATUS_GNSS1_RESET_COUNT_OFFSET	4
GPX_HDW_STATUS_FAULT_GNSS1_INIT	0x00000080
GPX_HDW_STATUS_GNSS1_FAULT_FLAG_OFFSET	7
GPX_HDW_STATUS_GNSS2_RESET_COUNT_MASK	0x00000700
GPX_HDW_STATUS_GNSS2_RESET_COUNT_OFFSET	8
GPX_HDW_STATUS_FAULT_GNSS2_INIT	0x00000800
GPX_HDW_STATUS_GNSS2_FAULT_FLAG_OFFSET	11
GPX_HDW_STATUS_GNSS_FW_UPDATE_REQUIRED	0x00001000
GPX_HDW_STATUS_UNUSED	0x00002000
GPX_HDW_STATUS_SYSTEM_RESET_REQUIRED	0x00004000
GPX_HDW_STATUS_FLASH_WRITE_PENDING	0x00008000
GPX_HDW_STATUS_ERR_COM_TX_LIMITED	0x00010000
GPX_HDW_STATUS_ERR_COM_RX_OVERRUN	0x00020000
GPX_HDW_STATUS_ERR_NO_GPS1_PPS	0x00040000
GPX_HDW_STATUS_ERR_NO_GPS2_PPS	0x00080000
GPX_HDW_STATUS_ERR_PPS_MASK	0x000C0000
GPX_HDW_STATUS_ERR_LOW_CNO_GPS1	0x00100000
GPX_HDW_STATUS_ERR_LOW_CNO_GPS2	0x00200000
GPX_HDW_STATUS_ERR_CNO_GPS1_IR	0x00400000
GPX_HDW_STATUS_ERR_CNO_GPS2_IR	0x00800000
GPX_HDW_STATUS_ERR_CNO_MASK	0x00F00000
GPX_HDW_STATUS_BIT_RUNNING	0x01000000
GPX_HDW_STATUS_BIT_PASSED	0x02000000
GPX_HDW_STATUS_BIT_FAULT	0x03000000
GPX_HDW_STATUS_BIT_MASK	0x03000000
GPX_HDW_STATUS_BIT_OFFSET	24
GPX_HDW_STATUS_ERR_TEMPERATURE	0x04000000
GPX_HDW_STATUS_GPS_PPS_TIMESYNC	0x08000000
GPX_HDW_STATUS_RESET_CAUSE_MASK	0x70000000
GPX_HDW_STATUS_RESET_CAUSE_BACKUP_MODE	0x10000000

Field	Value
GPX_HDW_STATUS_RESET_CAUSE_SOFT	0x20000000
GPX_HDW_STATUS_RESET_CAUSE_HDW	0x40000000
GPX_HDW_STATUS_FAULT_SYS_CRITICAL	0x80000000

DID_GPX_STATUS.RTKMODE

(eRTKConfigBits)

Field	Value
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING	0x00000001
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_EXTERNAL	0x00000002
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_F9P	0x00000004
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING	0x00000008
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_EXTERNAL)
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_F9P)
RTK_CFG_BITS_ROVER_MODE_MASK	0x0000000F
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER0	0x00000010
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER1	0x00000020
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER2	0x00000040
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_USB	0x00000080
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER0	0x00000100
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER1	0x00000200
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER2	0x00000400
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_USB	0x00000800
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER0	0x00001000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER1	0x00002000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER2	0x00004000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_USB	0x00008000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER0	0x00010000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER1	0x00020000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER2	0x00040000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_USB	0x00080000
RTK_CFG_BITS_BASE_POS_MOVING	0x00100000
RTK_CFG_BITS_RESERVED1	0x00200000
RTK_CFG_BITS_RTK_BASE_IS_IDENTICAL_TO_ROVER	0x00400000
RTK_CFG_BITS_GPS_PORT_PASS_THROUGH	0x00800000
RTK_CFG_BITS_ROVER_MODE_ONBOARD_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING)
RTK_CFG_BITS_ALL_MODES_MASK	(RTK_CFG_BITS_ROVER_MODE_MASK RTK_CFG_BITS_BASE_MODE)

DID_GPX_STATUS.STATUS

(eGpxStatus)

Field	Value
GPX_STATUS_COM_PARSE_ERR_COUNT_MASK	0x0000000F
GPX_STATUS_COM_PARSE_ERR_COUNT_OFFSET	0
GPX_STATUS_COM0_RX_TRAFFIC_NOT_DETECTED	0x00000010
GPX_STATUS_COM1_RX_TRAFFIC_NOT_DETECTED	0x00000020
GPX_STATUS_COM2_RX_TRAFFIC_NOT_DETECTED	0x00000040
GPX_STATUS_GENERAL_FAULT_MASK	0xFFFF0000
GPX_STATUS_FAULT_RTK_QUEUE_LIMITED	0x00010000
GPX_STATUS_FAULT_GNSS_RCVR_TIME	0x00100000
GPX_STATUS_FAULT_DMA	0x00800000
GPX_STATUS_FATAL_MASK	0x1F000000
GPX_STATUS_FATAL_OFFSET	24
GPX_STATUS_FATAL_RESET_LOW_POW	(int)1
GPX_STATUS_FATAL_RESET_BROWN	(int)2
GPX_STATUS_FATAL_RESET_WATCHDOG	(int)3
GPX_STATUS_FATAL_CPU_EXCEPTION	(int)4
GPX_STATUS_FATAL_UNHANDLED_INTERRUPT	(int)5
GPX_STATUS_FATAL_STACK_OVERFLOW	(int)6
GPX_STATUS_FATAL_KERNEL_OOPS	(int)7
GPX_STATUS_FATAL_KERNEL_PANIC	(int)8
GPX_STATUS_FATAL_UNALIGNED_ACCESS	(int)9
GPX_STATUS_FATAL_MEMORY_ERROR	(int)10
GPX_STATUS_FATAL_BUS_ERROR	(int)11
GPX_STATUS_FATAL_USAGE_ERROR	(int)12
GPX_STATUS_FATAL_DIV_ZERO	(int)13
GPX_STATUS_FATAL_SER0_REINIT	(int)14
GPX_STATUS_FATAL_UNKNOWN	0x1F
GPX_STATUS_FAULT_RP	0x20000000
GPX_STATUS_FAULT_UNUSED	0xC0000000

DID_SYS_CMD.COMMAND

(eSystemCommand)

Field	Value
SYS_CMD_NONE	0
SYS_CMD_SAVE_PERSISTENT_MESSAGES	1
SYS_CMD_ENABLE_BOOTLOADER_AND_RESET	2
SYS_CMD_ENABLE_SENSOR_STATS	3
SYS_CMD_ENABLE_RTOS_STATS	4
SYS_CMD_ZERO_MOTION	5
SYS_CMD_REF_POINT_STATIONARY	6
SYS_CMD_REF_POINT_MOVING	7
SYS_CMD_RESET_RTOS_STATS	8
SYS_CMD_ENABLE_GPS_LOW_LEVEL_CONFIG	10
SYS_CMD_DISABLE_SERIAL_PORT_BRIDGE	11
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_GPS1	12
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_GPS2	13
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_SER0	14
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_SER1	15
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_SER2	16
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_SER0_TO_GPS1	17
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_GPS1	18
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_GPS2	19
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_USB	20
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_SER0	21
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_SER1	22
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_TO_SER2	23
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_LOOPBACK	24
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_SER0_LOOPBACK	25
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_SER1_LOOPBACK	26
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_SER2_LOOPBACK	27
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_LOOPBACK	28
SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_CUR_PORT_LOOPBACK_TESTMODE	29
SYS_CMD_GPX_ENABLE_BOOTLOADER_MODE	30
SYS_CMD_GPX_ENABLE_GNSS1_CHIPSET_BOOTLOADER	31
SYS_CMD_GPX_ENABLE_GNSS2_CHIPSET_BOOTLOADER	32
SYS_CMD_GPX_ENABLE_GNSS1_PASS_THROUGH	33
SYS_CMD_GPX_ENABLE_GNSS2_PASS_THROUGH	34
SYS_CMD_GPX_HARD_RESET_GNSS1	36

Field	Value
SYS_CMD_GPX_HARD_RESET_GNSS2	37
SYS_CMD_GPX_SOFT_RESET_GPX	38
SYS_CMD_GPX_ENABLE_SERIAL_BRIDGE_CUR_PORT_LOOPBACK	39
SYS_CMD_GPX_ENABLE_SERIAL_BRIDGE_CUR_PORT_LOOPBACK_TESTMODE	40
SYS_CMD_GPX_ENABLE_RTOS_STATS	41
SYS_CMD_SET_GPX_SER0_PIN_DEFAULT	67
SYS_CMD_SET_GPX_SER0_PIN_REINIT	68
SYS_CMD_TEST_SER0_TX_PIN_LOW	70
SYS_CMD_TEST_SER0_TX_PIN_HIGH	71
SYS_CMD_TEST_SER0_TX_INPUT	72
SYS_CMD_TEST_SER0_TX_PP_NONE	80
SYS_CMD_TEST_SER0_TX_PP_U	81
SYS_CMD_TEST_SER0_TX_PP_D	82
SYS_CMD_SAVE_FLASH	97
SYS_CMD_SAVE_GPS_ASSIST_TO_FLASH_RESET	98
SYS_CMD_SOFTWARE_RESET	99
SYS_CMD_MANF_UNLOCK	1122334455
SYS_CMD_MANF_FACTORY_RESET	1357924680
SYS_CMD_MANF_CHIP_ERASE	1357924681
SYS_CMD_MANF_DOWNGRADE_CALIBRATION	1357924682
SYS_CMD_MANF_ENABLE_ROM_BOOTLOADER	1357924683
SYS_CMD_FAULT_TEST_TRIG_MALLOC	57005
SYS_CMD_FAULT_TEST_TRIG_HARD_FAULT	57006
SYS_CMD_FAULT_TEST_TRIG_WATCHDOG	57007

DID_SYS_PARAMS.GENFAULTCODE

(eGenFaultCodes)

Field	Value
GFC_INS_STATE_ORUN_UVW	0x00000001
GFC_INS_STATE_ORUN_LAT	0x00000002
GFC_INS_STATE_ORUN_ALT	0x00000004
GFC_UNHANDLED_INTERRUPT	0x00000010
GFC_GNSS_CRITICAL_FAULT	0x00000020
GFC_GNSS_TX_LIMITED	0x00000040
GFC_GNSS_RX_OVERRUN	0x00000080
GFC_INIT_SENSORS	0x00000100
GFC_INIT_SPI	0x00000200
GFC_CONFIG_SPI	0x00000400
GFC_GNSS1_INIT	0x00000800
GFC_GNSS2_INIT	0x00001000
GFC_FLASH_INVALID_VALUES	0x00002000
GFC_FLASH_CHECKSUM_FAILURE	0x00004000
GFC_FLASH_WRITE_FAILURE	0x00008000
GFC_SYS_FAULT_GENERAL	0x00010000
GFC_SYS_FAULT_CRITICAL	0x00020000
GFC_SENSOR_SATURATION	0x00040000
GFC_INIT_IMU	0x00100000
GFC_INIT_BAROMETER	0x00200000
GFC_INIT_MAGNETOMETER	0x00400000
GFC_INIT_I2C	0x00800000
GFC_CHIP_ERASE_INVALID	0x01000000
GFC_EKF_GNSS_TIME_FAULT	0x02000000
GFC_GNSS_RECEIVER_TIME	0x04000000
GFC_GNSS_GENERAL_FAULT	0x08000000
GFC_GPX_STATUS_COMMON_MASK	GFC_GNSS1_INIT GFC_GNSS2_INIT GFC_GNSS_TX_LIMITED GFC_GNSS_RX_OVERRUN GFC_GNSS_CRITICAL_FAULT GFC_GNSS_RECEIVER_TIME GFC_GNSS_GENERAL_FAULT

GPS NAVIGATION FIX TYPE

(eGpsNavFixStatus)

Field	Value
GPS_NAV_FIX_NONE	0x00000000
GPS_NAV_FIX_POSITIONING_3D	0x00000001
GPS_NAV_FIX_POSITIONING_RTK_FLOAT	0x00000002
GPS_NAV_FIX_POSITIONING_RTK_FIX	0x00000003

GPS STATUS

(eGpsStatus)

Field	Value
GPS_STATUS_NUM_SATS_USED_MASK	0x000000FF
GPS_STATUS_FIX_NONE	0x00000000
GPS_STATUS_FIX_DEAD_RECKONING_ONLY	0x00000100
GPS_STATUS_FIX_2D	0x00000200
GPS_STATUS_FIX_3D	0x00000300
GPS_STATUS_FIX_GPS_PLUS_DEAD_RECK	0x00000400
GPS_STATUS_FIX_TIME_ONLY	0x00000500
GPS_STATUS_FIX_UNUSED1	0x00000600
GPS_STATUS_FIX_UNUSED2	0x00000700
GPS_STATUS_FIX_DGPS	0x00000800
GPS_STATUS_FIX_SBAS	0x00000900
GPS_STATUS_FIX_RTK_SINGLE	0x00000A00
GPS_STATUS_FIX_RTK_FLOAT	0x00000B00
GPS_STATUS_FIX_RTK_FIX	0x00000C00
GPS_STATUS_FIX_MASK	0x00001F00
GPS_STATUS_FIX_BIT_OFFSET	(int)8
GPS_STATUS_FLAGS_FIX_OK	0x00010000
GPS_STATUS_FLAGS_DGPS_USED	0x00020000
GPS_STATUS_FLAGS_RTK_FIX_AND_HOLD	0x00040000
GPS_STATUS_FLAGS_WEEK_VALID	0x00040000
GPS_STATUS_FLAGS_TOW_VALID	0x00080000
GPS_STATUS_FLAGS_GPS1_RTK_POSITION_ENABLED	0x00100000
GPS_STATUS_FLAGS_STATIC_MODE	0x00200000
GPS_STATUS_FLAGS_GPS2_RTK_COMPASS_ENABLED	0x00400000
GPS_STATUS_FLAGS_GPS1_RTK_RAW_GPS_DATA_ERROR	0x00800000
GPS_STATUS_FLAGS_GPS1_RTK_BASE_DATA_MISSING	0x01000000
GPS_STATUS_FLAGS_GPS1_RTK_BASE_POSITION_MOVING	0x02000000
GPS_STATUS_FLAGS_GPS1_RTK_BASE_POSITION_INVALID	0x03000000
GPS_STATUS_FLAGS_GPS1_RTK_BASE_POSITION_MASK	0x03000000
GPS_STATUS_FLAGS_GPS1_RTK_POSITION_VALID	0x04000000
GPS_STATUS_FLAGS_GPS2_RTK_COMPASS_VALID	0x08000000
GPS_STATUS_FLAGS_GPS2_RTK_COMPASS_BASELINE_BAD	0x00002000
GPS_STATUS_FLAGS_GPS_NMEA_DATA	0x00008000
GPS_STATUS_FLAGS_GPS_PPS_TIMESYNC	0x10000000
GPS_STATUS_FLAGS_MASK	0xFFFFFE00

Field	Value
GPS_STATUS_FLAGS_BIT_OFFSET	(int)16

HARDWARE STATUS FLAGS

(eHdwStatusFlags)

Field	Value
HDW_STATUS_MOTION_GYR	0x00000001
HDW_STATUS_MOTION_ACC	0x00000002
HDW_STATUS_MOTION_MASK	0x00000003
HDW_STATUS_IMU_FAULT_REJECT_GYR	0x00000004
HDW_STATUS_IMU_FAULT_REJECT_ACC	0x00000008
HDW_STATUS_IMU_FAULT_REJECT_MASK	0x0000000C
HDW_STATUS_GPS_SATELLITE_RX_VALID	0x00000010
HDW_STATUS_STROBE_IN_EVENT	0x00000020
HDW_STATUS_GPS_TIME_OF_WEEK_VALID	0x00000040
HDW_STATUS_REFERENCE_IMU_RX	0x00000080
HDW_STATUS_SATURATION_GYR	0x00000100
HDW_STATUS_SATURATION_ACC	0x00000200
HDW_STATUS_SATURATION_MAG	0x00000400
HDW_STATUS_SATURATION_BARO	0x00000800
HDW_STATUS_SATURATION_MASK	0x00000F00
HDW_STATUS_SATURATION_OFFSET	8
HDW_STATUS_SYSTEM_RESET_REQUIRED	0x00001000
HDW_STATUS_ERR_GPS_PPS_NOISE	0x00002000
HDW_STATUS_MAG_RECAL_COMPLETE	0x00004000
HDW_STATUS_FLASH_WRITE_PENDING	0x00008000
HDW_STATUS_ERR_COM_TX_LIMITED	0x00010000
HDW_STATUS_ERR_COM_RX_OVERRUN	0x00020000
HDW_STATUS_ERR_NO_GPS_PPS	0x00040000
HDW_STATUS_GPS_PPS_TIMESYNC	0x00080000
HDW_STATUS_COM_PARSE_ERR_COUNT_MASK	0x00F00000
HDW_STATUS_COM_PARSE_ERR_COUNT_OFFSET	20
HDW_STATUS_BIT_RUNNING	0x01000000
HDW_STATUS_BIT_PASSED	0x02000000
HDW_STATUS_BIT_FAILED	0x03000000
HDW_STATUS_BIT_MASK	0x03000000
HDW_STATUS_ERR_TEMPERATURE	0x04000000
HDW_STATUS_SPI_INTERFACE_ENABLED	0x08000000
HDW_STATUS_RESET_CAUSE_MASK	0x70000000
HDW_STATUS_RESET_CAUSE_BACKUP_MODE	0x10000000
HDW_STATUS_RESET_CAUSE_WATCHDOG_FAULT	0x20000000

Field	Value
HDW_STATUS_RESET_CAUSE_SOFT	0x30000000
HDW_STATUS_RESET_CAUSE_HDW	0x40000000
HDW_STATUS_FAULT_SYS_CRITICAL	0x80000000

IMU STATUS

(eImuStatus)

Field	Value
IMU_STATUS_SATURATION_IMU1_GYR	0x00000001
IMU_STATUS_SATURATION_IMU2_GYR	0x00000002
IMU_STATUS_SATURATION_IMU3_GYR	0x00000004
IMU_STATUS_SATURATION_IMU1_ACC	0x00000008
IMU_STATUS_SATURATION_IMU2_ACC	0x00000010
IMU_STATUS_SATURATION_IMU3_ACC	0x00000020
IMU_STATUS_SATURATION_MASK	0x0000003F
IMU_STATUS_MAG_UPDATE	0x00000100
IMU_STATUS_REFERENCE_IMU_PRESENT	0x00000200
IMU_STATUS_RESERVED2	0x00000400
IMU_STATUS_SATURATION_HISTORY	0x00000100
IMU_STATUS_SAMPLE_RATE_FAULT_HISTORY	0x00000200
IMU_STATUS_GYR1_OK	0x00010000
IMU_STATUS_GYR2_OK	0x00020000
IMU_STATUS_GYR3_OK	0x00040000
IMU_STATUS_ACC1_OK	0x00080000
IMU_STATUS_ACC2_OK	0x00100000
IMU_STATUS_ACC3_OK	0x00200000
IMU_STATUS_IMU1_OK	(int)(IMU_STATUS_GYR1_OK IMU_STATUS_ACC1_OK)
IMU_STATUS_IMU2_OK	(int)(IMU_STATUS_GYR2_OK IMU_STATUS_ACC2_OK)
IMU_STATUS_IMU3_OK	(int)(IMU_STATUS_GYR3_OK IMU_STATUS_ACC3_OK)
IMU_STATUS_IMU_OK_MASK	0x003F0000
IMU_STATUS_GYR_FAULT_REJECT	0x01000000
IMU_STATUS_ACC_FAULT_REJECT	0x02000000

INS STATUS FLAGS

(eInsStatusFlags)

Field	Value
INS_STATUS_HDG_ALIGN_COARSE	0x00000001
INS_STATUS_VEL_ALIGN_COARSE	0x00000002
INS_STATUS_POS_ALIGN_COARSE	0x00000004
INS_STATUS_ALIGN_COARSE_MASK	0x00000007
INS_STATUS_WHEEL_AIDING_VEL	0x00000008
INS_STATUS_HDG_ALIGN_FINE	0x00000010
INS_STATUS_VEL_ALIGN_FINE	0x00000020
INS_STATUS_POS_ALIGN_FINE	0x00000040
INS_STATUS_ALIGN_FINE_MASK	0x00000070
INS_STATUS_GPS_AIDING_HEADING	0x00000080
INS_STATUS_GPS_AIDING_POS	0x00000100
INS_STATUS_GPS_UPDATE_IN_SOLUTION	0x00000200
INS_STATUS_EKF_USING_REFERENCE_IMU	0x00000400
INS_STATUS_MAG_AIDING_HEADING	0x00000800
INS_STATUS_NAV_MODE	0x00001000
INS_STATUS_STATIONARY_MODE	0x00002000
INS_STATUS_GPS_AIDING_VEL	0x00004000
INS_STATUS_KINEMATIC_CAL_GOOD	0x00008000
INS_STATUS_SOLUTION_MASK	0x000F0000
INS_STATUS_SOLUTION_OFFSET	16
INS_STATUS_SOLUTION_OFF	0
INS_STATUS_SOLUTION_ALIGNING	1
INS_STATUS_SOLUTION_NAV	3
INS_STATUS_SOLUTION_NAV_HIGH_VARIANCE	4
INS_STATUS_SOLUTION_AHRS	5
INS_STATUS_SOLUTION_AHRS_HIGH_VARIANCE	6
INS_STATUS_SOLUTION_VRS	7
INS_STATUS_SOLUTION_VRS_HIGH_VARIANCE	8
INS_STATUS_RTK_COMPASSING_BASELINE_UNSET	0x00100000
INS_STATUS_RTK_COMPASSING_BASELINE_BAD	0x00200000
INS_STATUS_RTK_COMPASSING_MASK	(INS_STATUS_RTK_COMPASSING_BASELINE_UNSET INS_STATUS_RTK_COMPASSING_BASELINE_BAD)
INS_STATUS_MAG_RECALIBRATING	0x00400000
INS_STATUS_MAG_INTERFERENCE_OR_BAD_CAL	0x00800000
INS_STATUS_GPS_NAV_FIX_MASK	0x03000000
INS_STATUS_GPS_NAV_FIX_OFFSET	24

Field	Value
INS_STATUS_RTK_COMPASSING_VALID	0x04000000
INS_STATUS_RTK_RAW_GPS_DATA_ERROR	0x08000000
INS_STATUS_RTK_ERR_BASE_DATA_MISSING	0x10000000
INS_STATUS_RTK_ERR_BASE_POSITION_MOVING	0x20000000
INS_STATUS_RTK_ERR_BASE_POSITION_INVALID	0x30000000
INS_STATUS_RTK_ERR_BASE_MASK	0x30000000
INS_STATUS_RTK_ERROR_MASK	(INS_STATUS_RTK_RAW_GPS_DATA_ERROR INS_STATUS_RTK_ERR_BASE_MASK)
INS_STATUS_RTOS_TASK_PERIOD_OVERRUN	0x40000000
INS_STATUS_GENERAL_FAULT	0x80000000

MAGNETOMETER RECALIBRATION MODE

(eMagCalState)

Field	Value
MAG_CAL_STATE_DO_NOTHING	(int)0
MAG_CAL_STATE_MULTI_AXIS	(int)1
MAG_CAL_STATE_SINGLE_AXIS	(int)2
MAG_CAL_STATE_ABORT	(int)101
MAG_CAL_STATE_RECAL_RUNNING	(int)200
MAG_CAL_STATE_RECAL_COMPLETE	(int)201

RTK CONFIGURATION

(eRTKConfigBits)

Field	Value
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING	0x00000001
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_EXTERNAL	0x00000002
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_F9P	0x00000004
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING	0x00000008
RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING_EXTERNAL)
RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING_F9P)
RTK_CFG_BITS_ROVER_MODE_MASK	0x0000000F
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER0	0x00000010
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER1	0x00000020
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_SER2	0x00000040
RTK_CFG_BITS_BASE_OUTPUT_GPS1_UBLOX_USB	0x00000080
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER0	0x00000100
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER1	0x00000200
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_SER2	0x00000400
RTK_CFG_BITS_BASE_OUTPUT_GPS1_RTCM3_USB	0x00000800
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER0	0x00001000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER1	0x00002000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_SER2	0x00004000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_UBLOX_USB	0x00008000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER0	0x00010000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER1	0x00020000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_SER2	0x00040000
RTK_CFG_BITS_BASE_OUTPUT_GPS2_RTCM3_USB	0x00080000
RTK_CFG_BITS_BASE_POS_MOVING	0x00100000
RTK_CFG_BITS_RESERVED1	0x00200000
RTK_CFG_BITS_RTK_BASE_IS_IDENTICAL_TO_ROVER	0x00400000
RTK_CFG_BITS_GPS_PORT_PASS_THROUGH	0x00800000
RTK_CFG_BITS_ROVER_MODE_ONBOARD_MASK	(RTK_CFG_BITS_ROVER_MODE_RTK_POSITIONING RTK_CFG_BITS_ROVER_MODE_RTK_COMPASSING)
RTK_CFG_BITS_ALL_MODES_MASK	(RTK_CFG_BITS_ROVER_MODE_MASK RTK_CFG_BITS_BASE_MODE)

SYSTEM CONFIGURATION

(eSysConfigBits)

Field	Value
UNUSED1	0x00000001
SYS_CFG_BITS_ENABLE_MAG_CONTINUOUS_CAL	0x00000002
SYS_CFG_BITS_AUTO_MAG_RECAL	0x00000004
SYS_CFG_BITS_DISABLE_MAG_DECL_ESTIMATION	0x00000008
SYS_CFG_BITS_DISABLE_LEDS	0x00000010
Magnetometer	multi-axis
SYS_CFG_BITS_MAG_RECAL_MODE_MASK	0x00000700
SYS_CFG_BITS_MAG_RECAL_MODE_OFFSET	8
SYS_CFG_BITS_MAG_ENABLE_WMM_DECLINATION	0x00000800
SYS_CFG_BITS_DISABLE_MAGNETOMETER_FUSION	0x00001000
SYS_CFG_BITS_DISABLE_BAROMETER_FUSION	0x00002000
SYS_CFG_BITS_DISABLE_GPS1_FUSION	0x00004000
SYS_CFG_BITS_DISABLE_GPS2_FUSION	0x00008000
SYS_CFG_BITS_DISABLE_AUTO_ZERO_VELOCITY_UPDATES	0x00010000
SYS_CFG_BITS_DISABLE_AUTO_ZERO_ANGULAR_RATE_UPDATES	0x00020000
SYS_CFG_BITS_DISABLE_INS_EKF	0x00040000
SYS_CFG_BITS_DISABLE_AUTO_BIT_ON_STARTUP	0x00080000
SYS_CFG_BITS_DISABLE_WHEEL_ENCODER_FUSION	0x00100000
SYS_CFG_BITS_UNUSED3	0x00200000
SYS_CFG_BITS_BOR_LEVEL_0	0x0
SYS_CFG_BITS_BOR_LEVEL_1	0x1
SYS_CFG_BITS_BOR_LEVEL_2	0x2
SYS_CFG_BITS_BOR_LEVEL_3	0x3
SYS_CFG_BITS_BOR_THRESHOLD_MASK	0x00C00000
SYS_CFG_BITS_BOR_THRESHOLD_OFFSET	22
SYS_CFG_USE_REFERENCE_IMU_IN_EKF	0x01000000
SYS_CFG_EKF_REF_POINT_STATIONARY_ON_STROBE_INPUT	0x02000000

7.3 Inertial Sense Binary (ISB) Protocol

The Inertial Sense binary protocol provides the most efficient way to communicate with the μ INS, μ AHRS, and μ IMU because it preserved the native floating point and integer binary format used in computers. Binary protocol is not human readable like [NMEA Protocol](#). Binary protocol uses [Data Set \(DID\)](#) C structures defined in SDK/src/data_sets.h of the InertialSense SDK.

7.3.1 Communication

Writing to and reading from InertialSense products is done using "Set" and "Get" commands. The following helper function `portWrite()` which assists with writing data to the serial port is used throughout this document.

```
static int portWrite(int port, const unsigned char* buf, int len)
{
    return serialPortWrite(&serialPort, buf, len);
}
```

Setting Data

The `is_comm_set_data()` function will encode a message used to set data or configurations.

```
// Set INS output Euler rotation in radians to 90 degrees roll for mounting
void setInsOutputRotation()
{
    float rotation[3] = { 90.0f*C_DEG2RAD_F, 0.0f, 0.0f };
    is_comm_set_data(portWrite, 0, comm, DID_FLASH_CONFIG, sizeof(float) * 3, offsetof(nvm_flash_cfg_t, insRotation), rotation);
}
```

Getting Data

Data broadcasting or streaming is enabled by using the **Realtime Message Controller (RMC)** or the get data command.

GET DATA COMMAND

The `is_comm_get_data()` function will encode a `PKT_TYPE_GET_DATA` message that enables broadcast of a given message at a multiple of the [Data Source Update Rates](#). Set the data rate (period multiple) to zero disable message broadcast and pull a single packet of data. Set the data size and offset to zero to request the entire data set.

```
// Ask for INS message w/ update 40ms period (4ms source period x 10). Set data rate to zero to disable broadcast and pull a single packet.
is_comm_get_data(portWrite, 0, comm, DID_INS_1, 0, 0, 10);
```

DATA SOURCE UPDATE RATES

DID	Default Update Rate (Period)
DID_INS_[1-4]	(7ms default) Configured with DID_FLASH_CONFIG.startupNavDtMs
DID_IMU, DID_PIMU*	(14ms default) Configured with DID_FLASH_CONFIG.startupImuDtMs
DID_BAROMETER	~20ms
DID_MAGNETOMETER_[1-2]	~20ms
DID_GPS[1-2]_[X] (Any DID beginning with DID_GPS)	(200ms default) Configured with DID_FLASH_CONFIG.startupGPSDtMs
All other DIDs	1ms

*DID_PIMU integration period (dt) and output data rate are the same as DID_FLASH_CONFIG.startupNavDtMs and cannot be output at any other rate. If a different output data rate is desired, DID_IMU which is derived from DID_PIMU can be used instead.

REALTIME MESSAGE CONTROLLER (RMC)

The RMC is used to enable message broadcasting and provides updates from onboard data as soon as it becomes available with minimal latency. All RMC messages can be enabled using the [Get Data Command](#), which is the preferred method, or by directly setting the RMC bits. The RMC bits are listed below. Message data rates are listed in the [Data Source Update Rates](#) table.

RMC Message

RMC_BITS_INS[1-4]

RMC_BITS_DUAL_IMU, RMC_BITS_PIMU

RMC_BITS_BAROMETER

RMC_BITS_MAGNETOMETER[1-2]

RMC_BITS_GPS[1-2]_NAV

RMC_BITS_GPS_RTK_NAV, RMC_BITS_GPS_RTK_MISC

RMC_BITS_STROBE_IN_TIME

The following is an example of how to use the RMC. The `rmc.options` field controls whether RMC commands are applied to other serial ports. `rmc.options = 0` will apply the command to the current serial port.

```
rmc_t rmc;
// Enable broadcasts of DID_INS_1 and DID_GPS_NAV
rmc.bits = RMC_BITS_INS1 | RMC_BITS_GPS1_POS;
// Remember configuration following reboot for automatic data streaming.
rmc.options = RMC_OPTIONS_PERSISTENT;

is_comm_set_data(portWrite, 0, comm, DID_RMC, 0, 0, &rmc);
```

The update rate of the EKF is set by `DID_FLASH_CONFIG.startupNavDtMs` (reboot is required to apply the change). Independently, the `DID_INS_x` broadcast period multiple can be used to set the output data rate down to 1ms.

PERSISTENT MESSAGES

The *persistent messages* option saves the current data stream configuration to flash memory for use following reboot, eliminating the need to re-enable messages following a reset or power cycle.

- **To save persistent messages** - (to flash memory), bitwise OR `RMC_OPTIONS_PERSISTENT (0x200)` with the RMC option field or set `DID_CONFIG.system = 0x00000001` and `DID_CONFIG.system = 0xFFFFFFFF`. See the [save persistent messages example](#) in the Binary Communications example project.
- **To disable persistent messages** - a [stop all broadcasts packet](#) followed by a *save persistent messages* command.

[NMEA persistent messages](#) are also available.

Enabling Persistent Messages - EvalTool

- Enable the desired messages in the EvalTool "Data Sets" tab.
- Press the "Save Persistent" button in the EvalTool "Data Logs" tab to store the current message configuration to flash memory for use following reboot.
- Reset the system and verify the messages are automatically streaming. You can use the EvalTool->Data Logs dialog to view the streaming messages.

To disable all persistent messages using the EvalTool, click the "Stop Streaming" button and then "Save Persistent" button.

Enabling Persistent Messages - CLTool

Persistent messages are enabled using the CLTool by including the `-persistent` option along with the options for the desired messages in the command line.

```
cltool -c /dev/ttyS3 -persistent -msgINS2 -msgGPS
```

EXAMPLE PROJECTS

Examples on how to use the Inertial Sense SDK for binary communications are found in the [Binary Communications Example Project](#) and [cltool project](#). NMEA communications examples are found in the [NMEA Example Project](#).

Parsing Data

The [ISComm](#) library in the [InertialSenseSDK](#) provides a communications parser that can parse InertialSense binary protocol as well as other protocols.

ONE BYTE (SIMPLE METHOD)

The following parser code is simpler to implement. This method uses the `is_comm_parse_byte()` function to parse one byte at a time of a data stream. The return value is a non-zero `protocol_type_t` when valid data is found.

```
uint8_t c;
protocol_type_t ptype;
// Read from serial buffer until empty
while (serialPortReadChar(&s_serialPort, &c) > 0)
{
    // timeMs = current_timeMs();
    switch (is_comm_parse_byte(&comm, inByte))
    {
        case _PTYPE_INERTIAL_SENSE_DATA:
            break;
        case _PTYPE_UBLOX:
            break;
        case _PTYPE_RTCM3:
            break;
        case _PTYPE_NMEA:
            break;
    }
}
```

SET OF BYTES (FAST METHOD)

The following parser code uses less processor time to parse data by copying multiple bytes at a time. This method uses `is_comm_free()` and `is_comm_parse()` along with a serial port read or buffer copy. The return value is a non-zero `protocol_type_t` when valid data is found.

```
// Read a set of bytes (fast method)
protocol_type_t ptype;

// Get available size of comm buffer. is_comm_free() modifies comm->rxBuf pointers, call it before using comm->rxBuf.tail.
int n = is_comm_free(comm);


// Read data directly into comm buffer
if ((n = serialPortRead(comm->rxBuf.tail, n))
{
    // Update comm buffer tail pointer
    comm->rxBuf.tail += n;

    // Search comm buffer for valid packets
    while ((ptype = is_comm_parse(comm)) != _PTYPE_NONE)
    {
        switch (ptype)
        {
            case _PTYPE_INERTIAL_SENSE_DATA:
            case _PTYPE_INERTIAL_SENSE_CMD:
                break;
            case _PTYPE_UBLOX:
                break;
            case _PTYPE_RTCM3:
                break;
            case _PTYPE_NMEA:
                break;
        }
    }
}
```

7.3.2 ISB Packet Overview

The IMX and GPX communicate using the Inertial Sense Binary (ISB) protocol. This section details the ISB protocol packet structure specific for protocol 2.x (software releases 2.x). Refer to the [release 1.x ISB protocol](#) document for a description of protocol 1.x (software releases 1.x). The [Inertial-Sense-SDK ISComm](#) provides functions to encode and decode ISB packets.

ISB Packet



The ISB packet structure is defined in the typedef `packet_t` found in [ISComm.h](#).

HEADER TYPE AND FLAGS

The packet type and flags are found in the byte at offset 2 in the ISB packet. The **Type** is the lower nibble and the **Flags** are the upper nibble. The packet and is defined in [ISComm.h](#).

```
typedef enum
{
    PKT_TYPE_INVALID           = 0, // Invalid packet id
    PKT_TYPE_ACK              = 1, // (ACK) received valid packet
    PKT_TYPE_NACK             = 2, // (NACK) received invalid packet
    PKT_TYPE_GET_DATA         = 3, // Request for data to be broadcast, response is PKT_TYPE_DATA. See data structures for list of possible
    broadcast data.
    PKT_TYPE_DATA             = 4, // Data sent in response to PKT_TYPE_GET_DATA (no PKT_TYPE_ACK is sent)
    PKT_TYPE_SET_DATA         = 5, // Data sent, such as configuration options. PKT_TYPE_ACK is sent in response.
    PKT_TYPE_STOP_BROADCASTS_ALL_PORTS = 6, // Stop all data broadcasts on all ports. Responds with an ACK
    PKT_TYPE_STOP_DID_BROADCAST = 7, // Stop a specific broadcast
    PKT_TYPE_STOP_BROADCASTS_CURRENT_PORT = 8, // Stop all data broadcasts on current port. Responds with an ACK
    PKT_TYPE_COUNT            = 9, // The number of packet identifiers, keep this at the end!
    PKT_TYPE_MAX_COUNT        = 16, // The maximum count of packet identifiers, 0x1F (PACKET_INFO_ID_MASK)
    PKT_TYPE_MASK              = 0x0F, // ISB packet type bitmask

    ISB_FLAGS_MASK            = 0xF0, // ISB packet flags bitmask (4 bits upper nibble)
    ISB_FLAGS_EXTENDED_PAYLOAD = 0x10, // Payload is larger than 2048 bytes and extends into next packet.
    ISB_FLAGS_PAYLOAD_W_OFFSET = 0x20, // The first two bytes of the payload are the byte offset of the payload data into the data set.
} eISBPacketFlags;
```

HEADER DID

The data ID (DID) values are defined at the top of [data_sets.h](#) and identify which data set is requested or contained in the ISB packet.

HEADER PAYLOAD SIZE

The ISB packet payload size is a uint16 that will


FOOTER CHECKSUM

The ISB packet footer contains a Fletcher-16 (16-bit integer). The following algorithm is used for this checksum and is found in [ISComm.h](#).

```
uint16_t is_comm_fletcher16(uint16_t cksum_init, const void* data, uint32_t size)
{
    checksum16_u cksum;
    cksum.ck = cksum_init;
    for (uint32_t i=0; i<size; i++)
    {
        cksum.a += ((uint8_t*)data)[i];
        cksum.b += cksum.a;
    }
    return cksum.ck;
}
```


The ISB packet footer checksum is computed using the Fletcher-16 algorithm starting with an initial value of zero and sequencing over the entire packet (excluding the two footer checksum bytes).

ISB Packet with Data Offset




*The first two bytes of the payload may be a uint16 offset for the data offset in the target data set when the `ISB_FLAGS_PAYLOAD_W_OFFSET` flag is set in the header flags.

ISB Packet with No Payload



Packet types `PKT_TYPE_STOP_BROADCASTS_ALL_PORTS`, `PKT_TYPE_STOP_DID_BROADCAST`, `PKT_TYPE_STOP_BROADCASTS_CURRENT_PORT` have payload size zero and no payload.

ISB Get Data Packet



The **Get Data** packet of type `PKT_TYPE_GET_DATA` is used to query specific data according to data set ID, size, offset, and streaming period multiple. The payload size is 8. Setting the payload period to zero will result in a single response and a continuous stream of data for a non-zero period.

7.3.3 Stop Broadcasts Packets

 **Note**

The `NEMA $STPB` stop broadcasts command is recommended as the protocol version-independent method for disabling data streaming.

Two *stop all broadcasts* packets are special packet types that will disable all binary and NMEA data streams. The following functions calls are provided in the SDK to generate the stop all broadcasts packets.

All Ports

```
is_comm_stop_broadcasts_all_ports(portWrite, 0, &comm);
```

The hexadecimal string to stop all broadcasts on all ports is:

```
0xef 0x49 0x06 0x00 0x00 0x00 0x3e 0x1f
```

Current Port Only

```
is_comm_stop_broadcasts_current_port(portWrite, 0, &comm);
```

The hexadecimal string to stop all broadcasts on the current port is:

```
0xef 0x49 0x08 0x00 0x00 0x00 0x40 0x27
```

7.3.4 RMC Presets

RMC Preset Stream PPD

The hexadecimal string for the RMC Preset enable PPD is:

```
0xef 0x49 0x05 0x09 0x0c 0x00 0xe2 0x3c 0x35 0x01 0x90 0x00 0x00 0xc0 0x00 0x01 0x00 0x00 0xf7 0xb0
```


7.4 NMEA 0183 (ASCII) Protocol

For simple use, the Inertial Sense device supports a human-readable NMEA communications protocol based on NMEA 0183. The NMEA protocol is human readable from in a command line terminal but is less optimal than the [binary protocol](#) in terms of message length for the same amount of data.

7.4.1 Communications Examples

The [NMEA Communications Example Project](#) demonstrates how to implement the protocol.

7.4.2 Packet Structure

The Inertial Sense NMEA protocol follows the standard [NMEA 0183](#) message structure:

- 1 byte - Start packet, \$ (0x24)
- n bytes - packet identifier
- 1 byte - comma (0x2C)
- n bytes - comma separated list of data, can include decimals and text
- 1 byte - checksum marker, * (0x2A)
- 2 bytes - checksum in hex format (i.e. f5 or 0a), 0 padded and lowercase
- 2 bytes - End packet, \r\n (0x0D, 0x0A)

The packet checksum is an 8 bit integer and is calculated by calculating the exclusive OR of all bytes in between and not including the \$ and * bytes. The packet checksum byte is converted to a 2 byte NMEA hex code, and left padded with 0 if necessary to ensure that it is always 2 bytes. The checksum is always lowercase hexadecimal characters. See [NMEA 0183](#) message structure for more details. The NMEA string checksum is automatically computed and appended to string when using the InertialSense SDK [serialPortWriteAscii function](#) or can be generated using an online checksum calculator. For example: [MTK NMEA checksum calculator](#)

7.4.3 Persistent Messages

The *persistent messages* option saves the current data stream configuration to flash memory for use following reboot, eliminating the need to re-enable messages following a reset or power cycle.

- **To save current NMEA persistent messages** - send the \$PERS command.
- **To disable persistent messages** - send STPB[#stpb) followed by [PERS.

[Binary persistent messages](#) are also available.

Enabling Persistent Messages - EvalTool

To enable persistent NMEA messages using the EvalTool:

- Enable the desired NMEA messages in the EvalTool "Data Sets" tab. Select DID_NMEA_BCAST_PERIOD in the DID menu and set the desired NMEA messages period to a non-zero value.
- Press the "Save Persistent" button in the EvalTool "Data Logs" tab to store the current message configuration to flash memory.
- Reset the IMX and verify the messages are automatically streaming. You can use a generic serial port program like putty or the EvalTool->Data Logs->Data Log->Messages dialog to view the NMEA messages.

To disable all persistent messages using the EvalTool, click the "Stop Streaming" button and then "Save Persistent" button.

7.4.4 NMEA Input Messages

The following NMEA messages can be received by the IMX.

Message	Description
<code>\$ASCE*14\r\n</code>	Query the broadcast rate of NMEA output messages.
<code>ASCE</code>	Set the broadcast period of selected NMEA output messages.
<code>\$INFO*0E\r\n</code>	Query device information.
<code>\$SRST*06\r\n</code>	Software reset.
<code>\$PERS*14\r\n</code>	Save persistent messages to flash.
<code>\$STPB*15\r\n</code>	Stop broadcast of all messages (NMEA and binary) on all ports.
<code>\$STPC*14\r\n</code>	Stop broadcast of all messages (NMEA and binary) on current port.

ASCE

Enable NMEA message output streaming by specifying the [NMEA message identifier or ID](#) and broadcast period. The period is the multiple of the [data source period](#) (i.e. a GNSS message with period multiple of 2 and data source period of 200 ms (5 Hz) will broadcast every 400 ms). "xx" is the two-character checksum. A period of 0 will disable message streaming. The broadcast period for each message is configurable as a period multiple of the [Data Source Update Rates](#). Up to 20 different NMEA messages can be enabled by repeating the message ID and period sequence within an ASCE message.

```
$ASCE, OPTIONS, (ID, PERIOD)*xx\r\n
```

The following examples will enable the same NMEA message output:

```
$ASCE, 0, PPIMU, 1, PINS2, 10, GNGGA, 1*26\r\n
$ASCE, 0, 2, 1, 5, 10, 7, 1*39\r\n
```

Index	Field	Description
1	OPTIONS	Port selection. Combine by adding options together: 0=current, 1=ser0, 2=ser1, 4=ser2, 8=USB, 512=persistent (remember after reset)
<i>Start of repeated group (1...20 times)</i>		
2+n*2	ID	Either 1.) message identifier string (i.e. PPIMU, PINS1, GNGGA) excluding packet start character \$ or 2.) message ID (eNmeaAsciiMsgId) of the NMEA message to be streamed. See the message ID in the NMEA output messages table.
3+n*2	PERIOD	Broadcast period multiple for specified message. Zero disables streaming.
<i>End of repeated group (1...20 times)</i>		

EXAMPLE MESSAGES

The following examples NMEA messages enable IMX data streaming output. The data period is 1, full [data source rates](#), for those that do not specify the output rate.

Message	Data (Output Rate)**
\$ASCE,0,6,1,7,1,8,1,10,1,14,1*04\r\n	GGA, GLL, GSA, ZDA, GSV (all at 5Hz)
\$ASCE,0,5,2,2,1,7,1*0A\r\n	PINS2 (31.25 Hz), PPIMU (62.5Hz), GGA (5Hz)
\$ASCE,0,0,1*09\r\n	PIMU
\$ASCE,0,1,1*08\r\n	PPIMU
\$ASCE,0,2,1*0B\r\n	PRIMU
\$ASCE,0,3,1*0A\r\n	PINS1
\$ASCE,0,4,1*0D\r\n	PINS2
\$ASCE,0,5,1*0C\r\n	PGPSP
\$ASCE,0,6,1*0F\r\n	GGA
\$ASCE,0,7,1*0E\r\n	GLL
\$ASCE,0,8,1*01\r\n	GSA
\$ASCE,0,9,1*00\r\n	RMC
\$ASCE,0,10,1*38\r\n	ZDA
\$ASCE,0,11,1*39\r\n	PASHR
\$ASCE,0,12,1*3A\r\n	PSTRB
\$ASCE,0,13,1*3B\r\n	INFO
\$ASCE,0,14,1*3C\r\n	GSV
\$ASCE,0,15,1*3D\r\n	VTG

** These rates assume the default settings for [data source rates](#).

PERS

Send this command to save current *persistent messages* to flash memory for use following reboot. This eliminates the need to re-enable messages following a reset or power cycle. In order to disable persistent messages, all messages must be disabled and then the 'save persistent messages' command should be sent.

```
$PERS*14\r\n
```

STPB

Stop all broadcasts (both binary and NMEA) on all ports by sending the following packet:

```
$STPB*15\r\n
```

The hexadecimal equivalent is:

```
24 53 54 50 42 2A 31 35 0D 0A
```

STPC

Stop all broadcasts (both binary and NMEA) on the current port by sending the following packet:

```
$STPC*14\r\n
```

The hexadecimal equivalent is:

```
24 53 54 50 43 2A 31 34 0D 0A
```

7.4.5 NMEA Output Messages

The following NMEA messages can be sent by the IMX. The message ID (`eNmeaAsciiMsgId`) is used with the `$ASCE` message to enable message streaming.

Identifier	ID	Description
ASCB		Broadcast period of NMEA output messages.
PIMU	1	IMU data (3-axis gyros and accelerometers) in the body frame.
PPIMU	2	Preintegrated IMU: delta theta (rad) and delta velocity (m/s).
PRIMU	3	Raw IMU data (3-axis gyros and accelerometers) in the body frame.
PINS1	4	INS output: euler rotation w/ respect to NED, NED position from reference LLA.
PINS2	5	INS output: quaternion rotation w/ respect to NED, ellipsoid altitude.
PGPSP	6	GPS position data.
GGA	7	Standard NMEA GGA GPS 3D location, fix, and accuracy.
GLL	8	Standard NMEA GLL GPS 2D location and time.
GSA	9	Standard NMEA GSA GPS DOP and active satellites.
RMC	10	Standard NMEA RMC Recommended minimum specific GPS/Transit data.
ZDA	11	Standard NMEA ZDA UTC Time/Date message.
PASHR	12	Standard NMEA PASHR (euler) message.
PSTRB	13	Strobe event input time.
INFO	14	Device information.
GSV	15	Standard NMEA GSV satellite info (all active constellations sent with corresponding talker IDs).
VTG	16	Standard NMEA VTG track made good and speed over ground.

The field codes used in the message descriptions are: lf = double, f = float, d = int.

PIMU

IMU sensor data (3-axis gyros and accelerometers) in the body frame.

```
SPIMU, l f, f, f, f, f, f, f, f*xx\r\n
 1 2 3 4 5 6 7
```

Index	Field	Units	Description
1	time	sec	Time since system power up
3	IMU pqr[0]	rad/sec	IMU angular rate gyro - X
2	IMU pqr[1]	rad/sec	IMU angular rate gyro - Y
4	IMU pqr[2]	rad/sec	IMU angular rate gyro - Z
5	IMU acc[0]	m/s ²	IMU linear acceleration - X
6	IMU acc[1]	m/s ²	IMU linear acceleration - Y
7	IMU acc[2]	m/s ²	IMU linear acceleration - Z

PPIMU

Preintegrated inertial measurement unit (IMU) sensor data, delta theta in radians and delta velocity in m/s in the body frame. Also known as coning and sculling integrals.

```
SPPIMU, l f, f, f, f, f, f, f, f, f*xx\r\n
 1 2 3 4 5 6 7 8
```

Index	Field	Units	Description
1	time	sec	Time since system power up
2	theta[0]	rad	IMU delta theta integral - X
3	theta[1]	rad	IMU delta theta integral - Y
4	theta[2]	rad	IMU delta theta integral - Z
8	vel[0]	m/s	IMU delta velocity integral - X
9	vel[1]	m/s	IMU delta velocity integral - Y
10	vel[2]	m/s	IMU delta velocity integral - Z
14	dt	s	Integration period for delta theta vel

PRIMU

Raw IMU sensor data (3-axis gyros and accelerometers) in the body frame (up to 1KHz). Use this IMU data for output data rates faster than DID_FLASH_CONFIG.startupNavDtMs. Otherwise we recommend use of PIMU or PPIMU as they are oversampled and contain less noise. 0 to disable.

```
SPRIMU, lf, f, f, f, f, f, f, f*xx\r\n
 1 2 3 4 5 6 7
```

Index	Field	Units	Description
1	time	sec	Time since system power up
3	Raw IMU pqr[0]	rad/sec	Raw IMU angular rate gyro - X
2	Raw IMU pqr[1]	rad/sec	Raw IMU angular rate gyro - Y
4	Raw IMU pqr[2]	rad/sec	Raw IMU angular rate gyro - Z
5	Raw IMU acc[0]	m/s ²	Raw IMU linear acceleration - X
6	Raw IMU acc[1]	m/s ²	Raw IMU linear acceleration - Y
7	Raw IMU acc[2]	m/s ²	Raw IMU linear acceleration - Z

PINS1

INS output with Euler angles and NED offset from the reference LLA.

```
SPINS1, lf, d, d, d, f, f, f, f, f, lf, lf, f, f, f*xx\r\n
 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
```

Index	Field	Units	Description
1	timeOfWeek	sec	Seconds since Sunday morning in GMT
2	GPS week	weeks	Number of weeks since January 1 st of 1980 in GMT
3	insStatus		INS Status Flags
4	hdwStatus		Hardware Status Flags
5	theta[0]	rad	Euler angle - roll
6	theta[1]	rad	Euler angle - pitch
7	theta[2]	rad	Euler angle - yaw
8	UVW[0]	m/s	Velocity in body frame - X
9	UVW[1]	m/s	Velocity in body frame - Y
10	UVW[2]	m/s	Velocity in body frame - Z
11	Latitude	deg	WGS84 Latitude
12	Longitude	deg	WGS84 Longitude
13	HAE Altitude	m	Height above ellipsoid (vertical elevation)
14	NED[0]	m	Offset from reference LLA - North
15	NED[1]	m	Offset from reference LLA - East
16	NED[2]	m	Offset from reference LLA - Down

PINS2

INS output with quaternion attitude.

```
SPINS2,lf,d,d,d,f,f,f,f,f,f,f,f,lf,lf,lf*xx\r\n
1 2 3 4 5 6 7 8 9 0 1 2 3 4
```

Index	Field	Units	Description
1	timeOfWeek	sec	Seconds since Sunday morning in GMT
2	GPS week	weeks	Number of weeks since January 1 st of 1980 in GMT
3	insStatus		INS Status Flags
4	hdwStatus		Hardware Status Flags
5	qn2b[0]		Quaternion rotation (NED to body) - W
6	qn2b[1]		Quaternion rotation (NED to body) - X
7	qn2b[2]		Quaternion rotation (NED to body) - Y
8	qn2b[3]		Quaternion rotation (NED to body) - Z
9	UVW[0]	m/s	Velocity in body frame - X
10	UVW[1]	m/s	Velocity in body frame - Y
11	UVW[2]	m/s	Velocity in body frame - Z
12	Latitude	deg	WGS84 Latitude
13	Longitude	deg	WGS84 Longitude
14	HAE altitude	m	Height above ellipsoid (vertical elevation)

PGPSP

GPS navigation data.

```
SPGPSP,d,d,d,lf,lf,lf,f,f,f,f,f,f,f,f,f,f*xx\r\n
1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
```

```
SPGPSP,337272200,2031,1075643160,40.33057800,-111.72581630,1406.39,1425.18,0.95,0.37,0.55,-0.02,0.02,-0.03,0.17,39.5,337182.4521*4d\r\n
```

Index	Field	Units	Description
1	timeOfWeekMs	ms	GPS time of week in milliseconds since Sunday morning in GMT
2	GPS week	weeks	GPS number of weeks since January 1 st of 1980 in GMT
3	status		(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags
4	Latitude	deg	WGS84 Latitude
5	Longitude	deg	WGS84 Longitude
6	HAE altitude	m	Height above WGS84 ellipsoid
7	MSL altitude	m	Elevation above mean sea level
8	pDOP	m	Position dilution of precision
9	hAcc	m	Horizontal accuracy
10	vAcc	m	Vertical accuracy
11	Velocity X	m/s	ECEF X velocity
12	Velocity Y	m/s	ECEF Y velocity
13	Velocity Z	m/s	ECEF Z velocity
14	sAcc	m/s	Speed accuracy
15	cnoMean	dBHz	Average of all satellite carrier to noise ratios (signal strengths) that non-zero
16	towOffset	s	Time sync offset between local time since boot up to GPS time of week in seconds. Add this to IMU and sensor time to get GPS time of week in seconds.
17	leapS	s	GPS leap second (GPS-UTC) offset. Receiver's best knowledge of the leap seconds offset from UTC to GPS time. Subtract from GPS time of week to get UTC time of week.

GGA

NMEA GPS fix, 3D location and accuracy data.


```

$GPGGA,204153.200,4003.34331,N,11139.51872,W,1,25,0.93,1433.997,M,18.82,M,,*6d\r\n
  1       2 3       4 5 6 7 8       9 0       1 2 3 4

```

Index	Field	Units	Description	Example
1	HHMMSS.sss		UTC time (fix taken at 20:41:53.200 UTC)	204153.200
2,3	Latitude	deg,min	WGS84 latitude (DDmm.mmmmm,N)	4003.34331,N
4,5	Longitude	deg,min	WGS84 longitude (DDDmm.mmmmm,E)	11139.51872,W
6	Fix quality		0 = invalid, 1 = GPS fix (SPS), 2 = DGPS fix, 3 = PPS fix, 4 = RTK Fix, 5 = RTK Float, 6 = estimated (dead reckoning), 7 = Manual input mode, 8 = Simulation mode	1
7	# Satellites		Number of satellites in use	15
8	hDop	m	Horizontal dilution of precision	0.9
9,10	MSL_altitude	m	Elevation above mean sea level (MSL)	545.4,M
11,12	Undulation	m	Undulation of geoid. Height of the geoid above the WGS84 ellipsoid.	46.9,M
13	empty	s	Time since last DGPS update	
14	empty		DGPS station ID number	

GLL

NMEA geographic position, latitude / longitude and time.

```

$GPGLL,4916.45123,N,12311.12324,W,225444.800,A*33\r\n
  1 2       3 4       5 6

```

Index	Field	Units	Description	Example
1,2	Latitude	deg,min	WGS84 latitude (DDmm.mmmmm,N)	4916.45123,N
3,4	Longitude	deg,min	WGS84 longitude (DDDmm.mmmmm,E)	12311.12324,W
5	HHMMSS.sss		UTC time (fix taken at 22:54:44.8 UTC)	225444.800
6	Valid		Data valid (A=active, V=void)	A

GSA

NMEA GPS DOP and active satellites.

```
$GPGSA,A,3,04,05,,09,12,,,24,,,,,2.5,1.3,2.1*39\r\n
 1 2 3 4 ...          15 16 17
```

Index	Field	Units	Description	Example
1			Auto selection of 2D or 3D fix (M = manual)	A
2	Fix quality		Fix quality (1 = none, 2 = 2D, 3 = 3D)	3
3-14	Sat ID		Satellite ID (PRNs)	04,05,,09,12,,,24,,,,
15	pDop	m	Dilution of precision	2.5
16	hDop	m	Horizontal dilution of precision	1.3
17	vDop	m	Vertical dilution of precision	2.1

RMC

NMEA GPS recommended minimum specific GPS/Transit data.

```
eg1. $GPRMC,081836,A,3751.65,S,14507.36,E,000.0,360.0,130998,011.3,E*62\r\n
eg2. $GPRMC,225446,A,4916.45,N,12311.12,W,000.5,054.7,191194,020.3,E*68\r\n
```

```
225446      Time of fix 22:54:46 UTC
A          Navigation receiver warning A = OK, V = warning
4916.45,N  Latitude 49 deg. 16.45 min North
12311.12,W Longitude 123 deg. 11.12 min West
000.5      Speed over ground, Knots
054.7      Course Made Good, True
191194     Date of fix 19 November 1994
020.3,E    Magnetic variation 20.3 deg East
*68        mandatory checksum
```

```
eg3. $GPRMC,220516,A,5133.82,N,00042.24,W,173.8,231.8,130694,004.2,W*70\r\n
 1 2 3 4 5 6 7 8 9 10 11 12
```

```
1 220516      Time Stamp
2 A          validity - A-ok, V-invalid
3 5133.82    current Latitude
4 N          North/South
5 00042.24  current Longitude
6 W          East/West
7 173.8      Speed in knots
8 231.8      True course
9 130694     Date Stamp
10 004.2     Variation
11 W         East/West
12 *70      checksum
```

```
eg4. $GPRMC,hhmmss.ss,A,llll.ll,a,yyyyy.yy,a,x.x,x.x,ddmmyy,x.x,a*hh\r\n
1 = UTC of position fix
2 = Data status (V=navigation receiver warning)
3 = Latitude of fix
4 = N or S
5 = Longitude of fix
6 = E or W
7 = Speed over ground in knots
8 = Track made good in degrees True
9 = UT date
10 = Magnetic variation degrees (Easterly var. subtracts from true course)
11 = E or W
12 = Checksum
```

VTG

NMEA GPS track made good and speed over ground.

```
eg1. $GPVTG,140.88,T,,M,8.04,N,14.89,K,D*05\r\n
```

```
0 Message ID $GPVTG
1 Track made good (degrees true)
2 T: track made good is relative to true north
3 Track made good (degrees magnetic)
4 M: track made good is relative to magnetic north
5 Speed, in knots
6 N: speed is measured in knots
7 Speed over ground in kilometers/hour (kph)
8 K: speed over ground is measured in kph
9 Mode indicator:
```

```

A: Autonomous mode
D: Differential mode
E: Estimated (dead reckoning) mode
M: Manual Input mode
S: Simulator mode
N: Data not valid
10 The checksum data, always begins with *

```

ZDA

NMEA GPS UTC Time and Date specification.

```

$GPZDA,213301.200,31,08,2023,00,00*41\r\n
 1  2  3  4  5  6

```

Index	Field	Units	Description	Example
1	HHMMSS.sss		UTC Time	213301.200
2	Day		Day	31
3	Month		Month	08
4	Year		Year	2023
5	localHrs		Local time zone hours	00
6	localMin		Local time zone minutes	00

GSV

NMEA GNSS satellites in view. `xx` corresponds to a constellation talker ID, shown in the table below.

Contains the number of sats in view, PRN numbers, elevation, azimuth and SNR value. Each message includes up to four satellites. When there are more than 4 sats for a constellation, multiple messages are sent. The total number of messages and the message number are included in each message.

Example:

```

$GPGSV,6,1,23,02,40,310,43,08,07,324,31,10,48,267,45,15,37,053,45*7C\r\n
$GPGSV,6,2,23,16,12,268,35,18,69,078,41,23,74,336,40,24,15,111,37*79\r\n
$GPGSV,6,3,23,26,02,239,31,27,35,307,38,29,12,162,37,32,14,199,39*7B\r\n
$GPGSV,6,4,23,44,43,188,43,46,40,206,43,52,48,267,45,527,37,053,26*73\r\n
$GPGSV,6,5,23,530,69,078,34,535,74,336,34,536,15,111,25,538,02,239,18*74\r\n
$GPGSV,6,6,23,539,35,307,27,541,12,162,21,544,14,199,25*73\r\n
$GAGSV,2,1,08,05,65,144,41,09,39,052,43,34,71,341,42,36,46,105,39*6A\r\n
$GAGSV,2,2,08,517,65,144,30,521,39,052,30,546,71,341,27,548,46,105,30*64\r\n
$GBGSV,3,1,10,11,09,141,34,14,52,047,44,27,32,313,43,28,80,263,44*64\r\n
$GBGSV,3,2,10,33,81,039,43,41,43,230,42,43,33,148,42,58,,44*5B\r\n
$GBGSV,3,3,10,11,09,141,16,14,52,047,32*60\r\n
$GQGSV,1,1,01,02,45,101,30*49\r\n
$GLGSV,2,1,07,65,85,260,33,66,28,217,30,72,36,034,35,81,20,324,33*69\r\n
$GLGSV,2,2,07,87,47,127,35,88,73,350,34,87,47,127,20*53\r\n

```

Example NMEA version 4.11:

```

$GPGSV,4,1,14,02,40,310,43,08,07,324,31,10,48,267,45,15,37,053,45*1*67\r\n
$GPGSV,4,2,14,16,12,268,35,18,69,078,41,23,74,336,40,24,15,111,37*1*62\r\n
$GPGSV,4,3,14,26,02,239,31,27,35,307,38,29,12,162,37,32,14,199,39*1*60\r\n
$GPGSV,4,4,14,44,43,188,43,46,40,206,43,52,48,267,45,527,37,053,26*1*65\r\n
$GPGSV,3,1,09,10,48,267,45,15,37,053,26,18,69,078,34,23,74,336,34*6*68\r\n
$GPGSV,3,2,09,24,15,111,25,26,02,239,18,27,35,307,27,29,12,162,21,6*64\r\n
$GPGSV,3,3,09,32,14,199,25,6*58\r\n
$GAGSV,1,1,04,05,65,144,41,09,39,052,43,34,71,341,42,36,46,105,39*7*7E\r\n
$GAGSV,1,1,04,05,65,144,30,09,39,052,30,34,71,341,27,36,46,105,30*2*73\r\n
$GBGSV,2,1,08,11,09,141,34,14,52,047,44,27,32,313,43,28,80,263,44*1*71\r\n
$GBGSV,2,2,08,33,81,039,43,41,43,230,42,43,33,148,42,58,,44*1*4E\r\n
$GBGSV,1,1,02,11,09,141,16,14,52,047,32*B*0D\r\n
$GQGSV,1,1,01,02,45,101,30*1*54\r\n
$GLGSV,2,1,06,65,85,260,33,66,28,217,30,72,36,034,35,81,20,324,33*1*75\r\n
$GLGSV,2,2,06,87,47,127,35,88,73,350,34*1*75\r\n
$GLGSV,1,1,01,87,47,127,20,3*41\r\n

```

Talker ID	Constellation
GP	GPS
GQ	QZSS
GA	Galileo
GL	Glonass
GB	BeiDou
GN	Combination of active constellations

Index	Field	Units	Description
1	numMsgs		Total number of messages for this constellation and epoch
2	msgNum		Message number
3	numSats		Total number of known satellites for the talker ID and signal ID
4+(n*5)	prn		Satellite PRN number
5+(n*5)	elev	deg	Elevation (0-90)
6+(n*5)	azim	deg	Azimuth (000 to 359)
7+(n*5)	snr	dB	SNR (00-99, empty when not tracking)
variable	system ID		GNSS system ID (distinguishes frequency band). This field is only output if the NMEA version is 4.11.

Where n is 0-3, for the four satellites supported by this message.

GSV OUTPUT FILTERING

Verbosity and size of the GSV NMEA message can be reduced to only select constellation and frequencies by using a [Filtered GSV NMEA Message IDs](#) instead of the standard GSV message ID `GPGSV` or `15` (`NMEA_MSG_ID_GNGSV`), either ASCII or integer. Note that the GSV output filter can only hide or mask information for satellites currently enabled in the `DID_FLASH_CONFIG.gnssSatSigConst` satellite system constellation. Usage:

```
$SASCE,[options],[Message ID]*[checksum]\r\n
```

For example, using message ID `GPGSV_1` or `3857` (`NMEA_MSG_ID_GPGSV_1`) will output only the GPS L1 frequency and prevent all other frequency and constellation satellite information from being displayed.

```
$SASCE,0,GPGSV_1,2*01\r\n
$SASCE,0,3857,2*33\r\n
```

Filtered GSV NMEA Message IDs

The following extended GSV NMEA message IDs are defined in data_sets.h.

All Constellations	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GNGSV_0	GNGSV_0	3840	Clear all constellations and frequencies
NMEA_MSG_ID_GNGSV_1	GNGSV_1	3841	Enable all constellations band1
NMEA_MSG_ID_GNGSV_2	GNGSV_2	3842	Enable all constellations band2
NMEA_MSG_ID_GNGSV_2_1	GNGSV_2_1	3843	Enable all constellations band1, band2
NMEA_MSG_ID_GNGSV_3	GNGSV_3	3844	Enable all constellations band3
NMEA_MSG_ID_GNGSV_3_1	GNGSV_3_1	3845	Enable all constellations band1, band3
NMEA_MSG_ID_GNGSV_3_2	GNGSV_3_2	3846	Enable all constellations band2, band3
NMEA_MSG_ID_GNGSV_3_2_1	GNGSV_3_2_1	3847	Enable all constellations band1, band2, band3
NMEA_MSG_ID_GNGSV_5	GNGSV_5	3848	Enable all constellations band5
NMEA_MSG_ID_GNGSV_5_1	GNGSV_5_1	3849	Enable all constellations band1, band5
NMEA_MSG_ID_GNGSV_5_2	GNGSV_5_2	3850	Enable all constellations band2, band5
NMEA_MSG_ID_GNGSV_5_2_1	GNGSV_5_2_1	3851	Enable all constellations band1, band2, band5
NMEA_MSG_ID_GNGSV_5_3	GNGSV_5_3	3852	Enable all constellations band3, band5
NMEA_MSG_ID_GNGSV_5_3_1	GNGSV_5_3_1	3853	Enable all constellations band1, band3, band5
NMEA_MSG_ID_GNGSV_5_3_2	GNGSV_5_3_2	3854	Enable all constellations band2, band3, band5
NMEA_MSG_ID_GNGSV_5_3_2_1	GNGSV_5_3_2_1	3855	Enable all constellations band1, band2, band3, band5
GPGSV - GPS	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GPGSV_0	GPGSV_0	3856	Disable all GPS frequencies
NMEA_MSG_ID_GPGSV_1	GPGSV_1	3857	Enable GPS L1
NMEA_MSG_ID_GPGSV_2	GPGSV_2	3858	Enable GPS L2
NMEA_MSG_ID_GPGSV_2_1	GPGSV_2_1	3859	Enable GPS L1, L2
NMEA_MSG_ID_GPGSV_5	GPGSV_5	3864	Enable GPS L5
NMEA_MSG_ID_GPGSV_5_1	GPGSV_5_1	3865	Enable GPS L1, L5
NMEA_MSG_ID_GPGSV_5_2	GPGSV_5_2	3866	Enable GPS L2, L5
NMEA_MSG_ID_GPGSV_5_2_1	GPGSV_5_2_1	3867	Enable GPS L1, L2, L5
NMEA_MSG_ID_GPGSV	GPGSV	3871	Enable all GPS frequencies

GAGSV - Galileo	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GAGSV_0	GAGSV_0	3888	Disable all Galileo frequencies
NMEA_MSG_ID_GAGSV_1	GAGSV_1	3889	Enable Galileo E1
NMEA_MSG_ID_GAGSV_5	GAGSV_5	3896	Enable Galileo E5
NMEA_MSG_ID_GAGSV_5_1	GAGSV_5_1	3897	Enable Galileo E1, E5
NMEA_MSG_ID_GAGSV	GAGSV	3903	Enable all Galileo frequencies
GBGSV - Beidou	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GBGSV_0	GBGSV_0	3904	Disable all Beidou frequencies
NMEA_MSG_ID_GBGSV_1	GBGSV_1	3905	Enable Beidou B1
NMEA_MSG_ID_GBGSV_2	GBGSV_2	3906	Enable Beidou B2
NMEA_MSG_ID_GBGSV_2_1	GBGSV_2_1	3907	Enable Beidou B1, B2
NMEA_MSG_ID_GBGSV_3	GBGSV_3	3908	Enable Beidou B3
NMEA_MSG_ID_GBGSV_3_1	GBGSV_3_1	3909	Enable Beidou B1, B3
NMEA_MSG_ID_GBGSV_3_2	GBGSV_3_2	3910	Enable Beidou B2, B3
NMEA_MSG_ID_GBGSV_3_2_1	GBGSV_3_2_1	3911	Enable Beidou B1, B2, B3
NMEA_MSG_ID_GBGSV	GBGSV	3919	Enable all Beidou frequencies
GQGSV - QZSS	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GQGSV_0	GQGSV_0	3920	Disable all QZSS frequencies
NMEA_MSG_ID_GQGSV_1	GQGSV_1	3921	Enable QZSS L1
NMEA_MSG_ID_GQGSV_2	GQGSV_2	3922	Enable QZSS L2
NMEA_MSG_ID_GQGSV_2_1	GQGSV_2_1	3923	Enable QZSS L1, L2
NMEA_MSG_ID_GQGSV_5	GQGSV_5	3928	Enable QZSS L5
NMEA_MSG_ID_GQGSV_5_1	GQGSV_5_1	3929	Enable QZSS L1, L5
NMEA_MSG_ID_GQGSV_5_2	GQGSV_5_2	3930	Enable QZSS L2, L5
NMEA_MSG_ID_GQGSV_5_2_1	GQGSV_5_2_1	3931	Enable QZSS L1, L2, L5
NMEA_MSG_ID_GQGSV	GQGSV	3935	Enable all QZSS frequencies

GLGSV - Glonass	Message ID ASCII	Message ID Int	Description
NMEA_MSG_ID_GLGSV_0	GLGSV_0	3936	Disable all Glonass frequencies
NMEA_MSG_ID_GLGSV_1	GLGSV_1	3937	Enable Glonass L1
NMEA_MSG_ID_GLGSV_2	GLGSV_2	3938	Enable Glonass L2
NMEA_MSG_ID_GLGSV_2_1	GLGSV_2_1	3939	Enable Glonass L1, L2
NMEA_MSG_ID_GLGSV_3	GLGSV_3	3940	Enable Glonass L3
NMEA_MSG_ID_GLGSV_3_1	GLGSV_3_1	3941	Enable Glonass L1, L3
NMEA_MSG_ID_GLGSV_3_2	GLGSV_3_2	3942	Enable Glonass L2, L3
NMEA_MSG_ID_GLGSV_3_2_1	GLGSV_3_2_1	3943	Enable Glonass L1, L2, L3
NMEA_MSG_ID_GLGSV	GLGSV	3951	Enable all Glonass frequencies

VTG

NMEA GPS track made good and speed over ground.

```
$GPVTG,140.88,T,,M,8.04,N,14.89,K,D*05\r\n
 1 2 3 4 5 6 7 8 9
```

Index	Field	Units	Description	Example
1	track true	deg	Ground track heading (true north)	140.88
2	T		Ground track heading is relative to true north	T
3	track mag	deg	Ground track heading (magnetic north)	M
4	M		Ground track heading is relative to magnetic north (track mag = track true + magVarCorrection)	M
5	speed Kn	knots	Speed	8.04
6	N		Speed is measured in knots	N
7	speed Km	kph	Speed over ground in kilometers/hour	14.89
8	K		Speed over ground is measured in kph	K
9	mode ind		Mode indicator	D

A: Autonomous mode | D: Differential mode | E: Estimated (dead reckoning) mode | M: Manual Input mode | S: Simulator mode | N: Data not valid

PASHR

NMEA GPS DOP and active satellites.

```
$PASHR,001924.600,95.81,T,+0.60,+1.05,+0.00,0.038,0.035,0.526,0,0*08\r\n
 1      2      3      4      5      6      7      8      9     10     11
```

Index	Field	Units	Description	Example
1	Time		UTC Time	001924.600
2	Heading		Heading value in decimal degrees	95.81
3	True Heading		T displayed if heading is relative to true north.	T
4	Roll	m	Roll in decimal degrees.	+0.60
5	Pitch	m	Pitch in decimal degrees.	+1.05
6	Heave	m	Instantaneous heave in meters.	+0.00
7	Roll Accuracy		Roll standard deviation in decimal degrees.	+0.038
8	Pitch Accuracy		Pitch standard deviation in decimal degrees.	0.035
9	Heading Accuracy		Heading standard deviation in decimal degrees.	0.526
10	GPS Status		GPS Status	0
11	INS Status		INS Status	0

PSTRB

Strobe input time. This message is sent when an assert event occurs on a strobe input pin.

```
$PSTRB,d,d,d,d*xx\r\n
 1 2 3 4
```

Index	Field	Units	Description
1	GPS week	weeks	Number of weeks since January 1 st of 1980 in GMT
2	timeMsOfWeek	ms	Milliseconds since Sunday morning in GMT
3	pin		Strobe event input pin number
4	count		Strobe event serial index number

INFO

Device version information. Query this message by sending \$INFO*0E\r\n.


```
$INFO,d,d,d,d,d,d,d,d,d,d,d,d,d,s,YYYY-MM-DD,hh:mm:ss.ms,s*xx\r\n
 1 2      3      4 5      6 7 8      9      10
```

Index	Field	Units	Description
1	Serial number		Manufacturer serial number
2	Hardware version		Hardware version
3	Firmware version		Firmware version
4	Build number		Firmware build number
5	Protocol version		Communications protocol version
6	Repo revision		Repository revision number
7	Manufacturer		Manufacturer name
8	Build date		Build date: [1] = year, [2] = month, [3] = day
9	Build time		Build date: [0] = hour, [1] = minute, [2] = second, [3] = millisecond
10	Add Info		Additional information
11	Hardware		Hardware: 1=uINS, 2=EVB, 3=IMX, 4=GPX
12	Reserved		Reserved for internal purpose.
13	Build type		Build type: 'a'=ALPHA, 'b'=BETA, 'c'=RELEASE CANDIDATE, 'r'=PRODUCTION RELEASE, 'd'=debug

7.4.6 NMEA Examples

Note

If the command strings below are altered, their checksum must be recalculated.

Note

All NMEA command strings must be followed with a carriage return and new line character (`\r\n` or `0x0D, 0x0A`).

The NMEA string checksum is automatically computed and appended to string when using the InertialSense SDK [serialPortWriteAscii](#) function or can be generated using an online [NMEA checksum calculator](#). For example: [MTK NMEA checksum calculator](#)

Stop streams on CURRENT port

```
$STPB*15
```

Stop all streams on ALL ports

```
$STPC*14
```

Query device version information

```
$INFO*0E
```

Response:

```
$INFO,30612,3.1.2.0,1.7.0.0,3522,1.2.74.7,6275,Inertial Sense Inc,0018-10-16,23:20:38.41,INL2*58
```

Stream INS1 @5Hz on port 0

```
$ASCE,1,3,1*0B
```

Stream INS1 @400ms on current port

```
$ASCE,0,3,2*09
```

Response:

```
$PINS1,244272.398,2021,427888998,805306448,0.0468,-0.3830,-0.0909,0.232,-0.083,-0.089,40.05574940,-111.65861580,1438.451,-1.678,-5.086,-9.697*11
$PINS1,244272.498,2021,427888998,805306448,0.0469,-0.3830,-0.0902,0.232,-0.081,-0.089,40.05575000,-111.65861550,1438.451,-1.611,-5.060,-9.697*18
$PINS1,244272.598,2021,427888998,805306448,0.0469,-0.3830,-0.0902,0.232,-0.081,-0.089,40.05575022,-111.65861562,1438.449,-1.587,-5.070,-9.695*1e
```

Stream INS1 @600ms on serial port 1

```
$ASCE,2,3,3*0A
```

Response:

```
$PINS1,256270.627,2021,427888998,1073741912,0.1153,-0.1473,-0.1628,0.001,0.001,0.003,40.05569486,-111.65864500,1416.218,-7.738,-7.570,12.536*3d
$PINS1,256270.647,2021,427888998,1073741912,0.1153,-0.1473,-0.1632,0.001,0.001,0.003,40.05569486,-111.65864500,1416.219,-7.738,-7.570,12.535*32
$PINS1,256270.667,2021,427888998,1073741912,0.1153,-0.1473,-0.1631,0.001,0.001,0.003,40.05569486,-111.65864500,1416.220,-7.738,-7.570,12.534*38
```

Stream PIMU @400ms and GGA @5Hz on current port

```
$ASCE,0,6,1,0,2*0D
```

Response:

```
$PIMU,3218.543,0.0017,-0.0059,-0.0077,-1.417,-1.106,-9.524,0.0047,0.0031,-0.0069,-1.433,-1.072,-9.585*1f
$GPGGA,231841,4003.3425,N,11139.5188,W,1,29,0.89,1434.16,M,18.82,M,,*59
$GPGGA,231841,4003.3425,N,11139.5188,W,1,29,0.89,1434.19,M,18.82,M,,*56
$PIMU,3218.763,0.0019,-0.0062,-0.0086,-1.426,-1.114,-9.509,0.0054,0.0029,-0.0070,-1.431,-1.085,-9.579*13
$GPGGA,231841,4003.3425,N,11139.5188,W,1,29,0.89,1434.16,M,18.82,M,,*59
$GPGGA,231841,4003.3425,N,11139.5188,W,1,29,0.89,1434.19,M,18.82,M,,*56
$PIMU,3218.543,0.0017,-0.0059,-0.0077,-1.417,-1.106,-9.524,0.0047,0.0031,-0.0069,-1.433,-1.072,-9.585*1f
```

7.5 SPI Protocol

The SPI interface provides an alternative method of communications with the IMX-5. The SPI protocol uses much of the same structure and format as the serial communication binary protocol which is outlined in the [Binary Protocol](#) section of the users manual.

7.5.1 Enable SPI

To Enable SPI, hold pin G9 (nSPI_EN) low at startup.

Note: When external GPS PPS timepulse signal is enabled on G9, the module will ignore the nSPI_EN signal and SPI mode will be disabled regardless of G9 pin state.

7.5.2 Hardware

Inertial Sense SPI interface uses 5 lines to interface with other devices.

Line	Function
CS	SPI Chip Select
SCLK	SPI Clock Synchronization Pin
MISO	SPI Master In Slave Out
MOSI	SPI Master Out Slave In
DR	SPI Data Ready Pin (optional)


Hardware Configuration

The IMX and GPX modules operate as a SPI slave device using **SPI Mode 3**:

SPI Settings	
SPI Mode	3
CPOL (Clock Polarity)	1
CPHA (Clock Phase)	1
Clock Polarity in Idle State	Logic high
Clock Phase Used to Sample and/or Shift Data	Data sampled on the rising edge and shifted out on the falling edge.
Chip Select	Active low
Data Ready	Active high

Data Transfer

To ensure correct behavior of the receiver in SPI Slave mode, the master device sending the frame must ensure a minimum delay of one t_{bit} (t_{bit} being the nominal time required to transmit a bit) between each character transmission. Inertial Sense devices do not require a falling edge of the [Chip Select (CS)] to initiate a character reception but only a low level. However, this low level must be present on the [Chip Select (CS)] at least one t_{bit} before the first serial clock cycle corresponding to the MSB bit. ⁽¹⁾



When reading the IMX and there is no data ready it will send zeros for the data.

Keeping CS low should not cause any issues. However, if the clocking between the master and slave processors gets out of sync there is nothing to get them back into sync. Ground bounce or noise during a transition could cause the IMX to see two clock edges when there should have only been one (due to an ESD or a fast transient event). Raising and lowering the CS line resets the shift register will resynchronize the clocks.

Data Ready Pin Option

There is a data ready pin option. This signal will be raised when data becomes ready. Depending on when this happens there can be 1-4 bytes of zeros that will come out before the packet starts. Also this line will go inactive a byte or two before the end of the packet gets sent. There is not a "not in a data packet" character to send. It is strictly done by data ready pin and parsing.

If the chip select line is lowered during a data packet, the byte being transmitted (or that would be transmitted) can be lost. It is recommended to only lower the chip select when outside of a data packet and the data ready pin is inactive.


The internal SPI buffer is 4096 bytes. If there is a buffer overflow, the buffer gets dropped. This is indicated by a data ready pin that is high without data being there. When an overflow happens, it clears the buffer, so the system could be in the middle of a packet and the IMX would just send zeros. If a request is sent to the IMX or the IMX sends a packet periodically it will resolve the situation.

The SPI interface supports up to 3 Mbs data rate. (5 Mbs works if the data ready pin is used to receive the data - see B below.)

Reading Data


There are two strategies that can be used to read the data:

A. Read a fixed data size out every set time interval. More data will be read than the uINx will produce on a regular interval, for instance, reading 512 bytes every 4 ms.



Packet will be 0x00 padded if bytes read exceeds packet size.

B. Read while the data ready pin is active **or** we are inside a data packet. One anomaly is the data ready pin will drop a byte or two before the end gets clocked out, hence needing to watch for the end of the packet.



Pseudo Code for reading data:

1. Check data ready pin. If pin is low, delay and check pin again.
2. Lower CS line and read a block of data. Read sizes are arbitrary, but it tends to work better if the read count is long enough to contain most data packets.
3. After read completes, check data ready pin. If it is high, read more data. DO NOT raise the CS line while the data ready pin is high, it will cause data loss. If data ready is low, raise CS line. On a busy system (and depending on baud rate) this would need to happen along with the data read as the data ready pin might not go low in between packets.
4. Parse data looking for start of packet (0xFF) discarding data until found. Once found start saving the data.
5. Save and parse data looking for end of packet (0xFE). Once found send packet off for use. If a start of packet character is seen while looking for the end, discard previous data and start the packet saving over.

7.5.3 EVB-2 SPI Dev Kit

The EVB-2 demonstrates SPI interface with the IMX. The EVB-2 ATSAM-E70 (E70) processor provides the example SPI interface with the IMX. The EVB-2 must be put into CBPreset mode 6 (CONFIG led color cyan) followed by a system reset to enable SPI mode. The EVB-2 (E70) project source code is available in the SDK for reference.

7.5.4 Troubleshooting

If every other character from a packet is lost it might be that the CS line is being toggled after every byte.

The uINS-3.1 uses a USART SPI peripheral which requires a minimum delay of one t_{bit} (t_{bit} being the nominal time required to transmit a bit) spacing between characters sent. Reading bytes one by one may cause significant time delays when streaming data. Depending on the amount of data streaming, the uINS may be unable to keep up and the buffer could overflow. Single message requests should work properly, but streaming probably will not work well. If the master hardware can't handle the delay, the uINS 3.2 hardware should be used.

7.5.5 Resources

(1) SAM E70/S70/V70/V71 Family. Microchip Technology Inc., <https://ww1.microchip.com/downloads/en/DeviceDoc/SAM-E70-S70-V70-V71-Family-Data-Sheet-DS60001527E.pdf>

7.6 CAN Protocol

The CAN interface allows the output of the the μ INS, μ AHRS, and μ IMU to be published on a CAN bus. The Inertial Sense CAN implementation is based on CAN2.0b specification and follows a specific structure and format which is outlined below. All of the CAN configuration is done using the data set DID_CAN_CONFIG.

7.6.1 Enable CAN

To enable the CAN bus interface on the IMX, set bit `IO_CONFIG_G1G2_CAN_BUS` in `DID_FLASH_CONFIG.ioConfig`. This bit can be set using the EvalTool >> Settings >> General >> DID_FLASH_CONFIG >> ioConfig >> Enable CAN Bus on G1,G2 option.

A CAN message is enabled by entering a non-zero value in the `DID_CAN_CONFIG.can_period_mult` field of the desired message. The `can_period_mult` field is an integer which is multiplied by the [Data Source Update Rate](#) to determine the message broadcast period. Set `can_period_mult` to zero disable message broadcasting.

In the image below the `CID_INS_TIME` message is set to broadcast data at 10 times the data source rate.

The screenshot shows the Inertial Sense software interface with the 'DID' tab selected. The 'Variables' section displays a table of configuration parameters. The 'can_period_mult' field for 'CID_INS_TIME' is highlighted with a red box and set to the value 10. The status bar at the bottom indicates a link speed of 35.6 KB/s and CAN bus status: SNO H:0.0.0 F:0.0.0 C:0.0.0.

DID	Variables	SN32405	Units	Description
DID_FLASH_CONFIG				
DID_NVR_MANAGE_USEI				
DID_SYS_FAULT				
DID_SYS_FAULT_DEC	can_period_mult[CID_INS_TIME]	10		Broadcast Period Multiple for CID_INS_TIME Messages
DID_RTOS_INFO				
DID_DEBUG_STRING				
DID_DEBUG_STR_U8				
DID_DEBUG_ARRAY	can_period_mult[CID_INS_STATUS]	0		Broadcast Period Multiple for CID_INS_STATUS Messages
DID_DEBUG_ARRAY_HE				
DID_RTK_DEBUG	can_period_mult[CID_INS_EULER]	0		Broadcast Period Multiple for CID_INS_EULER Messages
DID_HDW_PARAMS				
DID_INS_1	can_period_mult[CID_INS_QUATN2B]	0		Broadcast Period Multiple for CID_INS_QUATN2B Messages
DID_INS_2				
DID_INS_3	can_period_mult[CID_INS_QUATE2B]	0		Broadcast Period Multiple for CID_INS_QUATE2B Messages
DID_INS_4				
DID_SYS_PARAMS	can_period_mult[CID_INS_UVW]	0		Broadcast Period Multiple for CID_INS_UVW Messages
DID_PREINTEGRATED_I				
DID_DUAL_IMU	can_period_mult[CID_INS_VE]	0		Broadcast Period Multiple for CID_INS_VE Messages
DID_DUAL_IMU_RAW				
DID_MAGNETOMETER_1	can_period_mult[CID_INS_LAT]	0		Broadcast Period Multiple for CID_INS_LAT Messages
DID_MAGNETOMETER_2				
DID_MAG_CAL	can_period_mult[CID_INS_LON]	0		Broadcast Period Multiple for CID_INS_LON Messages
DID_BAROMETER				
DID_WHEEL_ENCODER	can_period_mult[CID_INS_ALT]	0		Broadcast Period Multiple for CID_INS_ALT Messages
DID_GPS1_RTK_MISC				
DID_GPS1_RTK_POS	can_period_mult[CID_INS_NORTH_EAST]	0		Broadcast Period Multiple for CID_INS_NORTH_EAST Messages
DID_GPS1_RTK_REL				
DID_GPS1_POS	can_period_mult[CID_INS_DOWN]	0		Broadcast Period Multiple for CID_INS_DOWN Messages
DID_GPS2_POS				
DID_GPS1_VEL	can_period_mult[CID_INS_ECEF_X]	0		Broadcast Period Multiple for CID_INS_ECEF_X Messages
DID_GPS2_VEL				
	can_period_mult[CID_INS_ECEF_Y]	0		Broadcast Period Multiple for CID_INS_ECEF_Y Messages
	can_period_mult[CID_INS_ECEF_Z]	0		Broadcast Period Multiple for CID_INS_ECEF_Z Messages
	can_period_mult[CID_INS_MSL]	0		Broadcast Period Multiple for CID_INS_MSL Messages
	can_period_mult[CID_PREINT_PX]	0		Broadcast Period Multiple for CID_PREINT_PX Messages
	can_period_mult[CID_PREINT_QY]	0		Broadcast Period Multiple for CID_PREINT_QY Messages

The baud rate is configurable by setting the field `DID_CAN_CONFIG.can_baudrate_kbps`. The following standard baud rates are supported:

- 20 kbps
- 33 kbps
- 50 kbps
- 83 kbps
- 100 kbps
- 125 kbps
- 200 kbps
- 250 kbps
- 500 kbps
- 1000 kbps

The message ID for each message can be entered into the `can_transmit_address` field corresponding to the desired message.

*Note: Any message ID greater than 0x7FF will be transmitted in the extended ID format.

The values set in any field of `DID_CAN_CONFIG` are saved to flash when a 'Save Persistent' command is received by the module. For example, this can be done in the EvalTool by clicking the Save Persistent button in the Data Logs tab. When the module is turned on, all the fields will be repopulated with the saved values.

All messages are disabled when a Stop Streaming message is received by the module. However, the values in each field will be repopulated to the values present when a 'Save Persistent' command was last received.

7.6.2 Hardware

Inertial Sense module exposes the RxCAN and TxCAN pins. The selection and implementation of a CAN transceiver is left to the user.

Line	Function
G1	RxCAN
G2	TxCAN

The Inertial Sense evaluation boards and Rugged unit have a built in transceiver.

7.6.3 CAN Data Sets (CIDs)

The CAN Data Sets, in the form of C structures, define the format of the output data. The data sets are defined in `SDK\src\data_sets_canbus.h` of the InertialSense SDK. The CID data is selected data from the standard Inertial Sense DIDs. The data types generally have been changed and scaled to fit the CAN2.0 8 byte payload restrictions.

`CID_INS_TIME`

INS time output

`is_can_time`

GMT information

Field	Type	Description
week	uint32_t	GPS number of weeks since January 6 th , 1980
timeOfWeek	float	GPS time of week (since Sunday morning) in seconds

CID_INS_STATUS

`is_can_ins_status`

INS status flags

Field	Type	Description
insStatus	uint32_t	INS status flags (see eInsStatusFlags)
hdwStatus	uint32_t	Hardware status flags (see eHdwStatusFlags)

CID_INS_EULER

`is_can_ins_euler`

Euler angles: roll, pitch, yaw in radians with respect to NED (scaled by 10000)

Field	Type	Description
theta1	int16_t	Roll (4 decimal places precision)
theta2	int16_t	Pitch (4 decimal places precision)
theta3	int16_t	Yaw (4 decimal places precision)

CID_INS_QUATN2B

`is_can_ins_quatn2b`

Quaternion body rotation with respect to NED: W, X, Y, Z (scaled by 10000)

Field	Type	Description
qn2b1	int16_t	W (4 decimal places precision)
qn2b2	int16_t	X (4 decimal places precision)
qn2b3	int16_t	Y (4 decimal places precision)
qn2b4	int16_t	Z (4 decimal places precision)

CID_INS_QUATE2B

`is_can_ins_quate2b`

Quaternion body rotation with respect to ECEF: W, X, Y, Z (scaled by 10000)

Field	Type	Description
qe2b1	int16_t	W (4 decimal places precision)
qe2b2	int16_t	X (4 decimal places precision)
qe2b3	int16_t	Y (4 decimal places precision)
qe2b4	int16_t	Z (4 decimal places precision)

CID_INS_UVW

`is_can_uvw`

Velocity U, V, W in body frame in meters per second (scaled by 100).

Field	Type	Description
uvw1	int16_t	U (2 decimal places precision)
uvw2	int16_t	V (2 decimal places precision)
uvw3	int16_t	W (2 decimal places precision)

CID_INS_VE

`is_can_ve`

Velocity in ECEF (earth-centered earth-fixed) frame in meters per second (scaled by 100).

Field	Type	Description
ve1	int16_t	ve1 (2 decimal places precision)
ve2	int16_t	ve2 (2 decimal places precision)
ve3	int16_t	ve3 (2 decimal places precision)

CID_INS_LAT

`is_can_ins_lat`

WGS84 latitude.

Field	Type	Description
lat	double	Latitude (degrees) (more than 8 decimal places precision)

CID_INS_LON

`is_can_ins_lon`

WGS84 longitude.

Field	Type	Description
lon	double	Longitude (degrees) (more than 8 decimal places precision)

CID_INS_ALT

`is_can_ins_alt`

WGS84 height above ellipsoid and GPS status flags

Field	Type	Description
alt	float	Altitude (meters) (more than 8 decimal places precision)
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags

CID_INS_NORTH_EAST

`is_can_north_east`

Offset from reference latitude, longitude, and altitude to current latitude, longitude, and altitude.

Type	Field	Description
float	ned1	North (meters)
float	ned2	East (meters)

CID_INS_DOWN

`is_can_down`

Down offset from reference LLA and INS status flags

Type	Field	Description
float	ned3	Down (meters)
float	insStatus	INS status flags

CID_INS_ECEF_X

`is_can_ecef_x`

X Position in ECEF (earth-centered earth-fixed) frame.

Type	Field	Description
ecef1	double	X (meters)

CID_INS_ECEF_Y

`is_can_ecef_y`

Y Position in ECEF (earth-centered earth-fixed) frame.

Type	Field	Description
ecef2	double	Y (meters)

CID_INS_ECEF_Z

`is_can_ecef_z`

Z Position in ECEF (earth-centered earth-fixed) frame.

Type	Field	Description
ecef2	double	Z (meters)

CID_INS_MSL

`ins_can_msl`

Height above Mean Sea Level

Type	Field	Description
msl	float	MSL (meters)

CID_PREINT_PX

`is_can_preint_imu_px`

Preintegrated IMU values delta theta and delta velocity (X axis), and Integral period in body/IMU frame of accelerometer 0.

Type	Field	Description
theta0	int16_t	Delta theta (rad, scaled by 1000, 3 decimal places precision)
vel0	int16_t	Delta velocity (m/s, scaled by 100, 2 decimal places precision)
dt	uints16_t	Integral Period (meters, scaled by 1000)

CID_PREINT_QY

`is_can_preint_imu_qy`

Preintegrated IMU values delta theta and delta velocity (Y axis), and Integral period in body/IMU frame of accelerometer 0.

Type	Field	Description
theta1	int16_t	Delta theta (rad, scaled by 1000, 3 decimal places precision)
vel1	int16_t	Delta velocity (m/s, scaled by 100, 2 decimal places precision)
dt	uints16_t	Integral Period (meters, scaled by 1000)

CID_PREINT_RZ

`is_can_preint_imu_rz`

Preintegrated IMU values delta theta and delta velocity (Z axis), and Integral period in body/IMU frame of accelerometer 0.

Type	Field	Description
theta2	int16_t	Delta theta (rad, scaled by 1000, 3 decimal places precision)
vel2	int16_t	Delta velocity (m/s, scaled by 100, 2 decimal places precision)
dt	uints16_t	Integral Period (meters, scaled by 1000)

CID_DUAL_PX

`is_can_dual_imu_px`

Dual IMU gyro and accelerometer values from accelerometer 0

Type	Field	Description
theta0	int16_t	Theta (rad/s, scaled by 1000, 3 decimal places precision)
vel0	int16_t	Acceleration (m/s^2 , scaled by 100, 2 decimal places precision)
status	uints32_t	IMU status (see eImuStatus)

CID_DUAL_QY

`is_can_dual_imu_qy`

Dual IMU gyro and accelerometer values from accelerometer 0

Type	Field	Description
theta1	int16_t	Theta (rad/s, scaled by 1000, 3 decimal places precision)
vel1	int16_t	Acceleration (m/s^2 , scaled by 100, 2 decimal places precision)
status	uints32_t	IMU status (see eImuStatus)

CID_DUAL_RZ

`is_can_dual_imu_rz`

Dual IMU gyro and accelerometer values from accelerometer 0

Type	Field	Description
theta2	int16_t	Theta (rad/s, scaled by 1000, 3 decimal places precision)
vel2	int16_t	Acceleration (m/s ² , scaled by 100, 2 decimal places precision)
status	uints32_t	IMU status (see eImuStatus)

CID_GPS1_POS

`is_can_gps_pos_status`

GPS CNO Mean and GPS status flags

Type	Field	Description
status	uint32_t	(see eGpsStatus) GPS status: [0x000000xx] number of satellites used, [0x0000xx00] fix type, [0x00xx0000] status flags
cnoMean	uint32_t	(dBHz) Average of all satellite carrier to noise ratios (signal strengths) that are non-zero

CID_GPS1_RTK_POS_REL

`is_can_gps_rtk_rel`

RTK-GPS positioning performance metrics

Type	Field	Description
arRatio	uint8_t	Ambiguity resolution ratio factor for validation
differentialAge	uint8_t	Age of differential (seconds)
distanceToBase	float	Distance to Base (m)
headingToBase	int16_t	Angle from north to vectorToBase in local tangent plane. (rad, scaled by 1000)

CID_GPS2_RTK_CMP_REL

`is_can_gps_rtk_rel`

RTK-GPS compassing performance metrics

Type	Field	Description
arRatio	uint8_t	Ambiguity resolution ratio factor for validation
differentialAge	uint8_t	Age of differential (seconds)
distanceToBase	float	Distance to Base (m)
headingToBase	int16_t	Angle from north to vectorToBase in local tangent plane. (rad, scaled by 1000)

CID_ROLL_ROLLRATE

`is_can_roll_rollRate`

Combination or INS roll estimation and preintegrated IMU of both accelerometers

Type	Field	Description
insRoll	int16_t	INS Roll (scaled by 10000, 4 decimal places precision)
pImu1	int16_t	Delta theta (rad, scaled by 1000, 3 decimal places precision)
pImu2	int16_t	Delta theta (rad, scaled by 1000, 3 decimal places precision)

8. GNSS - RTK

8.1 Multi-band GNSS

8.1.1 Multi-band GNSS

Advantages

The advent of multi-band GNSS (multiple frequency global navigation satellite systems) improves accuracy by reducing the impact of errors caused by multi-path and atmospheric distortion. When compared to traditional single-band GNSS, dual-band technology provides about a 2x reduction in average position error (circular error probable - CEP). Benefits of multi-band GNSS systems like the uBlox ZED-F9P or the Inertial Sense GPS-1 receiver include:

- Concurrent reception of GPS, GLONASS, Galileo and BeiDou for better coverage.
- Faster convergence time (GPS time to fix).
- More reliable / robust performance.
- ~2x reduction in average position error (CEP).
- Centimeter-level RTK position accuracy.
- Small and energy efficient module.
- Easy integration of RTK for fast time-to-market.

Overview


The IMX (GPS-INS) can be interfaced with external multi-band (multi-frequency) GNSS receiver(s) connected via serial port(s) to improve precision the EKF solution. The supported message protocols are uBlox binary and NMEA. The following are the GPS settings (accessible in the EvalTool GPS Settings tab and IMX `DID_FLASH_CONFIG.ioConfig` and `DID_FLASH_CONFIG.RTKCfgBits`):

Setting	Value
GPS Source	Serial port of the GNSS (serial 0 or 1)
GPS Type	GNSS model or protocol (ublox M8, ublox F9, Inertial Sense, or NMEA)
GPS RTK	<i>Position</i> for GPX-1 L1/L5 RTK precision positioning <i>Compass</i> for GPX-1 L1/L5 RTK Dual GNSS heading <i>F9 Position</i> for ZED-F9P multi-frequency RTK precision positioning <i>F9 Compass</i> for ZED-F9P multi-frequency Dual GNSS heading
GPS1 Timepulse	Source of the GNSS PPS time synchronization, uBlox GPS type only.

Refer to the Hardware section of this manual for serial port pinout information.


Dual GNSS Heading Accuracy

When using two multi-band GNSS receivers in moving baseline mode (RTK compassing) such as the [RUG-3-IMX-5-DUAL](#), the baseline error is composed of the measurement error plus the RTK solution error. The heading accuracy with ideal conditions is shown in the following plot.



Single GNSS RTK Positioning w/ LiDAR

RTK base messages (RTMC3) supplied to any of the IMX serial ports are forwarded to the GPX-1 for RTK positioning. The RTK precision position is used in the IMX EKF solution. The IMX can be configured to output NMEA messages such as GPGGA or GPRMC on any serial port.



Dual GNSS RTK Positioning and RTK Compassing

RTK base messages (RTMC3) supplied to any of the IMX serial ports are forwarded to GPS1 for RTK positioning. RTK moving base messages from GPS1 are forwarded to GPS2 for RTK compassing. The RTK precision position from GPS 1 and the RTK compassing heading from GPS2 are used in the IMX EKF solution.

8.1.2 IS GPX-1

The IMX can be configured for use with the Inertial Sense GPX-1 multi-band GNSS receivers. This can be done using either the EvalTool GPS Setting tab or the IMX `DID_FLASH_CONFIG.ioConfig` and `DID_FLASH_CONFIG.RTKCfgBits` fields.

GPS Ports	Value
GPS Source	serial 0, serial 1, or serial 2
GPS Type	GPX-1
GPS1 Timepulse	<i>Disable</i> or IMX pin connected to GPX-1

RTK Rover	Value
GPS RTK Mode	Position or Compass


RTK Base	Value
Serial Port 0 (Single GNSS only)	GPS1 - RTCM3
USB Port	GPS1 - RTCM3

The following sections detail how to interface and configure the IMX for operation using the GPX-1. See [RTK precision positioning](#) and [RTK compassing](#) for RTK operation principles.

TYPICAL INTERFACE

The IMX will automatically configure the GPX-1 for communications.

RUGGED-4 (COMING SOON)




The Rugged-4 INS contains the GPX-1 onboard supporting RTK positioning and compassing. GPS 1 and GPS 2 are connected to serial port 0 on the IMX-5.

The following is a list of the ZED-F9P GNSS receivers and compatible antenna(s).

Item



Item



8.1.3 ublox F9P

The IMX can be configured for use with uBlox ZED-F9P multi-band GNSS receivers. This can be done using either the EvalTool GPS Setting tab or the IMX `DID_FLASH_CONFIG.ioConfig` and `DID_FLASH_CONFIG.RTKCfgBits` fields.


GPS Ports	Value
GPS Source	serial 0, serial 1, or serial 2
GPS Type	ublox F9P
GPS1 Timepulse	<i>Disable</i> or IMX pin connected to ZED-F9P PPS

RTK Rover	Value
GPS RTK Mode	F9P Position or F9P Compass

RTK Base	Value
Serial Port 0 (Single GNSS only)	GPS1 - RTCM3
USB Port	GPS1 - RTCM3

The following sections detail how to interface and configure the IMX for operation using the ZED-F9P. See [RTK precision positioning](#) and [RTK compassing](#) for RTK operation principles.

RUGGED-3




The Rugged-3 INS contains the either single or dual ZED-F9P onboard supporting RTK positioning and compassing. GPS 1 and GPS 2 are connected to serial ports 1 and 0 respectively on the IMX.

Single GNSS Settings

Use the following IMX settings with the Rugged-3-G1 (single GNSS receiver). These settings can be applied either using the EvalTool GPS Settings tab or the IMX `DID_FLASH_CONFIG.ioConfig` and `DID_FLASH_CONFIG.RTKCfgBits` fields.

GPS Ports


Set the GPS1 source to **Serial 1** and type to **ublox F9P**.



DID_FLASH_CONFIG	Value
ioConfig (firmware >=1.8.5)	0x0244a040

RTK Rover


Enable RTK rover mode by selecting **F9P Precision Position**.



DID_FLASH_CONFIG	Value
RTKCfgBits	0x00000002

RTK Base

To configuring a system as an RTK base, disable the RTK Rover by setting the GPS1 and GPS2 RTK Mode to **OFF**, and select the appropriate correction output port on the IMX.




DID_FLASH_CONFIG	Value
RTKCfgBits	0x00000900

Dual GNSS Settings

Use the following IMX settings with the Rugged-3-G2 (dual GNSS receivers). These settings can be applied either using the EvalTool GPS Settings tab or the IMX `DID_FLASH_CONFIG.ioConfig` and `DID_FLASH_CONFIG.RTKCfgBits` fields.

GPS Ports


Set GPS 1 and 2 to source **Serial 1** and **Serial 0**, the serial port that the ZED-F9P is connected to and type to **ublox F9P**.



DID_FLASH_CONFIG	Value
ioConfig (firmware >=1.8.5)	0x025ca040

RTK Rover


Enable RTK rover mode by selecting **Precision Position External**. **GPS1** is designated for **Precision Position External** and **GPS2** for **F9P Compass settings**. Either or both can be enabled at the same time.



DID_FLASH_CONFIG	Value
RTKCfgBits	0x00000006


RTK Base

To configuring a system as an RTK base, skip the RTK rover settings, and select the appropriate correction output port on the IMX. Notice that IMX serial port 0 and 1 may be unavailable and occupied by the dual ZED-F9P receivers.



DID_FLASH_CONFIG	Value
RTKCfgBits	0x00000900

RUGGED-3-IMX-5 TO ZED-F9P



A +3.3V or +5V supply is needed to power the ZED-F9P when using the Rugged-1 IMX. A USB +5V supply can be used if available. The Rugged-1 must be configured for Serial Port 1 TTL voltage. See hardware configuration for [Rugged v1.0](#) or [Rugged v1.1](#) for details.

Settings

See the [single GNSS settings](#).

RTK Base Messages

In RTK mode, the ZED-F9P requires RTCM version 3 messages supporting DGNSS according to RTCM 10403.3.

ZED-F9 ROVER MESSAGES

The ZED-F9P operating in RTK rover mode can decode the following RTCM 3.3 messages.

Message type	Description
RTCM 1001	L1-only GPS RTK observables
RTCM 1002	Extended L1-only GPS RTK observables
RTCM 1003	L1/L2 GPS RTK observables
RTCM 1004	Extended L1/L2 GPS RTK observables
RTCM 1005	Stationary RTK reference station ARP
RTCM 1006	Stationary RTK reference station ARP with antenna height
RTCM 1007	Antenna descriptor
RTCM 1009	L1-only GLONASS RTK observables
RTCM 1010	Extended L1-only GLONASS RTK observables
RTCM 1011	L1/L2 GLONASS RTK observables
RTCM 1012	Extended L1/L2 GLONASS RTK observables
RTCM 1033	Receiver and antenna description
RTCM 1074	GPS MSM4
RTCM 1075	GPS MSM5
RTCM 1077	GPS MSM7
RTCM 1084	GLONASS MSM4
RTCM 1085	GLONASS MSM5
RTCM 1087	GLONASS MSM7
RTCM 1094	Galileo MSM4
RTCM 1095	Galileo MSM5
RTCM 1097	Galileo MSM7
RTCM 1124	BeiDou MSM4
RTCM 1125	BeiDou MSM5
RTCM 1127	BeiDou MSM7
RTCM 1230	GLONASS code-phase biases
RTCM 4072.0	Reference station PVT (u-blox proprietary RTCM Message)

ZED-F9 BASE OUTPUT MESSAGES

The ZED-F9P operating in RTK base mode will generate the following RTCM 3.3 output messages depending on whether the satellite constellation have been enabled. See the [Constellation Selection](#) for information on enabling and disabling satellite constellations.

Message Type	Period (sec)	Description
RTCM 1005	2	Stationary RTK reference station ARP
RTCM 1074	0.4	GPS MSM4
RTCM 1077	0.4	GPS MSM7
RTCM 1084	0.4	GLONASS MSM4
RTCM 1087	0.4	GLONASS MSM7
RTCM 1094	0.4	Galileo MSM4
RTCM 1097	0.4	Galileo MSM7
RTCM 1124	0.4	BeiDou MSM4
RTCM 1127	0.4	BeiDou MSM7
RTCM 1230	2	GLONASS code-phase biases

NTRIP MESSAGES


The NTRIP server must provide the necessary subset of [RTCM3 messages](#) supported by the IMX-RTK. See the [NTRIP](#) page for an overview of NTRIP.

ZED-F9P Firmware Update

The following section describes how to view the current GPS firmware version and how to update the firmware on the uBlox ZED-F9P GNSS receiver through the IMX.

GPS FIRMWARE VERSION


The current GPS firmware version can be read through the `DID_GPS1_VERSION` and `DID_GPS2_VERSION` messages.



FIRMWARE UPDATE


The following steps describe how to update the uBlox ZED-F9P firmware. The uBlox U-Center application software and firmware binary can be downloaded from the uBlox [ZED-F9P documentation and resources webpage](#).

1. **Enable IMX Serial Bypass** - Send the system command (DID_SYS_CMD) SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_GPS1 OR SYS_CMD_ENABLE_SERIAL_PORT_BRIDGE_USB_TO_GPS2 to enable serial bypass on the IMX. This will create a direct connection between the current IMX serial port and the GPS. This is done in the EvalTool using the Factory Options dialog in the Settings -> General tab.



2. **Update Using U-Center** - With the IMX serial bypass enabled, the uBlox U-Center software can connect directly to the ZED-F9P GPS. Use the following steps in the ublox U-Center app:

- Open the serial port with baudrate 921600.
- Select Tool -> Firmware Update and specify the uBlox F9P firmware file (i.e. UBX_F9_100_HPG132...bin).
- Enable "Use this baudrate for update" as 921600.
- Disable "Enter safeboot before update".
- Enable "Send training sequence".
- Start the firmware update by pressing the small green "GO" circle in the bottom left corner of the Firmware Update Utility dialog.




- Power cycle the IMX.

Multi-Band GNSS Components

The following is a list of the ZED-F9P GNSS receivers and compatible antenna(s).

Item




Item





Item



Item




Item



Item





Item



8.2 External NMEA GNSS

GNSS receivers that output NMEA ascii protocol can be used to aid the IMX EKF.

8.2.1 Configure IMX for NMEA GNSS Input

1. Set serial port baudrate, matching `DID_FLASH_CONFIG.serXBaudRate`.
2. Configure GPS1 using EvalTool GPS Setting tab or the `DID_FLASH_CONFIG.ioConfig`.

The screenshot shows a configuration window with three tabs: 'GPS Ports', 'RTK Rover', and 'RTK Base'. The 'GPS Ports' tab is active. It contains a table with columns 'Source' and 'Type'. For 'GPS1', the 'Source' is 'Serial 1' and the 'Type' is 'NMEA'. For 'GPS2', the 'Source' is 'Disabled' and the 'Type' is 'ublox M8'. There is a checkbox for 'Identical Base & Rover' which is unchecked, and a 'GPS1 Timepulse' dropdown set to 'Disabled'.

DID_FLASH_CONFIG	Value
ioConfig (firmware >=1.8.5)	0x00840040

3. Enable the NMEA messages on the external GNSS:

Message	Description
GNS	GNSS Fix data (preferred) or GGA - Global positioning System Fix Data.
ZDA	UTC time and date.
RMC	Recommended Minimum Specific GNSS Data.
GSA	GNSS DOP and Active Satellites.

4. If RTK positioning is supported by the NMEA receiver, Enable RTK rover mode by selecting **Precision Position External**. This will run the INS kalman filter in high accuracy mode and forward any RTK base station corrections to the external GNSS receiver.

The screenshot shows a configuration window with three tabs: 'GPS Ports', 'RTK Rover', and 'RTK Base'. The 'RTK Rover' tab is active. It contains a section titled 'RTK Mode' with two dropdown menus. The first dropdown, labeled 'GPS1', is set to 'Precision Position External'. The second dropdown, labeled 'GPS2', is set to 'OFF'.

DID_FLASH_CONFIG	Value
RTKCfgBits	0x00000002

8.2.2 Electrical Interface

The external NMEA GNSS receiver can be connected to Serial 0, Serial 1, and Serial 2 ports (3.3V TTL UART) on the IMX. See the [PCB Module](#) hardware page for a description of the IMX pinout. Serial 0 and 2 can be accessed on the main connector of [Rugged-1](#) and [Rugged-2](#) and all serial ports can be accessed on header H7 of the [EVB-2](#).

8.2.3 Enabling NMEA on ZED-F9P

The recommended protocol with the IMX and ZED-F9P receiver is the uBlox binary protocol. However, the ZED-F9 can operate using NMEA protocol if necessary. The following steps can be used to enable NMEA protocol output on the ublox ZED-F9P receiver.

1. Enable NMEA output using the [u-blox u-center](#) application.

- **Set the configuration:** (ublox u-center menu -> View -> Configuration View) change the following. You must press the "Send" button to apply each change.
- **PRT (Ports)** - Set Baudrate to match the GPS port baudrate (i.e. ser1BaudRate 921600)
- **PRT (Ports)** - Enable NMEA on the connected port/UART
- **PRT (Ports)** - Enable RTCM3 on the connected port/UART if using RTK
- **RATE (Rates)** - Measurement Period: 200ms
- **RATE (Rates)** - Navigation Rate: 1cyc
- **MSG (Messages)** - Enable NMEA messages listed above for the connected port/UART (i.e. UART1 On)
 - F0-0D NMEA GxGNS
 - F0-08 NMEA GxZDA
 - F0-04 NMEA GxRMC
 - F0-03 NMEA GxGSV
- **Save the configuration:** Send the CFG (Configuration) to 1 - FLASH or press the "Save Config" button with the small gear save icon (or menu Receiver -> Action -> Save Config).

8.3 GNSS Antennas

8.3.1 Selecting a GNSS Antenna

- Using a passive GNSS antenna is possible but not recommended. This requires a high RHCP antenna gain, good view of the sky, and a short matched/tuned 50 Ω input impedance line. This option may be appropriate to minimize BOM costs.
- Best performance is achieved by using an active antenna with integrated LNA. The LNA gain must be >17dB for standard GPS-INS use.
- For RTK and dual antenna (GPS compassing) use, the following characteristics are recommended: gain >26dB, multipath signal rejection, better signal to noise ratio, and improved carrier phase linearity.
- Antennas with integrated SAW filter may be necessary to reject interference from near frequencies or harmonic signals, such as wireless and LTE.
- For RTK and dual antenna applications we recommend dual feed (dual element) GNSS antennas

8.3.2 GNSS Antenna Integration Considerations

GNSS Antenna Ground Plane

A GNSS antenna ground plane blocks multipath signals, creating a shadow area for the antenna to hide in. The ground plane is acting as an RF blocking device. It is made of any material that attenuates (or totally blocks or reflects) RF signals. It creates a shadow area for the antenna to hide in. That shadow is a cone above the ground plane. Any signals that come down from the satellites and are bouncing back upward from the earth can't get to the antenna. Only signals coming directly from above can get to the antenna. The distance of the physical antenna above the ground plane changes the shape of the RF blocked shadow area.

The signal gain on some antennas can be improved by increasing the ground plane size up to a given size. Beyond that given size the antenna gain is not affected much.

A ground plane width of 8 to 12 cm is typically large enough for most applications.

HELPFUL LINKS:

[u-Blox: RF design considerations for GNSS receivers Application Note](#)

[Taoglas: GPS Patch Integration Application Note](#)

[electronics.stackexchange.com: How big a ground plane does a GPS antenna need?](https://electronics.stackexchange.com/questions/448882/how-big-a-ground-plane-does-a-gps-antenna-need/)

8.3.3 Recommended GNSS Components

The following components are optional components that may be used with the μ INS, μ AHRS, and μ IMU.

Frequencies: GPS (L1), GLONASS (G1), Beidou (B1), and Galileo (E1).

Recommended for RTK indicates the GNSS antenna will have better performance for applications using RTK and dual GNSS antenna (GNSS compassing).

For multi-frequency GNSS antennas, see [Purchasing the ZED-F9](#).

Enclosed GNSS Antennas

The following GNSS antennas have an environmental case rated at IP67 or better.

	Manufacturer Part Number	Description
	Tallysman TW4722	Magnet Mount, L1/G1/B1/E1 freq., Dual-feed, 26dB LNA, SAW filter, SMA 3m cable, Recommended for RTK
	Tallysman TW2712	Through-Hole Mount, L1/G1/B1/E1 freq., Dual-feed, 26dB LNA, SAW filter, SMA 3m cable, Recommended for RTK
	Tallysman TW3712	Through-Hole Mount, L1/G1/E1/B1 freq., Dual-feed, 26dB LNA, SAW filter, SMA 3m cable, Recommended for RTK
	Taoglas Limited AA.162.301111	Magnet Mount, L1/G1 freq., 29dB LNA, SAW Filter, SMA 3m cable.
	Taoglas Limited AA.171.301111	Magnet Mount, L1/G1/E1/B1 freq., 29dB LNA, SAW Filter, SMA 3m cable.
	Abracon LLC APAMPG-130	Magnet Mount, L1/G1 freq., 30dB LNA, SAW Filter, SMA 3m cable.

Manufacturer Part Number	Description
-----------------------------	-------------




OEM GNSS Antennas

These non-enclosed embedded antennas have exposed PCA with no environmental protection. OEM antennas are easily detuned by the local environment (caused by mounting inside enclosures). We recommend contacting the manufacturer for custom tuning services for optimized integration into OEM end-user modules.


Manufacturer Part Number	Description
-----------------------------	-------------



Tallysman TW2708	Dual-feed, L1/G1/B1/E1 freq., 1-3 dB axial ratio, 28dB LNA and SAW Filter, 56mm dia. x 7.6mm, RG174 cable, Recommended for RTK
---------------------	---



Tallysman TW1722	Dual-feed, L1/G1/B1/E1 freq., 28dB LNA and SAW Filter, 35mm dia. x 6mm, RG174 cable, Recommended for RTK
---------------------	---



Taoglas Limited AGGBP.25A. 07.0060A	L1/G1/B1/E1 freq., 28dB LNA and SAW Filter, 25x25mm, U.FL 6cm cable
---	---

Related GNSS Parts

	Manufacturer Part Number	Description
GNSS Backup Battery	Seiko Instruments MS621T-FL11E	Coin, 6.8mm 3V Lithium Battery Rechargeable (Secondary) 3mAh
GNSS Backup Battery	Panasonic ML-614S/FN	Coin, 6.8mm 3V Lithium Battery Rechargeable (Secondary) 3.4mAh

8.4 GNSS Satellite Constellations

The uINS supports onboard M8 and external (off-board) uBlox GNSS receivers. These receivers use multiple GNSS constellations in the global positioning solution.

The M8 receiver supports use of 3 concurrent constellations and the ZED-F9 receivers support 4 concurrent constellations (i.e. GPS, GLONASS, Galileo, and BeiDou).

The GPX-1 module supports 4 concurrent constellations.

8.4.1 Constellation Selection

The satellite constellations can be enabled or disabled by setting the corresponding enable bits in `DID_FLASH_CONFIG.gnssSatSigConst` as defined by `eGnssSatSigConst` in `data_sets.h`. The following are commonly used and recommended configuration groups.

```
// 3 constellations is supported by uINS onboard M8 reciever.  
// (SBAS is not considered a constellation)  
DID_FLASH_CONFIG.gnssSatSigConst = 0x133F // GPS/QZSS, Galileo, GLONASS, SBAS  
DID_FLASH_CONFIG.gnssSatSigConst = 0x10FF // GPS/QZSS, Galileo, BeiDou, SBAS  
DID_FLASH_CONFIG.gnssSatSigConst = 0x130F // GPS/QZSS, GLONASS, SBAS  
  
// 4 constellations is supported by ZED-F9 receiver and the GPX-1 (not uINS onboard M8 receiver).  
DID_FLASH_CONFIG.gnssSatSigConst = 0x13FF // GPS/QZSS, Galileo, GLONASS, BeiDou, SBAS
```


8.5 RTK Positioning

8.5.1 RTK Precision Positioning

Overview

Real Time Kinematic (RTK) is a precision satellite positioning technique which utilizes a base station to transmit position corrections to a receiver. The Inertial Sense RTK solution provides centimeter level position accuracy.

To use RTK, a base station, a rover (receiver), and a method to send corrections from the base to the rover are required.



See the [multi-band GNSS](#) section for details on using our multi-frequency ZED-F9 GNSS system.

RTK Hardware Setup

BASE STATION OPTIONS

Any of the following devices can be used as a RTK base station. All Inertial Sense base station options require a GPS antenna.

- **Inertial Sense EVB 2** - Sends corrections using the onboard 915 MHz radio, the onboard WiFi module, either serial port, or USB.
- **Inertial Sense μ INS module, EVB 1 or Rugged** - Sends corrections on either serial port or USB that can then be forwarded to a rover using a communication method of choice.
- **3rd Party Base Station** - e.g. Emlid Reach Receiver.
- **Public NTRIP Caster** - e.g. CORS Network.

ROVER OPTIONS

The following configurations can be used for the RTK rover:

- **Inertial Sense EVB 2** - Can receive corrections via the onboard 915 MHz radio, onboard WiFi module, serial ports, or USB.
- **Inertial Sense μ INS module, EVB 1 or Rugged** - Can receive corrections via either serial port or USB.


BASE TO ROVER COMMUNICATION

1. **Direct Serial** - Using USB, RS232, RS422/485, or TTL to pass corrections from Base to Rover.
2. **Radio Link** - Inertial Sense EVB 2 uses the Digi Xbee Pro SX module to send RTK corrections. Other communication methods such as Bluetooth may also work for the chosen application.
3. **NTRIP** - Transmits RTK correction data over the Internet. To receive messages with NTRIP, the user must supply a URL, port number, and mount point. Often a username and password are also required.
4. **TCP/IP** - A protocol for communicating directly between computers. In order to receive messages using TCP/IP, an address (IP Address or DNS) must be supplied to the Base where the corrections will be transmitted.

How to Know RTK is Working

USING THE EVALTOOL

1. Connect the μ INS Rover to a computer with the EvalTool running. Open the comport for the unit in the Settings > Serial Ports.
2. Navigate to Settings > RTK.
3. Under the Status section, RTK functionality can be verified in 3 ways:
 - Status field will show Single. Over the course of several minutes this status will change to Float then Fix.
 - The Differential Age will show a timestamp that increments and resets back to zero about every second. This shows that the Rover is receiving Base messages.
 - The Accuracy: H, V will show a large number at first. This number will decrease over time as the system acquires RTK Fix. Once in Fix, this number will average at +/- 0.08, 0.14 m.



USING THE CLTOOL

1. Connect the μ INS Rover to a computer with the CLTool running.
2. Include the argument `-msgPresetPPD` in the CLTool command.
3. Observe the `DID_GPS_RTNav_NAV` message, Status: `0x*****` (Single) over the course of several minutes this will change to (Float) then (Fix).

RTK Fix Status

LED INDICATORS

The LEDs on the IMX will indicate RTK fix status.

LED Behavior	Status	Description
	3D Fix, RTK Float	Allows improved accuracy up to ~1m
	RTK Fix	Allows increased accuracy up to ~3cm


RTK POSITIONING VALID FLAGS

The RTK precision positioning fix status can be identified using the valid bit in the INS and GPS status flags.

```
// INS status
INS_STATUS_NAV_FIX_STATUS(DID_INS_1.insStatus) == GPS_NAV_FIX_POSITIONING_RTk_FIX

// GPS status
DID_GPS1_POS.status & GPS_STATUS_FLAGS_GPS1_RTk_POSITION_VALID
```

RTK precision positioning fix is indicated is indicated when the RTK-Pos radio button turns purple in the EvalTool INS tab.




PROGRESS AND ACCURACY

The ambiguity resolution ratio, `arRatio`, is a metric that indicates progress of the solution that ranges from 0 to 999. Typically values above 3 indicate RTK fix progress.

```
DID_GPS1_RTK_POS_REL.arRatio // Ambiguity resolution ratio
```

The `DID_GPS1_RTK_POS_REL` status can be monitored in the EvalTool GPS tab.



RTK Base Messages

The IMX RTK solution accepts both RTCM3 and uBlox raw GNSS base correction messages. See the [RTK Base](#) or [NTRIP](#) pages for details on using base stations.

8.5.2 Rover Setup

System Configuration

A μ INS must be configured as a Rover to receive RTK Base messages. This can be done through the EvalTool or the CLTool by enabling "Rover Mode".

EvalTool

1. Navigate to Settings > GPS > Rover > RTK.
2. Change the first drop-down menu to "Positioning (GPS1)", or one of the F9P options depending on the hardware setup.
3. Press Accept.
4. Verify the `RTKCfgBits` was automatically set correctly to any one of the [rover modes](#) listed in our binary communications protocol page.

CLTool

Use the `-flashConfig=rtkCfgBits=0x01` argument to configure the unit as rover where 0x01 can be any one of the [rover modes](#) listed in our binary communications protocol page.

Communications Setup

The IMX automatically parses data that arrives at any of the ports and recognizes base corrections data. Any communications method that sends the base corrections to one of the ports is suitable. Several common methods are described below.

EVB2 RADIO

EvalTool

The EVB-2 radio can be configured by pressing the "CONFIG" tactile switch until the light next to it is blue. This enables the radio and configures the radio settings. See the [Configurations](#) and [EVB-2 Connections](#) sections of the [EVB-2](#) documentation.

1. Under "IMX Parameters" section verify the following:
 - Check the Baud Rate for the serial port of the radio (`ser0BaudRate` or `ser1BaudRate`). This should match the Baud Rate of the radio. The Digi Xbee Pro SX module on the EVB2 runs at **115200** baud.
2. Navigate to Data Sets > `DID_EVB_FLASH_CFG`
 - Change `cbPreset` - This should be set to `0x3` to enable the Digi Xbee Pro SX module.
 - Change `radioPID` - Radio Preamble ID. Should be the same number used as the Base radio. (`0x0` to `0x9`)
 - Change `radioNID` - Radio Network ID. Should be the same number used as the Base radio. (`0x0` to `0x7FFF`)
 - Change `radioPowerLevel` - Used to adjust the radio output power level. (0=20dbm, 1=27dbm, and 2=30dbm)
3. Reset the EVB2 and Rover radio setup is complete.

For more information on `DID_EVB_FLASH_CFG` see [DID-descriptions](#).

NTRIP CLIENT

For the Rover to receive messages from an NTRIP Caster, it must be connected to an interface with internet access (e.g. computer).

EvalTool

Follow the proceeding steps in order to set up the Rover to receive messages through NTRIP:

1. Navigate to Settings > RTK > Rover Mode.
2. Change the first drop-down menu to "RTK - GPS1"
3. Under Correction Input:
 - Type = NTRIP
 - Address:Port = : Ex: rtgpsout.unavco.org:2101
 - Username/Password = Enter the Username and Password to the account used as the NTRIP Caster. Some Casters do not require this field.
 - Format = RTCM3 or UBLOX
 - Mount Point = Specify the mount point of the caster. Ex: P016_RTCM3
4. Press Apply.

CLTool

With the Rover μ INS connected to the computer, use the `-rover` argument when running the CLTool executable:

- `-rover=TCP`: Set the type to "TCP".
- `PROTOCOL`: Set the protocol to "RTCM3" or "UBLOX". UBLOX requires more bandwidth and is not available from NTRIP casters.
- `URL`: The URL for the NTRIP Caster.
- `Port`: The port number will be provided by the NTRIP Caster.
- `MountPoint`: The mount point specifies which base station the corrections come from. This number will be provided by the NTRIP Caster.
- `Username:Password` The username and password for the account at the given URL (Not required by some public NTRIP casters).

Example:

```
cltool.exe -c COM10 -flashConfig=rtkCfgBits=0x01 -baud=57600 -rover=TCP:RTCM3:rtgpsout.unavco.org:2101:P016_RTCM3:username:password
```

TCP/IP

For the Rover to receive messages from a Base Station on a local network, it must be connected to an interface with network access (e.g. computer).

EvalTool

Follow these steps:

1. Navigate to Settings > GPS1
2. Under Correction Input:
 - Type = TCP
 - Address:Port = : e.g. 192.168.1.145:2001
 - Change Format to "ublox" or "RTCM3". Ublox requires more bandwidth but will result in better performance.
3. Press Accept.



For **serial ports**, view available comport numbers in the Settings tab of the EvalTool.

CLTool

With the μ INS Rover connected to the computer, enter the `-rover` argument when running the CLTool executable:

- `-rover=TCP`: Set the type to "TCP".
- `RTCM3`: Set the message type to "RTCM3" or "UBLOX". UBLOX requires more bandwidth and may be unavailable from some NTRIP Casters.
- `IP_Address`: The IP Address of the Base Station to receive messages from.
- `Port`: You may choose any number here. This should match the port number used for the Base Station.

Example: `cltool.exe -c COM10 -flashConfig=rtkCfgBits=0x01 -baud=57600 -rover=RTCM3:100.100.1.100:7777`

EVB2 WIFI

Using the EVB2 WiFi module to connect to the TCP/IP Base. EVB2 can save up to 3 Networks information. (Wifi[0], Wifi[1], Wifi[2]) Follow these steps using the EvalTool:

1. Under "IMX Parameters" section verify the following:
 - Verify the `RTKCfgBits` was automatically set to `0x00000001`
2. Navigate to Data Sets > `DID_EVB_FLASH_CFG`
 - Change `cbPreset` - This should be set to `0x4` to enable the WiFi module.
 - Change `wifi[0].ssid` - WiFi [0] Service Set Identifier or network name.
 - Change `wifi[0].psk` - WiFi [0] Pre-Shared Key authentication or network password.
 - Change `server[0].ipAddr` - server [0] IP address.
 - Change `server[0].port` - server [0] port.
3. Reset the EVB2 and Rover WiFi setup is complete.


8.5.3 Base Setup

RTK Base Configuration

Note

If using an **NTRIP** service or **3rd Party Base Station** instead of your own base station, please skip this page and see the **NTRIP** page or reference the setup instructions for the 3rd Party Base Station. **NTRIP services** do not require additional setup.

An essential part of an RTK system is the Base Station which supplies correction messages from a known, surveyed location to the RTK Rover. The μ INS Rover supports receiving RTCM3 and UBLOX correction messages.



Surveying In Base Position

Important

Accuracy of the base position directly effects the rover absolute position accuracy. It is critical that the base position be surveyed in for rover absolute position accuracy.

The base survey cannot happen at the same time as base correction output messages are enabled. If a survey is started the base correction output will automatically be disabled.

The base position is stored in `DID_FLASH_CONFIG.reflla` and transmitted to the rover during RTK operation. The following steps outline how to survey in the base position.

1. **Mount base station in fixed location** - The location should not change during or following a survey.
2. **Set survey-in parameters** - This step can either be done using the EvalTool or programmatically using the data set (`DID_SURVEY_IN`).

EvalTool

1. Navigate to Settings > RTK > Base Mode.
2. In the "Survey In" section select one of the States:
 - **Manual**: Direct entry of base position.
 - **Average GPS 3D** - Requires standard GPS 3D lock (non-RTK mode) for survey.*
 - **Average RTK Float** - Requires RTK float state for survey.*
 - **Average RTK Fix** - Requires RTK fix for survey.

*The average methods will not run if the minimum requirements are not met. The system will wait until the requirements are met and then begin the survey.
3. Use the slider to select the Survey In runtime. Generally the longer the survey runs the more accurate the results will be.
4. Press the Start button.



The current estimate of the survey is listed in the Position area above the Survey In section. If the survey completes successfully the results stored in flash memory (`DID_FLASH_CONFIG.reflla`) which will only change if the survey is re-run.

Using `DID_SURVEY_IN`

1. The location of the base can be manually entered using (`DID_FLASH_CONFIG.reflla`) if location is known.
2. Set `DID_SURVEY_IN.maxDurationSec` - Maximum time in milliseconds the survey will run. This is ignored if it is set to 0.
3. Set `DID_SURVEY_IN.minAccuracy` - Minimum horizontal accuracy in meters for survey to complete before maxDuration. This is ignored if it is set to 0.
4. Set (`DID_SURVEY_IN.state`) to begin the survey according to the desired survey State:
 - **2 = Average GPS 3D** - Requires standard GPS 3D lock (non-RTK mode) or better for survey.*
 - **3 = Average RTK Float** - Requires RTK float fix or better for survey.*
 - **4 = Average RTK Fix** - Requires RTK fix for survey.

*The average methods will not run if the minimum requirements are not met. The system will wait until the requirements are met and then begin the survey.

Communications Setup

RADIO

The Base IMX must be configured to stream base corrections to the radio so it can be broadcast to the rover.

EvalTool

1. Open the COM port for the μ INS under Settings > Serial Ports.

2. Navigate to Settings > RTK > Base Mode.
3. Under "Correction Output", find the fields for serial ports 0, 1, or USB. Select the serial port from which the corrections will be transmitted. This port must also be connected to the radio. Choose one of the options listed below. Leave the unused serial port off.
 - "GPS1 - RTCM3": *Output standard RTCM3 messages.*
 - "GPS1 - uBlox": *Output uBlox messages. This will provide more accuracy but requires significantly more bandwidth.*
4. Change the "Data Rate(ms)" field. This determines how many milliseconds pass between message outputs (e.g. Data Rate(ms) = 1,000 means one message/second). It is usually best to match the startupGPSDtMs value found in DID_FLASH_CONFIG.
5. In the "Position" section, a the Base Station position is required so that it can transmit accurate corrections. Please refer to [Surveying In Base Position](#) if the base station location is unknown.
6. Click Apply, and reset the μ INS. The unit will now start up in Base Station mode. Verify the base station is working by looking in the section labeled "Status". It will display the serial port of the radio and the message type. e.g. "SER1:UBX"
7. Navigate to Data Sets > DID_EVB_FLASH_CFG
 - Change `cbPreset` - This should be set to `0x3` to enable the Digi Xbee Pro SX module.
 - Change `radioPID` - Radio Preamble ID. Should be the same number used as the Rover radio. (`0x0` to `0x9`)
 - Change `radioNID` - Radio Network ID. Should be the same number used as the Rover radio. (`0x0` to `0x7FFF`)
 - Change `radioPowerLevel` - Used to adjust the radio output power level. (0 = 20dbm, 1 = 27dbm, and 2 = 30dbm)
8. Reset the EVB2 and Base radio setup is complete.

For more information on `DID_EVB_FLASH_CFG` see [DID-descriptions](#).

CLTool

The RTK config bit must be set manually when using the CLTool. Use the following command line arguments when executing the CLTool from a prompt/terminal.

- `-c #` Open the COM port of the μ INS. Windows users will use the name of the COM port, e.g. COM7. Linux users must enter the path to the correct COM port, e.g. `/dev/ttyUSB0`.
- `-baud=#` Set the baud rate for communications output (Replace # with baud rate number). This number will vary depending on setup. For lower quality radios it maybe necessary to use a lower baud rate (ex: 57600).
- `-flashConfig=rtkCfgBits=0x00` Configure the unit to cast Base corrections. For more configuration options see [eRTKConfigBits](#)

Example:

```
cltool.exe -c COM29 -baud=57600 -flashConfig=rtkCfgBits=0x00
```

Warning

If the Base Station is not communicating properly, it maybe necessary to verify that the baud rate is set to match that of the radios used. This rate varies depending on radio type.

TCP/IP SETUP

CLTool

It is required to manually set the RTK config bits in the CLTool. Passed these to the CLTool when run from the command prompt/terminal.

- `-c #` Open the COM port of the μ INS. Windows users will use the name of the COM port, e.g. COM7. Linux users must enter the path to the correct COM port, e.g. `/dev/ttyUSB0`.
- `-baud=#` Set the baud rate for communications output (Replace # with baud rate number).
- `-flashConfig=rtkCfgBits=0x00` Configure the unit to cast Base corrections. For more configuration options see [eRTKConfigBits](#)
- `-base=:#` Create the port over which corrections will be transmitted. Choose any unused port number.

Example:

```
cltool.exe -c COM29 -baud=921600 -flashConfig=rtkCfgBits=0x10 -base=:7777
```


Important

If the console displays the error "**Failed to open port at COMx**", reset the device immediately after attempting to change the baud rate in the CLTool.

8.5.4 NTRIP

Networked Transport of RTCM via internet protocol, or NTRIP, is an open standard protocol for streaming differential data over the internet in accordance with specifications published by RTCM. There are three major parts to the NTRIP system: The NTRIP client, the NTRIP server, and the NTRIP caster:

1. The NTRIP server is a PC or on-board computer running NTRIP server software communicating directly with a GNSS reference station.
2. The NTRIP caster is an HTTP server which receives streaming RTCM data from one or more NTRIP servers and in turn streams the RTCM data to one or more NTRIP clients via the internet.
3. The NTRIP client receives streaming RTCM data from the NTRIP caster to apply as real-time corrections to a GNSS receiver.



The EvalTool/CLTool software applications provide NTRIP client functionality to be used with the IMX RTK rover. Typically an EvalTool NTRIP client connects over the internet to an NTRIP service provider. The EvalTool/CLTool NTRIP client then provides the RTCM 3.3 corrections to the IMX and ZED-F9P rover connected over USB or serial. Virtual reference service (VRS) is also supported by the EvalTool/CLTool NTRIP client.

Important

If using a **virtual reference service (VRS)**, the rover must output the **NMEA GGA** message to return to the NTRIP caster. Without this, the NTRIP caster will not provide correction information.

NTRIP RTCM3 Messages

The NTRIP server must provide the necessary subset of [RTCM3 messages](#) supported by the IMX-RTK. The following is an example of compatible RTCM3 base output messages provided from a Trimble NTRIP RTK base station.

REQUIRED RTCM MESSAGES FOR RTK POSITIONING

Message Type	Description
RTCM 1005	Stationary RTK reference station ARP
RTCM 1074, 1075, or 1077	GPS MSM4, MSM5, or MSM7
RTCM 1084, 1085, or 1087	GLONASS MSM4, MSM5, or MSM7
RTCM 1094, 1095, or 1097	Galileo MSM4, MSM5, or MSM7
RTCM 1230	GLONASS code-phase biases

8.5.5 Using uBlox PointPerfect L-band Corrections

The IMX-5 can receive corrections from the uBlox D9S device, which provides L-band corrections through the uBlox PointPerfect solution. **PointPerfect IP-based corrections are currently not supported (L-band only)**

Firmware update


L-band corrections requires a later version of F9P firmware. Use FW version HPG 1.32 from the F9P downloads page on the uBlox site.

To check your firmware version, follow these steps:

1. Open the Inertial Sense EvalTool
2. Navigate to the Data Sets tab.
3. Select `DID_GPSX_VERSION`
4. The firmware version is displayed in extension[1]. For Example, FWVER=HPG 1.12

To update the firmware on the F9P, follow these steps:

1. Open the Inertial Sense EvalTool
2. Navigate to the Data Sets tab. Select `DID_SYS_CMD` from the sidebar (see the image below)
3. Set `command` to `11` and `invCommand` to `-12` to enable passthrough to GNSS1 (set `12` and `-13` for GNSS2)
4. Close the serial port (Settings tab)
5. Open the device in uBlox u-center (we currently use u-center 22.07)
6. Update the firmware in u-center per u-blox instructions. Baudrate should be set to 921600.




Configuration of the F9P

By default, the IMX-5 module updates settings on the F9P at bootup. Currently the IMX:

- Configures frequencies and constellations to use in the solution
- Changes the CFG-SPARTN setting to use L-band corrections. IP corrections are not currently supported through the IMX-5 due to a difference in the protocol.

The IMX acts as a transparent pipe for some UBX messages. In the mode shown below, the IMX passes the following messages:

- RXM-SPARTN (from F9P)
- RXM-SPARTNKEY (to/from F9P)
- RXM-PMP (to F9P)
- CFG-* (bidirectional)



For L-band, the messages are sent as UBX-RXM-PMP messages. No additional configuration on the IMX is needed to switch between these messages and RTCM3, either will work. We have not tested using them together, contact uBlox if you are considering this.

To set the SPARTNKEY message, use the u-center tool or send the proper message as specified in the HPG 1.32 manual to the IMX. SPARTNKEY messages are passed through the IMX.

If you need to access additional settings on the F9P, you can use the serial passthrough mode used for firmware update, or there are settings under the **RTK Base** tab that allow passthrough of all uBlox messages.

Corrections can be forwarded through the EvalTool using the **Correction Input** section of the tool. See the above screenshot for an example configuration.


8.5.6 Using uBlox SBAS corrections

The uBlox F9P receivers can be configured to enable the SBAS corrections constellations

Firmware update

SBAS corrections require a later version of F9P firmware. Use FW version HPG 1.32 from the F9P downloads page on the uBlox site. To update the firmware on the F9P, follow these steps:

1. Open the Inertial Sense EvalTool
2. Navigate to the Data Sets tab. Open `DID_SYS_CMD` from the sidebar (see the image below)
3. Set `command` to `11` and `invCommand` to `-12` to enable passthrough to GNSS1 (set `12` and `-13` for GNSS2)
4. Close the serial port (Settings tab)
5. Open the device in uBlox u-center (u-center 22.07)
6. Update the firmware in u-center per u-blox instructions. Baudrate should be set to 921600.



Configuration of the F9P

With the uBlox 1.32 firmware installed on the F9P SBAS can be enabled using the standard constellation selection methods described in the [GNSS Constellations](#) page.

8.6 Dual GNSS RTK Compassing


8.6.1 Overview

RTK Compassing (Dual GNSS) is a system that determines heading by use of two GNSS receivers and antennas. It replaces the need for magnetometers which can be problematic in the presence of ferrous materials (e.g. steel) and EMI generating circuits (e.g. electric motors and drivers).

See the [multi-band dual GNSS](#) section for details on using our multi-frequency dual ZED-F9 GNSS system.

8.6.2 Heading Accuracy

The generalized heading accuracy for both the single-band (L1) and the [dual GNSS multi-band](#) systems under ideal conditions is shown in the following plot.



Recommended Minimum Baseline

The recommended minimum baseline (distance between dual GNSS antennas) is **0.3 meters** for single-band (L1) GNSS compassing and **0.25 meters** for multi-band ZED-F9 GNSS compassing. The solution can operate at shorter baseline distances but is less robust and more susceptible to getting caught in a local minimum which may not converge to the correct heading.

8.6.3 Antenna Orientation

Important


It is recommended that both GNSS antennas be identical and have the same physical orientation relative to each other (i.e. the antenna cable should exit in the same direction on both antennas). This will ensure best RF phase center alignment and heading accuracy. The actual RF phase center is often offset from the physical center of the antenna case.

Mismatch

BAD



8.6.4 Rugged GNSS Antenna Ports




On the Rugged IMX, the MMCX port **A** is for **GPS1** and MMCX port **B** is **GPS2**. These port labels are changed to **1** and **2** on newer Rugged units.

8.6.5 Dual Antenna Locations

The location for both GPS antennae must be correctly specified by the user in the `DID_FLASH_CONFIG` variables within 1 cm accuracy:

```
DID_FLASH_CONFIG.gps1AntOffset[X, Y, Z]
DID_FLASH_CONFIG.gps2AntOffset[X, Y, Z]
```


These values describe the distance of each GPS antenna from the IMX [Sensor Frame](#) origin in the direction of the Sensor Frame axes. The [Sensor Frame](#) is defined using `DID_FLASH_CONFIG.sensorConfig`.



Example Antennae Configurations

The following are examples that illustrate what the GPS antenna offsets should be for two different antenna configurations.

DRONE




```

DID_FLASH_CONFIG.gps1AntOffset[0] = 0.0
DID_FLASH_CONFIG.gps1AntOffset[1] = -0.3 (negative direction of Y axis)
DID_FLASH_CONFIG.gps1AntOffset[2] = 0.0

DID_FLASH_CONFIG.gps2AntOffset[0] = 0.0
DID_FLASH_CONFIG.gps2AntOffset[1] = 0.3
DID_FLASH_CONFIG.gps2AntOffset[2] = 0.0

```

AUTOMOBILE



```

DID_FLASH_CONFIG.gps1AntOffsetX = -0.5 (negative direction of X axis)
DID_FLASH_CONFIG.gps1AntOffsetY = 0.5
DID_FLASH_CONFIG.gps1AntOffsetZ = -0.5 (negative direction of Z axis, above IMX)

DID_FLASH_CONFIG.gps2AntOffsetX = -1.5 (negative direction of X axis)
DID_FLASH_CONFIG.gps2AntOffsetY = 0.5
DID_FLASH_CONFIG.gps2AntOffsetZ = -0.5 (negative direction of Z axis, above IMX)

```

GPS Antenna Ports

The following table explains how ports A and B on the Rugged IMX map to GPS antennas 1 and 2.

Ports	Rugged IMX	IMX Module and EVB-2
GPS 1 antenna port	A	1
GPS 2 antenna port	B	2

8.6.6 Setup

Step 1 - Specify Offsets for Both Antennae

Refer to the [Dual Antenna Locations](#) section for a description of the GPS antenna offset.

```
DID_FLASH_CONFIG.gps1AntOffsetX = ?
DID_FLASH_CONFIG.gps1AntOffsetY = ?
DID_FLASH_CONFIG.gps1AntOffsetZ = ?

DID_FLASH_CONFIG.gps2AntOffsetX = ?
DID_FLASH_CONFIG.gps2AntOffsetY = ?
DID_FLASH_CONFIG.gps2AntOffsetZ = ?
```

Using EvalTool - select Data Sets -> DID_FLASH_CONFIG and set gps1AntOffset[X,Y,Z] and gps2AntOffset[X,Y,Z] with the GPS antenna offsets.

Using CLTool - run the CLTool using the following options replacing the [OFFSET] with the GPS antenna offsets.

```
-flashconfig=gps1AntOffsetX=[OFFSET]
-flashconfig=gps1AntOffsetY=[OFFSET]
-flashconfig=gps1AntOffsetZ=[OFFSET]
-flashconfig=gps2AntOffsetX=[OFFSET]
-flashconfig=gps2AntOffsetY=[OFFSET]
-flashconfig=gps2AntOffsetZ=[OFFSET]
```

Step 2 - Enable GPS Dual Antenna

Set the RTK_CFG_BITS_COMPASSING (0x00000008) bit of RTKCfgBits.

```
DID_FLASH_CONFIG.RTKCfgBits |= RTK_CFG_BITS_COMPASSING // |= 0x00000008
```

Using EvalTool - go to Settings -> RTK -> Rover Mode, set the dropdown menu to GPS Compassing, and press the Apply button.

Using CLTool - run the CLTool using the -flashconfig=RTKCfgBits=0x8 option to enable GPS Dual Antenna.


8.6.7 RTK Compassing Fix Status

INS and GPS Status Flags

The RTK compassing fix status can be identified using the valid bit in the INS and GPS status flags.

```
DID_INS_1.insStatus & INS_STATUS_RTK_COMPASSING_VALID // INS status
DID_GPS1_POS.status & GPS_STATUS_FLAGS_GPS2_RTK_COMPASS_VALID // GPS status
```

RTK compassing fix is indicated when the RTK-Cmp radio button turns purple in the EvalTool INS tab.




Progress and Accuracy

The ambiguity resolution ratio, `arRatio`, is a metric that indicates progress of the solution that ranges from 0 to 999. Typically values above 3 indicate RTK fix progress. The base to rover heading accuracy indicates how much error is in the base to rover heading (RTK compassing heading).

```
DID_GPS1_RTK_CMP_REL.arRatio // Ambiguity resolution ratio
DID_GPS1_RTK_CMP_REL.baseToRoverHeadingAcc // (rad) RTK compassing accuracy
```

The `DID_GPS1_RTK_CMP_REL` status can be monitored in the EvalTool GPS tab.



8.6.8 Stationary Application

For RTK compassing stationary application, enabling the STATIONARY INS dynamic model (`DID_FLASH_CONFIG.dynamicModel = 2`) is recommended to reduce heading noise and drift. This will reduce heading error during RTK compassing fix or loss of fix. See [INS-GNSS Dynamic Model](#) and [Zero Motion Command](#) for details.

9. Dead Reckoning

9.1 Ground Vehicle Dead Reckoning

9.1.1 Overview

The IMX inertial navigation integrates IMU data to dead reckon (estimate position and velocity) when GPS position fix is not available. The amount of position error during dead reckoning can vary based on several factors including system runtime, motion experienced, and sensor bias stability.

Knowledge about the vehicle's kinematic constraints is applied to reduce drift and improve position estimation.

9.1.2 Installation

Important

It is critical to ensure the IMX remains fixed relative to the vehicle. Any shift or change in the IMX location relative to the vehicle will result in degraded or inaccurate dead reckoning solution.

Important

Heavy vibrations can degrade the IMX measurements and dead reckoning solution.

1. Mount the IMX and GNSS antenna at fixed locations on the vehicle.
2. Set the GPS antenna offsets relative to the IMX origin in meters. EvalTool > Data Sets > DID_FLASH_CONFIG > gps1AntOffsetX/Y/Z.

Enabling

Dead reckoning is enabled by setting the `DID_FLASH_CONFIG.dynamicModel` to 4 for ground vehicles. This is done automatically during Learning Mode and stored to flash memory.



Learning Mode

Learning mode is be used following installation or any change in the IMX position relative to the vehicle. Learning is used to estimate the vehicle kinematic calibration which is used during normal operation.

LEARNING MODE INSTRUCTIONS

1. `start` learning mode.
2. Drive with sufficient motion for learning. This is identified with the EvalTool `gv: cal` indicator in the INS tab turns GREEN (`DID_GROUND_VEHICLE.status` & `GV_STATUS_LEARNING_CONVERGED` is not zero). Either of the following patterns is typically adequate.
 - At least 200 meters straight, 5 left turns (+90 degrees) and 5 right turns
 - Three figure eight patterns.
3. `stop` learning and save kinematic calibration to flash memory.

Using the EvalTool



From the EvalTool INS tab:

1. Press the `gv:` button to reveal the ground vehicle options.
2. Press the `start` button to clear and start learning.
3. Press the `stop` button to stop learning and save kinematic calibration to flash memory.

Using the DID_GROUND_VEHICLE Message

1. Enable learning mode by setting the `DID_GROUND_VEHICLE.mode` to any of the following commands. The `DID_GROUND_VEHICLE.mode` value will toggle to 1 indicating the system is in learning mode and 0 to indicate learning mode is off.
 - 2 **"Start"** - Start with user supplied values in the `DID_GROUND_VEHICLE.transform` and enable learning mode.
 - 3 **"Resume"** - Start with the existing calibration and enable learning mode.
 - 4 **"Clear & Start"** - Set transform to zero and start with aggressive learning mode. This is the same as the "Start" button in the EvalTool INS tab.
 - 5 **"Stop & Save"** - End learning mode and save kinematic calibration to flash memory.
2. Disable learning and save kinematic calibration to flash memory by setting `DID_GROUND_VEHICLE.mode` to 5.

9.1.3 Examples

[Dead reckoning examples can be found here.](#)



9.2 IMX Dead Reckoning Examples

Dead Reckoning is the process of calculating the current position of a moving object by using a previously determined position, or fix, and then incorporating estimations of speed, heading direction, and course over elapsed time. Knowledge about the vehicle's kinematic constraints (i.e. wheels on the ground) is applied to reduce drift and improve position estimation.

Inertial Sense has added dead reckoning capability to IMX to estimate position for extended periods of time during GNSS outages. In this report RTK-GNSS is used.


The following are examples dead reckoning of a car test vehicle. No wheel sensors were used in these examples. The dead reckoning position is shown in the yellow "INS" line and GNSS position in the red "GNSS" line.

9.2.1 Parking Lot Simulated GNSS Outage

In this example GNSS outage was simulated by disabling GNSS fusion into the INS Kalman filter (EKF). This was done by setting the `Disable Fusion - GPS1` option found in the General settings of the EvalTool app. By disabling GPS fusion and keeping fix, we can use the GNSS position as truth and compare it to the dead reckoning solution.

Dead reckoning duration: **30 seconds, 605 meters**

Max position error: **2.5 meters, 0.4% drift**



When GNSS fusion is re-enabled, error in the INS solution is removed and the INS position estimate jumps back onto the GNSS position. There is 2.5m of error between the dead reckoning position and the GNSS position.

9.2.2 Multi-Level Parking Garage


In this example our test vehicle drove in and out of a parking garage. The drive consisted of starting outside with GNSS fix, entering the garage (losing GNSS fix), driving up one level, parking, and then following the path back down and out of the garage where GNSS fix was regained.

Dead reckoning duration: **105 seconds, 349 meters**


Exit position error: **~2 meters, 0.6% drift**



Here we see outside parking lot where the test vehicle started and ended. GNSS fix was lost upon entry of the garage and regained several seconds after exiting the garage.



Above is the top view of the parking garage. When inside the garage, the GNSS fix is lost shown by the red line erratic deviation. The dead reckoning (INS) position shown by the yellow line matches the actual driven path.



GNSS fix was not regained until about 20 meters after exiting the garage, just prior to parking at the top right corner of the outside parking lot. The actual position is shown by the orange truth dotted line. GNSS position is shown by the red line and dead reckoning by the yellow INS line. GNSS fix occurs when the red GNSS line jumps and joins the orange truth dotted line. When exiting the garage, the position error was approximately 2 meters following 105 seconds of dead reckoning from GNSS outage.

9.2.3 Conclusion

The IMX with dead reckoning and without wheel sensor can estimate position to within ~3m over 100 seconds of typical automotive parking lot driving.



10. General Configuration

10.1 Infield Calibration

The *Infield Calibration* provides a method to 1.) zero IMU biases and 2.) zero INS attitude to align the INS output frame with the vehicle frame. These steps can be run together or independently.

10.1.1 Zeroing IMU Bias

Zeroing IMU bias is a way to remove permanent offsets in the sensor output that may have occurred as a result of manufacturing or high shock. The system must be completely stationary for accurate bias measurement. The current value for IMU biases stored in flash memory is viewable in `DID_INFIELD_CAL.imu` when infield calibration is inactive and `DID_INFIELD_CAL.sampleCount` is zero.

Accelerometer Bias

In order to correct accelerometer bias on a given axis, that axis must be sampled while measuring full gravity. Thus, only the accelerometer axes that are sampled while in the vertical direction can be corrected. In order to correct all accelerometer axes, all three axes must be sampled while oriented vertically. The sample can be done while the axis is pointed up, down, or both up and down for averaging.

Gyro Bias

All three axes of the gyros are sampled simultaneously, and the bias is stored in flash memory. The system must be completely stationary for accurate bias measurement. The system does not need to be level to zero the gyro biases.

10.1.2 Zeroing INS Attitude

The Infield Calibration process can be used to align or level the INS output frame with the vehicle frame. This is done by observing the X,Y,Z axes rotations necessary to level the orientation(s) sampled. Zeroing the INS attitude as part of the Infield Calibration routine provides a optimal and highly accurate method for measuring the attitude while stationary by averaging raw bias corrected accelerations.

Rotations cannot be computed for axes that are pointed vertically. For example, a single orientation sample with X and Y in the horizontal plane and Z pointed down will only be able to produce an X,Y rotation, and the Z rotation will remain zero. To compute all three rotations for the X,Y,Z axes, the system must be sampled at least twice, once while level and once while on its side.

The infield calibration process is generally useful for only small angle INS rotations and is not intended for those larger than 15° per axis. The user must set the INS rotation manually for larger rotations. The INS rotation is stored and accessed in `DID_FLASH_CONFIG.insRotation` in flash memory.

Because the sampled orientations are averaged together, it is recommended to only sample orientations that are at true 90° multiples of the vehicle frame.

The zero INS attitude feature assumes there are flat rigid surface(s) attached to the IMX about which the system can be leveled. If the working surface is not level or additional precision is desired, each orientation sampled can have an additional sample taken with ~180° yaw offset to cancel out tilt of the working surface.

If Infield Calibration is not adequate, the INS may be [leveled or aligned manually](#).

10.1.3 Infield Calibration Process

The following process can be used to improve the IMU calibration accuracy and also align or level the INS to the vehicle frame.

- 1. Prepare Leveling Surface** - Ensure the system is stable and stationary on a near-level surface with one of three axes in the vertical direction.
- 2. Initialize the Mode** - Clear any prior samples and set the calibration mode by setting `DID_INFIELD_CAL.state` to one of the following:

```

INFIELD_CAL_STATE_CMD_INIT_ZERO_IMU           = 1, // Zero accel and gyro biases.
INFIELD_CAL_STATE_CMD_INIT_ZERO_GYRO         = 2, // Zero only gyro biases.
INFIELD_CAL_STATE_CMD_INIT_ZERO_ACCEL        = 3, // Zero only accel biases.
INFIELD_CAL_STATE_CMD_INIT_ZERO_ATTITUDE     = 4, // Zero (level) INS attitude by adjusting INS rotation.
INFIELD_CAL_STATE_CMD_INIT_ZERO_ATTITUDE_IMU = 5, // Zero gyro and accel biases. Zero (level) INS attitude by adjusting INS rotation.
INFIELD_CAL_STATE_CMD_INIT_ZERO_ATTITUDE_GYRO = 6, // Zero only gyro biases. Zero (level) INS attitude by adjusting INS rotation.
INFIELD_CAL_STATE_CMD_INIT_ZERO_ATTITUDE_ACCEL = 7, // Zero only accel biases. Zero (level) INS attitude by adjusting INS rotation.

INFIELD_CAL_STATE_CMD_INIT_OPTION_DISABLE_MOTION_DETECT = 0x00010000, // Bitwise AND this with the above init commands to disable motion detection during sampling (allow for more tolerant sampling).
INFIELD_CAL_STATE_CMD_INIT_OPTION_DISABLE_REQUIRE_VERTICAL = 0x00020000, // Bitwise AND this with the above init commands to disable vertical alignment requirement for accelerometer bias calibration (allow for more tolerant sampling).

```

Zeroing accelerometer biases requires that any of the X,Y,Z axes be vertically aligned with gravity during sampling. This is indicated by bit `INFIELD_CAL_STATUS_AXIS_NOT_VERTICAL = 0x01000000` in `DID_INFIELD_CAL.status`.

By default, the system must also be stationary without any movement during sampling. This is indicated by bit `INFIELD_CAL_STATUS_MOTION_DETECTED = 0x02000000` is set in `DID_INFIELD_CAL.status`. Motion detection can be disabled to make the system more tolerant during sampling. To do this, bitwise and `INFIELD_CAL_STATE_CMD_INIT_OPTION_DISABLE_MOTION_DETECT = 0x00010000` with the initialization command. As an example, the command to initialize *INS alignment with zero IMU bias* with motion detection disabled is as follows:

```


(INFIELD_CAL_STATE_CMD_INIT_ZERO_ATTITUDE_IMU | INFIELD_CAL_STATE_CMD_INIT_OPTION_DISABLE_MOTION_DETECT);
0x00010101 = (0x0000101 | 0x00010000);

```

- 3. Sample Orientation(s)** - Initiate sampling of one or more orientations by setting `DID_INFIELD_CAL.state` to `INFIELD_CAL_STATE_CMD_START_SAMPLE = 8`. Sampling per orientation will take 5 seconds and completion is indicated when `DID_INFIELD_CAL.state` switches to `INFIELD_CAL_STATE_SAMPLING_WAITING_FOR_USER_INPUT = 50`.
 - Sample Same Orientation w/ +180° Yaw** - If the working surface is not level, two samples per orientation can be taken to cancel out the tilt of the working surface. Rotate the system approximately 180° in yaw (heading) and initiate the sampling a second time for a given orientation.
 - Sample Up to Six Orientations** - The sampling process can be done for up to six orientations (X,Y,Z pointed up and down). Each sample will be automatically associated with the corresponding vertical axis and direction. All orientations will be averaged together for both the zero IMU bias and zero INS attitude.
- 4. Store IMU Bias and/or Align INS** - Following sampling of the orientations, set `DID_INFIELD_CAL.state` to `INFIELD_CAL_STATE_CMD_SAVE_AND_FINISH = 9` to process and save the infield calibration to flash memory. The built-in test (BIT) will run once following this to verify the newly adjusted calibration and `DID_INFIELD_CAL.state` will be set to `INFIELD_CAL_STATE_SAVED_AND_FINISHED`.

EvalTool or CLTool for Infield Cal

The EvalTool IMU Settings tab provides a user interface to read and write the `DID_INFIELD_CAL` message.



CLTOOL INFIELD CAL

The following options can be used with the CLTool to edit the infield calibration (DID_INFIELD_CAL).

```
cltool -c /dev/ttyS2 -edit DID_INFIELD_CAL
```

Below is an example of the CLTool edit view of the DID_INFIELD_CAL message.

```
$ Inertial Sense. Connected. Press CTRL-C to terminate. Rx 13657


(94) DID_INFIELD_CAL:      W up, S down
                           0 calData[2].down.dev[1].acc[1]
                           0 calData[2].down.dev[1].acc[2]
                           0 calData[2].down.yaw
                           0 calData[2].up.dev[0].acc[0]
                           0 calData[2].up.dev[0].acc[1]
                           0 calData[2].up.dev[0].acc[2]
                           0 calData[2].up.dev[1].acc[0]
                           0 calData[2].up.dev[1].acc[1]
                           0 calData[2].up.dev[1].acc[2]
                           0 calData[2].up.yaw
0.0398919582 imu[0].acc[0]
0.000717461109 imu[0].acc[1]
0.67872334 imu[0].acc[2]
0.00583727891 imu[0].pqr[0]
0.0135380113 imu[0].pqr[1]
-0.00342554389 imu[0].pqr[2]
0.0874974579 imu[1].acc[0]
-0.167159081 imu[1].acc[1]
0.67817783 imu[1].acc[2]
-0.00111889921 imu[1].pqr[0]
-0.00523020467 imu[1].pqr[1]
0.00455262465 imu[1].pqr[2]
0 sampleTimeMs
50 state
0x00B01000 * status
```

10.2 Platform Configuration

The `DID_FLASH_CONFIG.platformConfig` allows for specification of the IMX carrier board type and configuration settings. This is important and helpful for configuring I/O specific to the platform (carrier board). Values for the Platform Config are specified in the **enum ePlatformConfig** in the SDK [data_sets.h](#).


10.2.1 Platform Type

The platform config type can be set through the EvalTool General Settings and GPS Settings tabs. Setting the Platform Config type through the EvalTool acts as a convenience preset that automatically sets the GPS source, type, and timepulse pin selection for the selected platform.



10.2.2 I/O Presets

The pin assignments on the RUG-3 are software configurable using the `PLATFORM_CFG_PRESET_MASK` bits of the `DID_FLASH_CONFIG.platformConfig`. The `PLATFORM_CFG_TYPE` must be set to one of the RUG-3 types to enable the I/O Presets configuration on the RUG-3. The RUG-3 main connector pin numbers are listed in parenthesis in the I/O Preset.



10.3 IMU INS GNSS Configuration

10.3.1 Translation


The IMX can be mounted and operated in any arbitrary orientation. It is often desirable and conventional to translate the IMX output so that it is translated into the vehicle frame located at certain point for control and navigation of the vehicle. This is done using the **Sensor Rotation**, **INS Rotation**, and **INS Offset** parameters.

In most common applications, output is translated to the vehicle frame (X to the front, Y to the right, and Z down):

- *Sensor Rotation* provides gross rotation of the IMU output in multiples of 90°.
- *INS Rotation* provides small angle alignment of the INS output.
- *INS Offset* shifts the location from the INS output.

Coordinate Frame Relationship

The relationship between the Hardware Frame, Sensor Frame, and INS Output Frame are as follows.



The **Hardware Frame** and **Sensor Frame** are equivalent when the **Sensor Rotation** in `DID_FLASH_CONFIG.sensorConfig` is zero. The **Hardware Frame origin** and **Sensor Frame origin** are always at the same location and may differ in direction according to the **Sensor Rotation** in `DID_FLASH_CONFIG.sensorConfig`. The **Sensor Frame** and **INS output Frame** are equivalent when the `DID_FLASH_CONFIG.insRotation` and `DID_FLASH_CONFIG.insOffset` are zero.

Sensor Rotation (Hardware Frame to Sensor Frame)

The *Sensor Rotation* is used to rotate the IMU and magnetometer output from the hardware frame to the **sensor frame** by **multiples of 90°**. This is done using the `SENSOR_CFG_SENSOR_ROTATION_MASK` bits of the `DID_FLASH_CONFIG.sensorConfig` as defined in `enum eSensorConfig`. The *Sensor Rotation* is defined in X,Y,Z rotations about the corresponding axes and applied in the order of Z,Y,X. This rotation is recommended for gross rotations.

INS Rotation

The *INS rotation* is used to convert the INS output from the [sensor frame](#) to the vehicle frame. This is useful if the sensor frame and vehicle frame are not aligned. The actual INS rotation parameters are `DID_FLASH_CONFIG.insRotation[3]` (X, Y, Z) in radians. The *INS rotation* values describes the rotation from the INS sensor frame to the intermediate frame in order of Z, Y, X.

INS Offset

The *INS offset* is used to shift the location of the INS output and is applied following the INS Rotation. This offset can be used to move the IMX location from the origin of the sensor frame to any arbitrary location, often a control navigation point on the vehicle.

Manually Aligning the INS After Mounting

NOTE for use:

- The [Infield Calibration](#) process can be used instead of this process to automatically measure and align the INS with the vehicle frame for INS rotations less than 15°.
- If using software release 1.8.4 or newer, we recommend using the `DID_FLASH_CONFIG.sensorConfig` to rotate the sensor frame by 90° to near level before following the steps below.

The following process uses the IMX to measure and correct for the IMX mounting angle.

1. Set `DID_FLASH_CONFIG.insRotation` to zero.
2. Set the sensor on the ground at various known orientations and record the INS quaternion output (`DID_INS_2`). Using the Euler output (`DID_INS_1`) can be used if the pitch is less than 15°. It is recommended to use the EKF [Zero Motion Command](#) to ensure the EKF bias estimation and attitude have stabilized quickly before measuring the INS attitude.
3. Find the difference between the known orientations and the measured INS orientations and average these differences together.
4. Negate this average difference and enter that into the `DID_FLASH_CONFIG.insRotation`. This value is in Euler, however it is OK for this step as this rotation should have just been converted from quaternion to Euler and will be converted back to quaternion on-board for the runtime rotation.

10.3.2 Infield Calibration


The [Infield Calibration](#) provides a method to 1.) zero IMU biases and 2.) zero INS attitude to align the INS output frame with the vehicle frame. These steps can be run together or independently.

10.3.3 GNSS Antenna Offset

If the setup includes a significant distance (40cm or more) between the GPS antenna and the IMX central unit, enter a non-zero value for the GPS lever arm, `DID_FLASH_CONFIG.gps1AntOffset` (or `DID_FLASH_CONFIG.gpsAnt2Offset`) X,Y,Z offset in meters from Sensor Frame origin to GPS antenna. The Sensor Frame origin and Hardware Frame origin are always at the same location but may differ in direction according to the Sensor Rotation.

10.3.4 IMU Sample and Navigation Periods

The IMU sample period is configured by setting `DID_FLASH_CONFIG.startupImuDtMs` in milliseconds. This parameter determines how frequently the IMU is measured and data integrated into the `DID_PIMU` data. `DID_FLASH_CONFIG.startupImuDtMs` also automatically sets the bandwidth of the IMU anti-aliasing filter to less than one half the Nyquist frequency (i.e. $< 250 / \text{startupImuDtMs}$).



The preintegrated IMU (PIMU) a.k.a. Coning and Sculling (delta theta, delta velocity) integrals serve as an anti-aliased moving average of the IMU value. The DID_IMU is the derivative of the DID_PIMU value over a single integration period.

IMU Latency

The IMU low-pass filter (LPF) adds latency (delay) to the signal in the IMU output. This latency can be expressed as:

$$\text{IMU Latency} \cong \frac{2.197}{\text{LPF bandwidth}}$$

The default IMU sensor bandwidths (cutoff frequencies) and corresponding signal latencies are:

Sensor	Bandwidth	Signal Latency
Gyro	539 Hz	4.1 ms
Accelerometer	416 Hz	5.3 ms

Navigation Update and Output Periods

The navigation filter output period should be set using the flash parameter DID_FLASH_CONFIG.startupNavDtMs. This value sets the DID_SYS_PARAMS.navOutputDtMs and DID_SYS_PARAMS.navUpdateDtMs during startup of the IMX.

The **navigation filter output period** (DID_SYS_PARAMS.navOutputDtMs) determines the EKF output data rate, the maximum rate for messages DID_INS_1, DID_INS_2, and DID_INS_3.

The **navigation filter update period** (`DID_SYS_PARAMS.navUpdateDtMs`) controls the EKF update rate and sets the standard integration period for the preintegrated IMU (PIMU) output. This parameter is automatically adjusted based on the value of `DID_SYS_PARAMS.navOutputDtMs` and the amount of CPU available.

MINIMUM NAV OUTPUT AND UPDATE PERIOD (MAXIMUM DATA RATE)

The following table lists the output and update period minimum limits for the IMX.

Operation Mode	IMX-5.0 Minimum Output Period / Update Period	IMX-5.1, uINS-3 Minimum Output Period / Update Period
INS (GPS enabled)	7 ms (142 Hz) / 14 ms	2 ms (500 Hz) / 4 ms
AHRS (GPS disabled)	5 ms (200 Hz) / 10 ms	2 ms (500 Hz) / 4 ms
VRS (GPS and magnetometer disabled)	4 ms (250 Hz) / 8 ms	2 ms (500 Hz) / 4 ms

10.3.5 INS-GNSS Dynamic Model

The `DID_FLASH_CONFIG.dynamicModel` setting allows the user to adjust how the EKF behaves in different dynamic environments. All values except for 2 (STATIONARY) and 8 (AIR <4g) are experimental. The user is encouraged to attempt to use different settings to improve performance, however in most applications the default setting, 8: airborne <4g, will yield best performance.


The STATIONARY configuration (`dynamicModel = 2`) can be used to configure the EKF for static applications. It is a permanent implementation of the [Zero Motion Command](#) which will reduce EKF drift under stationary conditions.

10.3.6 Disable Magnetometer and Barometer Updates

Magnetometer and barometer updates (fusion) into the INS and AHRS filter (Kalman filter) can be disabled by setting the following bits in `DID_FLASH_CONFIG.sysCfgBits`.

Bit Name	Bit Value	Description
<code>SYS_CFG_BITS_DISABLE_MAGNETOMETER_FUSION</code>	0x00001000	Disable magnetometer fusion into EKF
<code>SYS_CFG_BITS_DISABLE_BAROMETER_FUSION</code>	0x00002000	Disable barometer fusion into EKF

These settings can be disabled using the General Settings tab of the EvalTool.



10.3.7 Disable Zero Velocity Updates

Zero velocity updates (ZUPT) rely on GPS and/or wheel encoder data. In some cases there can be a slight lag/deviation when starting motion while simultaneously rotating. This is because GPS data is updated at 5 Hz and it takes a few samples to detect motion after a period of no motion. When ZUPT is enabled, it acts as a virtual velocity sensor telling the system that its velocity is zero. It may conflict briefly with GPS velocity observation when starting motion. If a slight lag at the beginning of motion is an issue, ZUPT may be disabled. Generally it should be enabled (Default). It can be disabled using `DID_FLASH_CONFIG.sysCfgBits` or using the General Settings tab of the EvalTool.

10.3.8 Disable Zero Angular Rate Updates

Zero angular rate updates (ZARU) rely on analysis of either IMU (gyro) data or wheel encoders when available. When angular motion is very slow and no wheel encoders are available a zero angular rate may be mistakenly detected, which will lead to gyro bias estimation errors. In these cases it can be beneficial to disable ZARU if the application has slow rotation rates (approximately below 3 deg/s). It is not encouraged to disable ZARU if there is no rotation or faster rotation. It can be disabled using `DID_FLASH_CONFIG.sysCfgBits` or using the General Settings tab of the EvalTool.

10.4 System Configuration

See the [Binary Protocol](#) page for descriptions of each [flash configuration](#) value and [enumeration bit values](#).

10.4.1 Serial Port Baud Rates

UART standard baud rates available on the IMX are: 921600, 460800, 230400, 115200, 57600, 38400, 19200. When operating within the standard baud rate range (≤ 921600 bps), only these specific baud rates can be used. Non-standard high speed baud rates (>921600) listed in the following section allow for arbitrary custom baud rates.

High Speed Baud Rates

Non-standard high speed UART baud rates (>921600 bps) can be set to arbitrary values up to 10 Mbps. Due to hardware limitations, the applied baud rate will be rounded to the closest available baud rate and reported back via the

`DID_FLASH_CONFIG.serxBaudRate` parameter.

Baud Rate Configuration

The IMX baud rate can be manually set by changing the following flash configuration parameters:

Configuration	Description
<code>DID_FLASH_CONFIG.ser0BaudRate</code>	baud rate for IMX serial port 0
<code>DID_FLASH_CONFIG.ser1BaudRate</code>	baud rate for IMX serial port 1
<code>DID_FLASH_CONFIG.ser2BaudRate</code>	baud rate for IMX serial port 2

These parameters can be changed using the EvalTool or the CLTool. The following examples show how the EvalTool and CLTool can be used to set the IMX serial port 1 baud rate to 460,800 bps.

```
EvalTool -> Data Sets -> DATA_FLASH_CONFIG.ser1BaudRate = 460800
```

```
cltool -c COM# -flashConfig=ser0BaudRate=460800
```

10.5 Time Synchronization

10.5.1 INS & GPS Timestamps

The IMX output messages are timestamped using GPS time-base because this time is known immediately following GPS signal reception. Conversion from GPS time to UTC time requires knowledge of the number of leap seconds (GPS-UTC) offset. This value is received periodically (every 12.5 minutes) and is available in the `DID_GPS1_POS` and `DID_GPS1_RTK_POS` (`gps_pos_t`) messages. GPS leap seconds is 18 seconds as of December 31, 2016 and [will change in the future](#).

The original designers of GPS chose to express time and date as an integer week number (starting with the first full week in January 1980) and a time of week (often abbreviated to TOW) expressed in seconds. Working with time/date in this form is easier for digital systems than the more "conventional" year/month/day, hour/minute/second representation. Most GNSS receivers use this representation internally and converting to a more "conventional form" externally.

GPS to UTC Time Conversion

UTC time is found by subtracting GPS leap seconds from the GPS time.

10.5.2 GPS Time Synchronization

Systems connected to the IMX can be time synchronized using the GPS PPS timepulse signal and any message containing GPS time. The actual time of the GPS PPS timepulse signal is the same as any message with GPS time rounded down to the second. The following pseudo code illustrates how this is done.

```
// GPS Time Synchronization - Find the difference between local time and GPS time:

// 1. Sample your local time on the rising edge of the GPS PPS timepulse signal.
double ppsLocalTime = localTime();

// 2. Read the GPS time from any message WITHIN ONE SECOND FOLLOWING the GPS PPS timepulse signal.
double gpsTime = readGpsMessageTime(); // within one second after GPS PPS

// 3. Find the difference between the GPS PPS local time and the GPS time rounded down to the
// nearest second (443178.800 s down to 443178 s, or 443178800 ms down to 443178 s).
double localToGpsTimeTemp = ppsLocalTime - floor(gpsTime);

// 4. Error check to ensure you have a consistent solution
static double localToGpsTimeLast;
double localToGpsTime;

if (fabs(localToGpsTimeLast - localToGpsTimeTemp) < 0.002) // within 2ms
{
    localToGpsTime = localToGpsTimeTemp;
}
localToGpsTimeLast = localToGpsTimeTemp; // Update history


// Local time can now be converted at anytime to GPS time using 'localToGpsTime' difference.
double currentGpsTime = localTime() + localToGpsTime;
```

10.5.3 Using the Strobe Input Pins

The IMX has several strobe input pins which can be configured to cause the IMX to report both its internal time and full navigation solution at the moment when triggered.

Strobe I/O Events

Strobe input and output (I/O) events are used for time and data synchronization.



STROBE pins on the μ IMU, μ AHRS, and μ INS Module - Top View

Strobe Input (Time Sync Input)

Strobe inputs are used to timestamp digital events observed on any of the pins labeled STROBE, e.g. camera shutter signals. A STROBE input event occurs when the logic level of any STROBE pin is toggled. The transition direction can be set so that the STROBE event triggers on a rising edge, or a falling edge. An internal 100K pull-up or pull-down resistor is enabled, depending on the assertion direction. External pull-up or pull-down resistors are not necessary.

The STROBE input will trigger on the edge type specified. However, the minimum period between STROBE input pulses is 1 ms. The measurement and timestamp resolution are both 1 ms.

The following pins can be used for STROBE input.

Signal	Module Pin	EVB-1 Pin	Rugged Pin	EVB-2
G2	5	H2-4	12	H7-6
G5	9	H6-3		H7-9
G8	8	H6-6		H7-12
G9	10	Button "B"		H7-13

To use a pin as a Strobe Input pin, the I/O must be configured as a strobe input. Additionally, the triggering edge must be set using the following bits in `DID_FLASH_CONFIG.ioConfig`.

Bit Name	Bit Value	Description
IO_CONFIG_STROBE_TRIGGER_LOW	0x00000000	Trigger strobe on falling edge
IO_CONFIG_STROBE_TRIGGER_HIGH	0x00000001	Trigger strobe on rising edge

Pushbutton "B" on the EVB asserts a logic low to G9 (pin 10) of the IMX and can be used to test the STROBE input functionality.

**Note: Holding pin 9 low at startup enables SPI which uses pins 5 and 8 making them unavailable to be used as Strobe Inputs. If pin 9 is not held low, the internal pullup resistor holds it high at startup. This sets pins 5 and 8 as inputs which can be used as Strobe Inputs.

A STROBE input event causes a timestamp message and INS2 message to be transmitted. The ASCII messages \$PSTRB and \$PINS2 messages are sent by default but can be disabled and replaced by the binary messages DID_STROBE_IN_TIME and DID_INS_2 if the RMC bit RMC_BITS_STROBE_IN_TIME is set for the given serial port.

Example:

```

rmc_t rmc;
rmc.bits = RMC_BITS_STROBE_IN_TIME;

int messageSize = is_comm_set_data_to_buf(buffer, bufferSize, comm, DID_RMC, sizeof(uint64_t), offsetof(rmc_t, bits), &rmc);
if (messageSize != serialPortWrite(serialPort, comm->buffer, messageSize))
{
    printf("Failed to write save persistent message\r\n");
}

```

Table 2 - DID_STROBE_IN_TIME message transmitted following a SYNC input event.

Field	Type	Description
week	uint32_t	Weeks since January 6 th , 1980
timeOfWeekMs	uint32_t	Time of week (since Sunday morning) in milliseconds, GMT.
pin	uint32_t	STROBE input pin
count	uint32_t	STROBE serial index number

The STROBE input event also causes the HDW_STATUS_STROBE_IN_EVENT (0x00000020) bit of the hdwStatus field in INS output (DID_INS_1, DID_INS_2, DID_INS_3, and DID_INS_4) to be set, allowing users to identify strobe input events using the INS output.

TROUBLESHOOTING INPUT STROBE

If the STROBE input does not appear to be functioning properly, an oscilloscope or fast multi-meter can be used to probe the actual STROBE line to ensure the proper 0V to 3.3V voltage swing is present. The following two tests can be used to evaluate the proper function of the strobe source and the IMX strobe input.

TEST 1: Identify if the IMX strobe input is configured properly and has a low input impedance:

1. Disconnect your strobe source from the IMX. Use a 1K ohm resistor as a pull-up resistor between 3.3V and the IMX strobe input and measure the strong input line.
2. Repeat using the resistor as a pull-down resistor between ground and the strobe input and measure the strobe input line.

This will tell if the IMX strobe input is somehow being driven internally or not configured correctly. If it is functioning correctly, the line will toggle from 0V to +3.3V following the resistor pull-down and pull-up.


TEST 2: Identify if your strobe source is driving correctly:

1. With the IMX strobe input disconnected from your strobe driving circuit, probe the output of the strobe driving circuit and observe what levels it toggles between.
2. Attach a 1M ohm pull-down resistor from ground to the strobe output and observe the strobe voltage swing.


If the circuit is working correctly, it should drive the strobe output from 0V to +3.3V despite the 1M ohm pull-down resistor.

INPUT VOLTAGE LEVEL SHIFTER

The maximum input voltage for strobe lines (any pin on the IMX) is 3.6V. A level shifter may be used to convert any strobe signal that is larger than 3.3V. The following figure shows two passive level shifter circuits, a zener diode voltage clamp and a resistor voltage divider.



With a Zener diode



With a voltage divider

These circuits are beneficial because of their simplicity. An active, powered level shifter may also be used and necessary.

Strobe Output (Preintegrated IMU Period)

The STROBE output feature generates a 1 ms pulse on pin G9, with the leading edge marking the start of the preintegrated IMU (PIMU) integration period. To enable this output, set the `IO_CONFIG_G9_STROBE_OUTPUT_NAV` bit (0x00000020) in `DID_FLASH_CONFIG.ioConfig`. The polarity of the pulse is configured by setting the `IO_CONFIG_STROBE_TRIGGER_HIGH` bit (0x00000001) in the same field.

Configuring Message Output

By default, triggering a strobe input event will cause the IMX to produce an NMEA `PINS2` message as well as a `PSTRB` message which contains the time stamp of the strobe event.

To instead send a binary `DID_INS_2` and `DID_STROBE_IN_TIME` message, set the `RMC_BITS_STROBE_IN_TIME` flag of `DID_RMC/` `bits` field.

10.6 Zero Motion Command

The *Zero Motion Command* is user initiated and informs the EKF that the system is stationary on the ground. It is used to aid in IMU bias estimation which can reduce drift in the INS attitude. It works as a virtual velocity and angular rate sensor to provide velocity and angular rate observations when the INS is stationary (zero velocity and zero angular rate). This is done for a period of two seconds after the *Zero Motion Command* is received. The Zero Motion Command is beneficial for the following reasons:

- Overriding incorrect GPS motion caused by weak GPS signal.
- Speeding up gyro biases convergence time when there is no GPS signal.

In normal AHRS mode (stationary with or without GPS), only the IMU gyro biases are estimated by the EKF. Setting `DID_FLASH_CONFIG.dynamicModel = DYNAMIC_MODEL_STATIONARY (2)` is equivalent to continually issuing the zero motion command.

To use the *Zero Motion Command*:

1. Ensure the system is stationary on the ground.
2. Send the *Zero Motion Command* either once or continuously while the system is stationary. This can be done either by using the *Zero Motion* button in the EvalTool General Settings tab or by sending the `DID_SYS_CMD` binary message.
3. After sending the *Zero Motion Command*, wait for the `INS_STATUS_STATIONARY_MODE` status bit to clear in `DID_INS_x.insStatus` before moving the system. This flag takes about 2 seconds to clear following the last *Zero Motion Command*.

Applying this command more than one time can further improve the IMU bias estimation.

**Warning**

Issuing the *Zero Motion Command* while the system is moving can cause incorrect IMU bias estimates and lead to poor INS performance. It is important to make sure that the system is stationary when using the *Zero Motion Command*.

10.7 UART Interface

The IMX has different UART TTL serial ports. These serial ports can be converted from TTL to RS232 or RS422 using a level converter, such as found on the Rugged-3, EVB-1, and EVB-2 carrier boards.

10.7.1 Actual UART Baud Rates

The serial ports use different peripherals so the actual baud rates of the ports differ.

Due to UART limitations, the **actual baud rate** that the hardware is capable of generating differs from the target or desired baud rate. This difference is more pronounced at higher baud rates (>921600 bps). The following table outlines these differences.

Target Baud Rate (bps)	IMX-5 Actual Baud Rate (bps)	uINS-3 Actual Baud Rate (bps)
19,200	19,198	19,191
38,400	38,406	38,422
57,600	57,595	57,515
115,200	115,273	115,030
230,400	230,547	231,481
460,800	459,770	457,317
921,600	919,540	937,500
	3,200,000	3,125,000
	4,000,000	3,750,000
	5,000,000	4,687,500
	8,000,000	6,250,000
	10,000,000	9,375,000

IMX-5 UART Baud Rate Equation

The actual baud rate that the IMX-5 hardware is capable of generating is described in the following equation.

Baud rates \leq 5 Mbps:

```
Divisor = floor( (80e6 + ((Target Baud Rate)/2)) / (Target Baud Rate) )
Actual Baud Rate = floor( 80e6 / Divisor )
```

Baud rates $>$ 5 Mbps:

```
Divisor = floor( (160e6 + ((Target Baud Rate)/2)) / (Target Baud Rate) )
Actual Baud Rate = floor( 160e6 / Divisor )
```

uINS-3 UART Baud Rate Equation

The actual baud rate that the IMX-5 hardware is capable of generating is described in the following equations.

```
Divisor = floor( (18750000 + ((Target Baud Rate)/2)) / (Target Baud Rate) )
Actual Baud Rate = floor( 18750000 / Divisor )
```

11. SDK



11.1 Inertial Sense SDK

The [Inertial Sense software development kit \(SDK\)](#) is hosted on GitHub.

SDK - The Inertial Sense open source software development kit provides quick integration for communication with the Inertial Sense product line, including the IMX, uAHRS, and IMU. It includes data logger, math libraries, and serial port interface for Linux and Windows environments.

EvalTool executable - Graphical Windows-based desktop program that allows you to explore and test functionality of the Inertial Sense products in real-time. It has scrolling plots, 3D model representation, table views of all data, data logger, and firmware updating interface for the IMX, uAHRS, or uIMU. The EvalTool can simultaneously interface with multiple Inertial Sense devices.

CLTool - Command line utility that can be used to communicate, log data, and update firmware for Inertial Sense products. Additionally, InertialSenseCLTool serves as example source code to demonstrate how to integrate the Inertial Sense SDK into your own source code. The InertialSenseCLTool can be compiled in Linux and Windows.

EVB-2 - Multi-purpose hardware evaluation and development kit for the IMX. The EVB-2 includes the IMX-G2 with Dual GNSS, RTK heading / positioning, onboard logging to micro SD card, 915MHz XBee radio for RTK base corrections, WiFi and BLE interface, serial and SPI communications to IMX interface, and Microchip SAME70 processor as communications bridge and user project development environment.

ROS - The `inertial-sense-sdk/ros` directory contains the [ROS wrapper node implementation](#) for the Inertial Sense IMX product line.

Documents

- [User Manual, Datasheet, and Dimensions](#)
- [Inertial Sense ROS Instructions](#)

Downloads

- [SDK Example Projects](#) - Source code projects that demonstrate how to use the SDK.
- [Software Releases](#) - IMX, uAHRS, uIMU, and EVB-2 firmware and application installers.
- [SDK & CLTool Source Code](#) - Open source SDK repository with command line tool and example C/C++ source code.

Hardware Design Files

- [IS-hdw repository](#) - CAD models of our products and PCB design assets for integration.

Support

- Email - support@inertialsense.com
-

Open Source License**MIT LICENSE**

Copyright 2014-2025 Inertial Sense, Inc. - <http://inertialsense.com>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions :

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

© 2014-2025 Inertial Sense, Inc.

11.2 Example Projects

11.2.1 Binary Communications Example Project

This [IS Communications Example](#) project demonstrates binary communications with the [Inertial Sense Products](#) (IMX, uAHRS, and uIMU) using the Inertial Sense SDK.

Files

Project Files

- [ISCommunicationsExample.cpp](#)

SDK Files

- [data_sets.c](#)
- [data_sets.h](#)
- [ISComm.c](#)
- [ISComm.h](#)
- [serialPort.c](#)
- [serialPort.h](#)
- [serialPortPlatform.c](#)
- [serialPortPlatform.h](#)

Implementation

STEP 1: ADD INCLUDES

```
// Change these include paths to the correct paths for your project
#include "../../src/ISComm.h"
#include "../../src/serialPortPlatform.h"
#include "../../src/ISPose.h"
```

STEP 2: INIT COMM INSTANCE

```
is_comm_instance_t comm;
uint8_t buffer[2048];

// Initialize the comm instance, sets up state tracking, packet parsing, etc.
is_comm_init(&comm, buffer, sizeof(buffer));
```

STEP 3: INITIALIZE AND OPEN SERIAL PORT

```
serial_port_t serialPort;

// Initialize the serial port (Windows, MAC or Linux) - if using an embedded system like Arduino,
// you will need to handle the serial port creation, open and reads yourself. In this
// case, you do not need to include serialPort.h/.c and serialPortPlatform.h/.c in your project.
serialPortPlatformInit(&serialPort);

// Open serial, last parameter is a 1 which means a blocking read, you can set as 0 for non-blocking
// you can change the baudrate to a supported baud rate (IS_BAUDRATE_*), make sure to reboot the IMX
// if you are changing baud rates, you only need to do this when you are changing baud rates.
if (!serialPortOpen(&serialPort, argv[1], IS_BAUDRATE_921600, 1))
{
    printf("Failed to open serial port on com port %s\r\n", argv[1]);
    return -2;
}
```

STEP 4: STOP ANY MESSAGE BROADCASTING

```
int messageSize = is_comm_stop_broadcasts_all_ports(comm);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to encode and write stop broadcasts message\r\n");
}
```

STEP 5: SET CONFIGURATION (OPTIONAL)

```
// Set INS output Euler rotation in radians to 90 degrees roll for mounting
float rotation[3] = { 90.0f * C_DEG2RAD_F, 0.0f, 0.0f };
int messageSize = is_comm_set_data_to_buf(comm, DID_FLASH_CONFIG, sizeof(float) * 3, offsetof(nvm_flash_cfg_t, insRotation), rotation);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to encode and write set INS rotation\r\n");
}
}
```

STEP 6: ENABLE MESSAGE BROADCASTING

```
// Ask for INS message w/ update 40ms period (4ms source period x 10). Set data rate to zero to disable broadcast and pull a single packet.
int messageSize = is_comm_get_data_to_buf(buffer, bufferSize, comm, DID_INS_1, 0, 0, 10);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to encode and write get INS message\r\n");
}

// Ask for GPS message at period of 200ms (200ms source period x 1). Size and offset can be left at 0 unless you want to just pull a specific field from
a data set.
messageSize = is_comm_get_data_to_buf(buffer, bufferSize, comm, DID_GPS1_POS, 0, 0, 1);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to encode and write get GPS message\r\n");
}

// Ask for IMU message at period of 96ms (DID_FLASH_CONFIG.startupNavDtMs source period x 6). This could be as high as 1000 times a second (period
multiple of 1)
messageSize = is_comm_get_data_to_buf(buffer, bufferSize, comm, DID_IMU, 0, 0, 6);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to encode and write get IMU message\r\n");
}
}
```

STEP 7: SAVE PERSISTENT MESSAGES

(OPTIONAL) Save currently enabled streams as persistent messages enabled after reboot.

```
system_command_t cfg;
cfg.command = SYS_CMD_SAVE_PERSISTENT_MESSAGES;
cfg.invCommand = -cfg.command;

int messageSize = is_comm_set_data_to_buf(buffer, bufferSize, comm, DID_SYS_CMD, 0, 0, &cfg);
if (messageSize != serialPortWrite(serialPort, comm->buf.start, messageSize))
{
    printf("Failed to write save persistent message\r\n");
}
}
```

STEP 8: HANDLE RECEIVED DATA

```
uint8_t inByte;

// You can set running to false with some other piece of code to break out of the loop and end the program
while (running)
{
    // Read one byte with a 20 millisecond timeout
    while (serialPortReadCharTimeout(&serialPort, &inByte, 20) > 0)
    {
        switch (is_comm_parse_byte(&comm, inByte))
        {
            case _PTYPE_INERTIAL_SENSE_DATA:
            {
                switch (comm.dataHdr.id)
                {
                    case DID_INS_1:
                        handleIns1Message((ins_1_t*)comm.pkt.data.ptr);
                        break;

                    case _DID_INS_LLA_QN2B:
                        handleIns2Message((ins_2_t*)comm.pkt.data.ptr);
                        break;

                    case DID_GPS1_POS:
                        handleGpsMessage((gps_pos_t*)comm.pkt.data.ptr);
                        break;

                    case _DID_PIMU:
                        handleImuMessage((dual_imu_t*)comm.pkt.data.ptr);
                        break;

                    // TODO: add other cases for other data ids that you care about
                }
                break;

            default:
                break;
        }
    }
}
```

```
}
}
```

Compile & Run (Linux/Mac)

1. Create build directory

```
cd InertialSenseSDK/ExampleProjects/Communications
mkdir build
```

2. Run cmake from within build directory

```
cd build
cmake ..
```

3. Compile using make

```
make
```

4. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```
sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)
```

5. Run executable

```
./ISCommunicationsExample /dev/ttyUSB0
```

Compile & Run (Windows Powershell)

*Note - Install CMake for Windows natively, or install the CMake for Windows extension for Visual Studio

1. Create build directory

```
cd InertialSenseSDK/ExampleProjects/Communications
mkdir build
```

2. Run cmake from within build directory

```
cd build
cmake ..
```

3. Compile using make

```
cmake --build .
```

4. Run executable

```
C:\InertialSenseSDK\ExampleProjects\Communications\build\Release\ISCommunicationsExample.exe COM3
```

Summary

This section has covered the basic functionality you need to set up and communicate with [Inertial Sense](#) products. If this doesn't cover everything you need, feel free to reach out to us on the [Inertial Sense SDK GitHub repository](#), and we will be happy to help.

11.2.2 ASCII Communications Example Project

This [IS Communications Example](#) project demonstrates binary communications with the [Inertial Sense Products](#) (IMX, uAHRS, and uIMU) using the Inertial Sense SDK. See the [ASCII protocol](#) section for details on the ASCII packet structures.

Files

Project Files

- [ISAsciiExample.c](#)

SDK Files

- [data_sets.c](#)
- [data_sets.h](#)
- [ISComm.c](#)
- [ISComm.h](#)
- [ISConstants.h](#)
- [serialPort.c](#)
- [serialPort.h](#)
- [serialPortPlatform.c](#)
- [serialPortPlatform.h](#)

Implementation

STEP 1: ADD INCLUDES

```
// Change these include paths to the correct paths for the project
#include "../../src/ISComm.h"
#include "../../src/serialPortPlatform.h"
```

STEP 2: INITIALIZE AND OPEN SERIAL PORT

```
serial_port_t serialPort;

// Initialize the serial port (Windows, MAC or Linux) - if using an embedded system like Arduino,
// you will need to handle the serial port creation, open and reads yourself. In this
// case, you do not need to include serialPort.h/c and serialPortPlatform.h/c in your project.
serialPortPlatformInit(&serialPort);

// Open serial, last parameter is a 1 which means a blocking read, you can set as 0 for non-blocking
// you can change the baudrate to a supported baud rate (IS_BAUDRATE_*), make sure to reboot the IMX
// if you are changing baud rates, you only need to do this when you are changing baud rates.
if (!serialPortOpen(&serialPort, argv[1], IS_BAUDRATE_921600, 1))
{
    printf("Failed to open serial port on com port %s\r\n", argv[1]);
}
```

STEP 3: DISABLE PRIOR MESSAGE BROADCASTING

```
// Stop all broadcasts on the device on all ports. We don't want binary message coming through while we are doing ASCII
if (!serialPortWriteAscii(&serialPort, "STPB", 4))
{
    printf("Failed to encode stop broadcasts message\r\n");
}
```

STEP 4: ENABLE MESSAGE BROADCASTING

```
// ASCII protocol is based on NMEA protocol https://en.wikipedia.org/wiki/NMEA_0183
// turn on the INS message at a period of 100 milliseconds (10 hz)
// serialPortWriteAscii takes care of the leading $ character, checksum and ending \r\n newline
// ASCE message enables ASCII broadcasts
// ASCE fields: 1:options, ID0, Period0, ID1, Period1, ..... ID19, Period19
// IDs:
// NMEA_MSG_ID_PIMU    = 0,
// NMEA_MSG_ID_PPIMU   = 1,
// NMEA_MSG_ID_PRIMU   = 2,
```

```

// NMEA_MSG_ID_PINS1 = 3,
// NMEA_MSG_ID_PINS2 = 4,
// NMEA_MSG_ID_PGPSP = 5,
// NMEA_MSG_ID_GNGGA = 6,
// NMEA_MSG_ID_GNGLL = 7,
// NMEA_MSG_ID_GNGSA = 8,
// NMEA_MSG_ID_GNRMCA = 9,
// NMEA_MSG_ID_GNZNDA = 10,
// NMEA_MSG_ID_PASHR = 11,
// NMEA_MSG_ID_PSTRB = 12,
// NMEA_MSG_ID_INFO = 13,
// NMEA_MSG_ID_GNGSV = 14,
// NMEA_MSG_ID_GNVTG = 15,
// NMEA_MSG_ID_INTEL = 16,

// options can be 0 for current serial port, 1 for serial 0, 2 for serial 1 or 3 for both serial ports
// Instead of a 0 for a message, it can be left blank (,,) to not modify the period for that message
// please see the user manual for additional updates and notes

// Get PINS1 @ 5Hz on the connected serial port, leave all other broadcasts the same, and save persistent messages.
const char* asciiMessage = "ASCE,0,3,1";

// Get PINS1 @ 1Hz and PGPSP @ 1Hz on the connected serial port, leave all other broadcasts the same
// const char* asciiMessage = "ASCE,0,5,5";

// Get PIMU @ 50Hz, GGA @ 5Hz, serial0 and serial1 ports, set all other periods to 0
// const char* asciiMessage = "ASCE,3,6,1";

if (!serialPortWriteAscii(&serialPort, asciiMessage, (int)strlen(asciiMessage, 128)))
{
    printf("Failed to encode ASCII get INS message\r\n");
}

```

STEP 5: SAVE PERSISTENT MESSAGES

(OPTIONAL) This remembers the current communications and automatically streams data following reboot.

```

if (!serialPortWriteAscii(&serialPort, "PERS", 4))
{
    printf("Failed to encode ASCII save persistent message\r\n");
}

```

STEP 6: HANDLE RECEIVED DATA

```

// STEP 4: Handle received data
unsigned char* asciiData;
unsigned char asciiLine[512];

// you can set running to false with some other piece of code to break out of the loop and end the program
while (running)
{
    if (serialPortReadAscii(&serialPort, asciiLine, sizeof(asciiLine), &asciiData) > 0)
    {
        printf("%s\n", asciiData);
    }
}

```

Compile & Run (Linux/Mac)**1. Create build directory**

```

cd InertialSenseSDK/ExampleProjects/Ascii
mkdir build

```

2. Run cmake from within build directory

```

cd build
cmake ..

```

3. Compile using make

```

make

```

4. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```

sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)

```

5. Run executable

```
./ISAsciiExample /dev/ttyUSB0
```

Compile & Run (Windows Powershell)

*Note - Install CMake for Windows natively, or install the CMake for Windows extension for Visual Studio

1. Create build directory

```
cd InertialSenseSDK/ExampleProjects/Ascii  
mkdir build
```

2. Run cmake from within build directory

```
cd build  
cmake ..
```

3. Compile using make

```
cmake --build .
```

4. Run executable

```
C:\InertialSenseSDK\ExampleProjects\Ascii\build\Release\ISAsciiExample.exe COM3
```

Summary

This section has covered the basic functionality you need to set up and communicate with [Inertial Sense](#) products. If this doesn't cover everything you need, feel free to reach out to us on the [Inertial Sense SDK GitHub repository](#), and we will be happy to help.

11.2.3 Basic Arduino Communications Example Project

Interfacing with the IMX over serial

This example shows how to communicate with the IMX using the Inertial Sense [Binary Communications Protocol](#). The example code can be found in the [Inertial Sense SDK/ExampleProjects/Arduino](#).

Important

Update the IMX to the [latest firmware](#)

This example demonstrates how to use the Inertial Sense EVB with an Arduino Due. The Due was selected because it has two serial ports. This way the Arduino can communicate with the IMX using one of the ports, and write the output over the Serial Monitor to the computer using the other.


Warning

The InertialSense SDK requires 64-bit double support. 32-bit processors (Arduino Due, Zero, and M0) are supported. 8-bit processors (i.e. Arduino Mega and Uno) are NOT supported. The [ASCII protocol](#) (not covered in this example) may be used on an 8-bit Arduino.

Note

A [Raspberry PI](#) (similar in price to the Arduino) is a good alternative to the Arduino. Either the [Binary Communications](#) and [ASCII Communications](#) example projects can be run on a Raspberry PI.

Wiring Guide



After downloading the [Inertial Sense SDK](#), Navigate to ExampleProjects/Arduino/ReadIS. Use the ImportSdkFiles.bat (Windows) or ImportSdkFiles.sh (Linux) to copy the required files from the SDK into src/ISSdk directory. The resulting file structure for the ReadIS Arduino sketch should look like the following:

```

| -ReadIS
|   | - ImportSdkFiles.bat
|   | - ImportSdkFiles.sh
|   | - ReadIS.ino
|   | - src
|   |   | - ISSdk
|   |   |   | - data_sets.c
|   |   |   | - data_sets.h
|   |   |   | - ISComm.c
|   |   |   | - ISComm.h
|   |   |   | - ISConstants.h

```

What is an ino file?

An .ino file is the arduino extension for a sketch. It is actually C++ code.

Note

Note that there are two .c files in the tree. You'll need to make sure that these files are compiled by the toolchain, otherwise xxxxx is not defined errors can occur.

SDK Implementation

`ReadIS.ino` file explained:

STEP 1: ADD INCLUDES

The `"ISComm.h"` header file includes all the other required code. `stdint.h` file from the standard library is required for the `offsetof` function.

```
#include "src/ISsdk/ISComm.h"
#include <stdint.h>
```

STEP 2: CREATE BUFFERS

Next, define a buffer to hold data. As the IMX sends data, this buffer is used to hold the data until a full message arrives. This buffer only needs to be as big as the largest message expected, multiplied by two + 32 (worst case scenario if there is a bad transmission). For this example a 1KB buffer is used.

```
// This buffer is going to be used to hold messages as they come in.
// You can make this 512 size if memory is tight.
static uint8_t s_buffer[1024];
// create an instance to hold communications state
static is_comm_instance_t comm;
```

STEP 3: SERIAL PORT INITIALIZATION

```
void setup()
{
  // Initialize both serial ports:
  Serial.begin(115200);
  Serial1.begin(115200);

  if (sizeof(double) != 8)
  {
    Serial.println("Inertial Sense SDK requires 64 bit double support");
    while (true)
    {
      ;
    }
  }

  Serial.println("initializing");

  // Initialize comm interface - call this before doing any comm functions
  is_comm_init(&comm, s_buffer, sizeof(s_buffer));

  // Stop all the broadcasts on the device
  int messageSize = is_comm_stop_broadcasts_all_ports(&comm);
  Serial1.write(comm.rxBuf.start, messageSize); // Transmit the message to the inertialsense device

  // Ask for ins_1 message 20 times per second. Ask for the whole thing, so
  // set 0's for the offset and size
  messageSize = is_comm_get_data_to_buf(buffer, bufferSize, &comm, DID_INS_1, sizeof(ins_1_t), 0, 1000);
  Serial1.write(comm.rxBuf.start, messageSize); // Transmit the message to the inertialsense device
}
```

Initialize the communication using the following steps as shown above:

1. Initialize the serial ports
2. Tell the communication interface where to find the buffer to use to hold messages, and how big that buffer is.
3. Reset communications on the device
4. Perform configuration of the IMX
5. Tell the IMX what data to stream, and how often

Whenever sending a command to the IMX, the command is put into the buffer, and the length of the message is returned by one of the configuration functions. That buffer needs to be written out to the IMX for the command to be received.



It is recommended to use the enumerations in `data_sets.h` such as `SYS_CFG_BITS_RTK_ROVER` to configure the device. This aids code readability and reduces the chance for errors.

In this example, the `DID_INS_1` message is streamed. All available messages can be found in the `data_sets.h` file, defined as C-style structs.

STEP 4: HANDLE RECEIVED DATA

```
void loop()
{
  // Read from port 1, and see if we have a complete inertialsense packet
  if (Serial1.available())
  {
    uint8_t inByte = Serial1.read();
    // This function returns the DID of the message that was just parsed, we can then point the buffer to
    // the right function to handle the message. We can use a cast to interpret the s_buffer as the
    // kind of message that we received.
    uint32_t message_type = is_comm_parse_byte(&comm, inByte);
    switch (message_type)
    {
      case _PTYPE_INERTIAL_SENSE_DATA:
        switch (comm.dataHdr.id)
        {
          case DID_NULL:
            break;
          case DID_INS_1:
            handleINSMessage((ins_1_t *) (comm.pkt.data.ptr));
            break;
          default:
            Serial.print("Got an unexpected message DID: ");
            Serial.println(message_type, DEC);
        }
      }
    }
  }
}
```

In this code, every byte that we receive from the IMX is passed to the `is_comm_parse` function. For each byte received, this function waits for a complete message in the buffer and decodes it. Once a full message is received, it identifies what kind of message is in the buffer so it can be handled correctly. The easiest way to deal with this is to use a case structure as shown above, with separate "callback" functions for each message type.

The INS message handler is just printing the position in lla, velocity and euler angle attitude to the screen. Other parameterizations of position and attitude are available in other `DID_INS_x` messages.

```
static void handleINSMessage(ins_1_t *ins)
{
  Serial.print("Lat: ");
  Serial.print((float)ins->lla[0], 6);
  Serial.print("\t");
  Serial.print("Lon: ");
  Serial.print((float)ins->lla[1], 6);
  Serial.print("\t");
  Serial.print("Alt: ");
  Serial.print((float)ins->lla[2], 2);
  Serial.print("\t");
  Serial.print("roll: ");
  Serial.print(ins->theta[0] * C_RAD2DEG_F);
  Serial.print("\t");
  Serial.print("pitch: ");
  Serial.print(ins->theta[1] * C_RAD2DEG_F);
  Serial.print("\t");
  Serial.print("yaw: ");
  Serial.print("\t");
  Serial.println(ins->theta[2] * C_RAD2DEG_F);
}
```

11.2.4 Firmware Update (Bootloader) Example Project

This [ISBootloaderExample](#) project demonstrates firmware update with the [InertialSense](#) products (IMX, uAHRS, and uIMU) using the Inertial Sense SDK.

Files

Project Files

- [ISBootloaderExample.cpp](#)

SDK Files

- [data_sets.c](#)
- [data_sets.h](#)
- [inertialSenseBootLoader.c](#)
- [inertialSenseBootLoader.h](#)
- [ISComm.c](#)
- [ISComm.h](#)
- [serialPort.c](#)
- [serialPort.h](#)
- [serialPortPlatform.c](#)
- [serialPortPlatform.h](#)

Implementation

STEP 1: ADD INCLUDES

```
// Change these include paths to the correct paths for your project
#include "../src/ISComm.h"
#include "../src/serialPortPlatform.h"
#include "../src/ISBootloaderThread.h"
#include "../src/ISBootloaderBase.h"
#include "../src/ISSerialPort.h"
```

STEP 2: INITIALIZE AND OPEN SERIAL PORT

```
serial_port_t serialPort;

// initialize the serial port (Windows, MAC or Linux) - if using an embedded system like Arduino,
// you will need to either bootload from Windows, MAC or Linux, or implement your own code that
// implements all the function pointers on the serial_port_t struct.
serialPortPlatformInit(&serialPort);

// set the port - the bootloader uses this to open the port and enable bootload mode, etc.
serialPortSetPort(&serialPort, argv[1]);
```

STEP 3: SET BOOTLOADER PARAMETERS

```
// bootloader parameters
bootload_params_t param;

// very important - initialize the bootloader params to zeros
memset(&param, 0, sizeof(param));

// the serial port
param.port = &serialPort;
param.baudRate = atoi(argv[2]);

// the file to bootload, *.hex
param.fileName = argv[3];

// optional - bootloader file, *.bin
param.forceBootloaderUpdate = 0; //do not force update of bootloader
if (argc == 5)
    param.bootName = argv[4];
else
    param.bootName = 0;
```

STEP 4: RUN BOOTLOADER

```

if (bootloadFileEx(&param)==0)
{
    printf("Bootloader success on port %s with file %s\n", serialPort.port, param.fileName);
    return 0;
}
else
{
    printf("Bootloader failed! Error: %s\n", errorBuffer);
    return -1;
}

```

Compile & Run (Linux/Mac)

1. Create build directory

```

cd InertialSenseSDK/ExampleProjects/Bootloader
mkdir build

```

2. Run cmake from within build directory

```

cd build
cmake ..

```

3. Compile using make

```

make

```

4. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```

sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)

```

5. Run executable

```

./ISBootloaderExample /dev/ttyUSB0 IS_uINS-3.hex bootloader-SAMx70.bin

```

Compile & Run (Windows Powershell)

*Note - Install CMake for Windows natively, or install the CMake for Windows extension for Visual Studio

1. Create build directory

```

cd InertialSenseSDK/ExampleProjects/IS_firmwareUpdate_v2
mkdir build

```

2. Run cmake from within build directory

```

cd build
cmake ..

```

3. Compile using make

```

cmake --build .

```

4. Run executable

```

C:\InertialSenseSDK\ExampleProjects\IS_firmwareUpdate_v2\build\Release\ISBootloaderExample.exe COM3 IS_uINS-3.hex bootloader-SAMx70.bin

```

Summary

This section has covered the basic functionality you need to set up and communicate with [Inertial Sense](#) products. If this doesn't cover everything you need, feel free to reach out to us on the [Inertial Sense SDK GitHub repository](#), and we will be happy to help.

11.2.5 C++ API - Inertial Sense Class and CLTool Example Project

The [InertialSense C++ class](#), defined in `InertialSense.h/.cpp`, provides all SDK capabilities including serial communications, data logging to file, and embedded firmware update for [InertialSense](#) products.

CLTool Example

The [Command Line Tool \(CLTool\)](#) is an open source project designed to illustrate InertialSense C++ class implementation. The CLTool project can be compiled on most operating systems using `cmake` and `gcc` and can be used to communicate, log data, and update firmware for Inertial Sense products. A Visual Studio project for Windows is also included. See [Using CLTool](#) for details on compiling and running the CLTool.

IMPLEMENTATION KEYWORDS

The following keywords are found in the CLTool source code identify the steps for InertialSense class implementation.

```
/* SDK Implementation Keywords:
 * [C++ COMM INSTRUCTION] - C++ binding API, InertialSense class with binary
 * communication protocol and serial port support for Linux and Windows.
 * [LOGGER INSTRUCTION] - Data logger.
 * [BOOTLOADER INSTRUCTION] - Firmware update feature.
 */
```

Serial Communications

STEP 1: INSTANTIATE INERTIALSENSE CLASS

Include the `InertialSense` header file. Create `InertialSense` object.

```
#include "InertialSense.h"

// [C++ COMM INSTRUCTION] 1.) Create InertialSense object, passing in data callback function pointer.
InertialSense inertialSenseInterface(cltool_dataCallback);
```

STEP 2: OPEN SERIAL PORT

Open the serial by specifying the com port number, baudrate, and and The serial port used for communications

```
if (!inertialSenseInterface.Open(g_commandLineOptions.comPort.c_str(),
    g_commandLineOptions.baudRate,
    g_commandLineOptions.disableBroadcastsOnClose))
{
    cout << "Failed to open serial port at " << g_commandLineOptions.comPort.c_str() << endl;
    return -1; // Failed to open serial port
}
```

STEP 3: ENABLE DATA BROADCASTING

The following enables data broadcasting from the IMX at a specified data rate or period in milliseconds.

```
cltool_setupCommunications(inertialSenseInterface)
```

STEP 4: READ DATA

Call the `Update()` method at regular intervals to send and receive data.

```
// Main loop. Could be in separate thread if desired.
while (!g_inertialSenseDisplay.ControlCWasPressed())
{
    if (!inertialSenseInterface.Update())
    {
        // device disconnected, exit
        break;
    }
}
```

STEP 5: HANDLE RECEIVED DATA

New data is available in the data callback function.

```

static void cltool_dataCallback(InertialSense* i, p_data_t* data, int pHandle)
{
    // Print data to terminal
    g_inertialSenseDisplay.ProcessData(data);

    // uDatasets is a union of all datasets that we can receive. See data_sets.h for a full list of all available datasets.
    uDatasets d = {};
    copyDataToStructP(&d, data, sizeof(uDatasets));

    // Example of how to access dataset fields.
    switch (data->hdr.id)
    {
    case DID_INS_2:
        d.ins2.qn2b; // quaternion attitude
        d.ins2.uvw; // body velocities
        d.ins2.lla; // latitude, longitude, altitude
        break;
    case DID_INS_1:
        d.ins1.theta; // euler attitude
        d.ins1.lla; // latitude, longitude, altitude
        break;
    case DID_IMU: d.dualImu; break;
    case DID_PIMU: d.dThetaVel; break;
    case DID_GPS1_POS: d.gpsPos; break;
    case DID_MAGNETOMETER: d.mag; break;
    case DID_BAROMETER: d.baro; break;
    case DID_SYS_SENSORS: d.sysSensors; break;
    }
}

```

STEP 6: CLOSE INTERFACE

Close the interface when your application finishes.

```

// Close cleanly to ensure serial port and logging are shutdown properly. (optional)
inertialSenseInterface.Close();

```

Data Logging**STEP 1: CONFIGURE AND START LOGGING**

```

// [LOGGER INSTRUCTION] Setup and start data logger
if (!cltool_setupLogger(inertialSenseInterface))
{
    cout << "Failed to setup logger!" << endl;
    return -1;
}

```

Compile & Run (Linux/Mac)**1. Create build directory**

```

cd cltool
mkdir build

```

2. Run cmake from within build directory

```

cd build
cmake ..

```

3. Compile using make

```

make

```

4. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```

sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)

```

5. Run executable

```

./cltool

```

Compile & Run (Windows Powershell)

*Note - Install CMake for Windows natively, or install the CMake for Windows extension for Visual Studio

1. Create build directory

```
cd InertialSenseSDK/cltool
mkdir build
```

2. Run cmake from within build directory

```
cd build
cmake ..
```

3. Compile using make

```
cmake --build .
```

4. Run executable

```
C:\InertialSenseSDK\cltool\build\Release\cltool.exe
```

Summary

This section has covered the basic functionality you need to set up and communicate with [Inertial Sense](#) products. If this doesn't cover everything you need, feel free to reach out to us on the [Inertial Sense SDK GitHub repository](#), and we will be happy to help.

11.2.6 Data Logging Example Project

This [ISLoggerExample](#) project demonstrates data logging with the [InertialSense](#) products (IMX, uAHRS, and uIMU) using the Inertial Sense SDK.

Files

Project Files

- [ISLoggerExample.cpp](#)

SDK Files

- [SDK](#)

Implementation

STEP 1: ADD INCLUDES

```
// Change these include paths to the correct paths for your project
#include "../../src/InertialSense.h"
```

STEP 2: INSTANTIATE INERTIALSENSE CLASS

```
// InertialSense class wraps communications and logging in a convenient, easy to use class
InertialSense inertialSense(dataCallback);
if (!inertialSense.Open(argv[1]))
{
    std::cout << "Failed to open com port at " << argv[1] << std::endl;
}
```

STEP 3: ENABLE DATA LOGGER

```
// get log type from command line
cISLogger::sSaveOptions options;
options.logType = (argc < 3 ? cISLogger::LOGTYPE_DAT : cISLogger::ParseLogType(argv[2]));
inertialSense.EnableLogger(true, "", options);
```

STEP 4: ENABLE DATA BROADCASTING

```
// broadcast the standard set of post processing messages (ins, imu, etc.)
inertialSense.BroadcastBinaryDataRmcPreset();

// instead of the rmc preset (real-time message controller) you can request individual messages...
// inertialSense.BroadcastBinaryData(DID_IMU, 6); // (startupNavDtMs default)
```

By default, data logs will be stored in the "IS_logs" directory in the current directory.

```
build/IS_logs/LOG_SN30664_20180323_112822_0001.dat
```

Compile & Run (Linux/Mac)

1. Create build directory

```
cd InertialSenseSDK/ExampleProjects/Logger
mkdir build
```

2. Run cmake from within build directory

```
cd build
cmake ..
```

3. Compile using make

```
make
```

4. If necessary, add current user to the "dialout" group in order to read and write to the USB serial communication ports:

```
sudo usermod -a -G dialout $USER
sudo usermod -a -G plugdev $USER
(reboot computer)
```

5. Run executable

```
./ISLoggerExample /dev/ttyUSB0
```

Compile & Run (Windows Powershell)

*Note - Install CMake for Windows natively, or install the CMake for Windows extension for Visual Studio

1. Create build directory

```
cd InertialSenseSDK/ExampleProjects/Logger
mkdir build
```

2. Run cmake from within build directory

```
cd build
cmake ..
```

3. Compile using make

```
cmake --build .
```

4. Run executable

```
C:\InertialSenseSDK\ExampleProjects\Logger\build\Release\ISLoggerExample.exe COM3
```

Summary

This section has covered the basic functionality you need to set up and communicate with [Inertial Sense](#) products. If this doesn't cover everything you need, feel free to reach out to us on the [Inertial Sense SDK GitHub repository](#), and we will be happy to help.

12. Data Logging/Plotting

12.1 Data Logging/Plotting

Inertial Sense provides data a logging capability in the EvalTool, CLTool, and SDK (C++) that can record data in binary, comma separated (.CSV), and KML file formats. This logging capability is useful for storing, replaying, and analyzing data.

12.1.1 Data Log Types

Comma Seperated Values (*.csv)

The comma separated value (.csv) file format can be imported into many software packages, including Excel, Matlab, and Python.

KML (*.kml)

KML is a file format used to display geographic data in an Earth browser such as Google Earth.

Binary Data Log (*.raw and *.dat)


	Raw Logger (*.raw)	Serial Logger (*.dat)
Description	Data stored in the same byte for byte form as it appears over a serial port, without parsing and removing packet header/footer.	Stores data to file in the same serial order it was passed into the logger. This is the default logger used in the CLTool and EvalTool.
Advantages	Allows logging of all data/packet formats. Preserves all data in the original form as communicated over serial port. Can be logged by writting serial port data to file, no parsing needed.	Optimized for real-time data logging.
Source File	DeviceLogRaw.h / .cpp	DeviceLogSerial.h / .cpp
File extension	.raw	.dat

12.1.2 Binary Data Log Format

This section outlines the Inertial Sense binary data log types known as raw data and serial data (.raw and .dat file extensions). The .dat data log file type are composed of several data containers know as chunks. Each chunk contains a header, sub-header, and data.

File

The data log file name has the format *LOG_SNXXXXXX_YYYYMMDD_HHMMSS_CNT.dat* which contains the device serial number, date, time, and log file count. The serial data log file formats is .dat . This log consist of files containing series of data Chunks.




Standard data types are stored in the log files and are defined as:

U32	unsigned int
U16	unsigned short
S8	char
U8	unsigned char

Chunk

The data log file is composed of Chunks. A Chunk is a data container that provides an efficient method for organizing, handling, and parsing data in a file. A Chunk starts with a header which has a unique identifiable marker and ends with the data to be stored.



Chunk Header

The header, found at the start of each Chunk, is as follows:

CHUNK Header	=	Marker	Version	Classification	Name	Name Inverted	Data Size	Data Size Inverted	Group Number	Device Serial #	Port Handle	Reserved
	Byte Size	4	2	2	4	4	4	4	4	4	4	4
	Data Type	U32	U16	U16	S8 (x4)	S8 (x4)	U32	U32	U32	U32	U32	U32


The C structure implementation of the Chunk header is:

```

//!< Chunk Header
#pragma pack(push,1)
struct sChunkHeader
{
    uint32_t marker; //!< Chunk marker (0xFC05EA32)
    uint16_t version; //!< Chunk Version
    uint16_t classification; //!< Chunk classification
    char name[4]; //!< Chunk name
    char invName[4]; //!< Bitwise inverse of chunk name
    uint32_t dataSize; //!< Chunk data length in bytes
    uint32_t invDataSize; //!< Bitwise inverse of chunk data length
    uint32_t grpNum; //!< Chunk Group Number: 0 = serial data...
    uint32_t devSerialNum; //!< Device serial number
    uint32_t pHandle; //!< Device port handle
    uint32_t reserved; //!< Unused
};
#pragma pack(pop)
    
```

Chunk Data

The Chunk data is defined for the .dat file types.



Data Set Header

The Data set header is used for the .dat file types.

DATA SET Header	=	<table border="1"><tr><td>DATA SET ID</td><td>DATA SET Size</td><td>DATA SET Offset</td></tr><tr><td>4</td><td>4</td><td>4</td></tr><tr><td>U32</td><td>U32</td><td>U32</td></tr></table>	DATA SET ID	DATA SET Size	DATA SET Offset	4	4	4	U32	U32	U32
DATA SET ID	DATA SET Size	DATA SET Offset									
4	4	4									
U32	U32	U32									
Byte Size											

12.2 Logging

The SDK logging interface is defined in [SDK/src/ISLogger.h](#). Data logs can be converted between file formats using the Inertial Sense data logger. The logging interface is used in the Inertial Sense software described below.

12.2.1 Logging using Inertial Sense software

EvalTool

1. Go to **"Data Logs"** tab in EvalTool.
2. Select the **"Format"** file type from the drop-down menu.
3. Select the data to record within the Data Streams section of the **"Data Logs"** tab:
 - a. **Manual Selection** - Allows the user to select the specific datasets to stream and their update rates by setting the checkbox and period multiple in Manual Selection table.
 - b. **INS** - Log INS output (attitude, velocity, position) at 100 Hz by selecting **"INS"** from the RMC Presets dropdown.
 - c. **Post Process** - Used for beta testing and internal testing. Includes IMU, GPS, INS and other messages. Log by selecting **"PPD"** from the RMC Presets dropdown.
4. Press **"Enable"** to begin logging data.
5. Press **"Disable"** to stop logging data.
6. The **"Open Folder"** button opens the File Explorer location to the data logs, i.e. `C:\Users\[username]\Documents\Inertial_Sense\logs`.
7. To change the root log folder in the Eval Tool, edit `Documents/Inertial_Sense/settings.json`, and add or change the logger key: `"Directory": "FOLDER_FOR_LOGS"`.

CLTool

The CLTool, provided in the SDK, is a command line application that can record post process data. The CLTool help menu is displayed using the option `-h`. See the [CLTool section](#) for more information on using the CLTool.

12.2.2 Post Process Data (PPD) Logging Instructions

Post process data (PPD) logs include both the input to and output from the navigation filter. The data is used for analyzing, troubleshooting, and improving system performance. PPD logs can be recorded using the EvalTool, CLTool, or SDK.

PPD RMC bits Preset

PPD logs are created by enabling PPD data streaming by setting the RMC bits to `RMC_PRESET_IMX_PPD` and logging this stream to a `.dat` binary file. `RMC_PRESET_IMX_PPD` is [defined in data_sets.h](#).

Logging PPD in EvalTool

The following steps outline how to record post process data in the EvalTool

1. Go to the **"Data Logs"** tab in the EvalTool.
2. Press the **"Data Log: PPD Log"** button to start logging.
3. Toggle the **"Data Log: Disable"** button to stop logging.
4. The **"Open Folder"** button will open the directory where the data logs are stored.

Logging PPD in CLTool

Streaming and logging a PPD log using the CLTool is done using the `-presetPPD -lon` options:

```
cltool -c /dev/ttyS2 -presetPPD -lon
```

See the [CLTool section](#) for more information on using the CLTool.

12.3 Plotting

12.3.1 Log Inspector

[Log Inspector](#) is a convenient way to quickly plot Inertial Sense [PPD logs](#) that of of the `.dat` format. The source code is in the SDK and can be modified and expanded.

12.3.2 CLTool

The CLTool can be used to load and replay `.dat` log files. The source code for the CLTool is located in the SDK and can be expanded by a user to analyze log data.

- `-rp PATH` replay data log from specified path
- `-rs=SPEED` replay data log at x SPEED

The following example replays data at 1x speed from the specified directory.

```
cltool -rp IS_logs/20180801_222310
```

The following example will replay data as fast a possible in quiet mode (without printing to the screen). This is useful to quickly reprocess the data.

```
cltool -rp IS_logs/20180801_222310 -rs=0 -q
```

12.3.3 3rd Party Software

The various file types described in the [overview](#) section can be analyzed using various software packages. Matlab, Python, and Excel are popular choices and are well suited for Inertial Sense data logs.

13. Reference

13.1 IMX-5.0 Bootloader

The IMX-5.0 bootloader is embedded firmware stored on the IMX and is used to update the IMX application firmware.

13.1.1 Application Firmware Update

The following are conditions for the IMX firmware update.

- **Bootloader Enable** - At start of the firmware update process, the IMX is sent a "bootloader enable" command to reboot the processor into bootloader mode. The IMX will not reboot into application mode until a valid firmware upload has completed.
- **Handshake Sequence** - A handshake sequence consisting of five consecutive sync characters (U) spaced 10 ms (minimum 5 ms) apart is sent to the IMX to initiate a given port and close all other ports to prevent interference.
- **Application Enable** - The IMX reboots into application mode only after a valid firmware upload has completed.

13.1.2 Bootloader Update

Updating the bootloader firmware is occasionally necessary when new functionality is required. The bootloader is checked and updated at the same time as loading new firmware. The following steps outline how to update the IMX bootloader and firmware.

1. **Ensure IMX Firmware is Running** - *(This step is not necessary if the IMX firmware is running and the EvalTool is communicating with the IMX).* If the bootloader is running but the firmware is not, version information will not appear in the EvalTool. The LED will also be a fading cyan.
2. **Select Baud Rate** - Select a slower baud rate (i.e. 115,200 or 230,400) for systems with known baud rate limits.
3. **Update the Bootloader and Firmware** - Use the EvalTool "Update Firmware" button in the Settings tab to upload the latest [bootloader](#) and the latest firmware. **The bootloader can only be updated using serial0 or the native USB ports.**

13.1.3 Known Issues

The following are known issues in the IMX-5.0 bootloader.


- **UART 50s Disable** - (Version v5g and prior) All UARTs get disabled if no handshake sequence is received within 50 seconds of the bootloader start. The USB port does not automatically close due to no handshake reception.

13.2 Coordinate Frames

In this manual, coordinate frame systems are simply referred to as frames. This page is to assist the developer in choosing and implementing the appropriate coordinate frames for their respective application. It should be noted that the following frames are in relation to the IMX itself.

13.2.1 Coordinate Frame Relationship



The relationship between the Hardware Frame, Sensor Frame, and INS Output Frame are as follows.




NOTE: The **Hardware Frame** and **Sensor Frame** are equivalent when the sensor rotation in `DID_FLASH_CONFIG.sensorConfig` is zero. The **Sensor Frame** and **INS output Frame** are equivalent when the `DID_FLASH_CONFIG.insRotation` and `DID_FLASH_CONFIG.insOffset` are zero.

13.2.2 Hardware Frame

The Hardware Frame is labeled "X" and "Y" on the hardware indicating the direction of the sensing elements in the IMX.



The IMX follows the right right rule for XYZ axis relative direction and angular rotation.



13.2.3 Sensor Frame

The IMU and magnetometer data (i.e. messages DID_IMU and DID_MAGNETOMETER) are in the Sensor Frame. The **Hardware Frame** is rotated into the **Sensor Frame** in multiples of 90° using the `SENSOR_CFG_SENSOR_ROTATION_MASK` bits of the `DID_FLASH_CONFIG.sensorConfig` as defined in `enum eSensorConfig`.

13.2.4 INS Output Frame

The INS output data (`DID_INS_1`, `DID_INS_2`, `DID_INS_3`) is in the INS Output Frame. Translation from Sensor Frame to INS Output Frame is defined as:

1. Sensor Frame \rightarrow Intermediate Output Frame by rotation of `DID_FLASH_CONFIG.insRotation` euler angles (in order of heading, pitch, roll angle) In radians.
2. Intermediate Output Frame \rightarrow INS Output Frame: Offset by `DID_FLASH_CONFIG.insOffset` in meters.

If `DID_FLASH_CONFIG.insRotation` and `DID_FLASH_CONFIG.insOffset` are zero, the Sensor Frame and the INS Output Frame are the same.

13.2.5 North-East-Down (NED) Frame


Position estimates can be output in the North-East-Down (NED) coordinate frame defined as follows:

* Right-handed, Cartesian, non-inertial, geodetic frame with origin located at the surface of Earth (WGS84 ellipsoid). * Positive X-axis points towards North, tangent to WGS84 ellipsoid. * Positive Y-axis points towards East, tangent to WGS84 ellipsoid. * Positive Z-axis points down into the ground completing the right-handed system.

13.2.6 Earth-Centered Earth-Fixed (ECEF) Frame

The Earth-Centered Earth-Fixed (ECEF) frame is defined as follows:

* Right-handed, Cartesian, non-inertial frame with origin located at the center of Earth. * Fixed to and rotates with Earth. * Positive X-axis aligns with the WGS84 X-axis, which aligns with the International Earth Rotation and Reference Systems Service (IERS) Prime Meridian. * Positive Z-axis aligns with the WGS84 Z-axis, which aligns with the IERS Reference Pole (IRP) that points towards the North Pole. * Positive Y-axis aligns with the WGS84 Y-axis, completing the right-handed system.



13.2.7 Coordinate Frames Transformation Functions

This section is intended to be an example of how to rotate between frames using utility functions defined in the [InertialSenseSDK](#).

Body frame to NED frame

The following example converts body velocity `DID_INS_2.uvw` to NED velocity `vel_ned`.

```
#include "SDK/src/ISPose.h"
quatRot( vel_ned, DID_INS_2.qn2b, DID_INS_2.uvw );
```

The following computes ground track heading based on `DID_INS_2.uvw` body velocity in the local tangent plane.

```
#include "SDK/src/ISPose.h"
quatRot( vel_ned, DID_INS_2.qn2b, DID_INS_2.uvw );
ground_track_heading = atan2f( vel_ned[1], vel_ned[0] );
```

This following example removes gravity from the IMU measured acceleration.

```
#include "SDK/src/ISPose.h"
Vector gravityNED = { 0, 0, -9.80665 }; // m/s^2
Vector gravityBody;
Vector accMinusGravity;
// Rotate gravity into body frame
quatConjRot( gravityBody, DID_INS_2.qn2b, gravityNED );
// Subtract gravity from IMU acceleration output
sub_Vec3_Vec3( accMinusGravity, DID_IMU.I[0].acc, gravityBody );
```

ECEF frame to NED frame

This example converts ECEF velocity `vel_ecef` to NED velocity `vel_ned`.

```
#include "SDC/src/ISPose.h"
quat_ecef2ned( lla[0], lla[1], qe2n );
quatConj( qn2e, qe2n );
quatRot( vel_ned, qn2e, vel_ecef );
```

13.3 Definitions

13.3.1 GPS Time To Fix

The time it takes for the GPS receiver to get “fix” or produce a navigation solution from the visible satellites is affected by the following GPS startup conditions:

- Cold start - In cold start mode, the receiver has no information from the last position (e.g. time, velocity, frequency etc.) at startup. Therefore, the receiver must search the full time and frequency space, and all possible satellite numbers. If a satellite signal is found, it is tracked to decode the ephemeris (18-36 seconds under strong signal conditions), whereas the other channels continue to search satellites. Once there are enough satellites with valid ephemeris, the receiver can calculate position and velocity data. Other GNSS receiver manufacturers call this startup mode Factory Startup.
- Warm start - In warm start mode, the receiver has approximate information for time, position, and coarse satellite position data (Almanac). In this mode, after power-up, the receiver normally needs to download ephemeris before it can calculate position and velocity data. As the ephemeris data usually is outdated after 4 hours, the receiver will typically start with a Warm start if it has been powered down for more than 4 hours.
- Hot start - In hot start mode, the receiver was powered down only for a short time (4 hours or less), so that its ephemeris is still valid. Since the receiver doesn't need to download ephemeris again, this is the fastest startup method.

Battery backed-up power supplied to the IMX preserves the GPS time, position, and coarse satellite position (almanac) while off. GPS almanac data is typically valid for several weeks while the GPS is off.

13.3.2 Preintegrated IMU

Also known as Coning and Sculling Integrals, Δ Theta Δ Velocity, or Integrated IMU. For clarification, we will use the name "Preintegrated IMU" or "PIMU" throughout the User Manual. They are integrated by the IMU at IMU update rates (1KHz). These integrals are reset each time they are output. Preintegrated IMU data acts as a form of compression, adding the benefit of higher integration rates for slower output data rates, preserving the IMU data without adding filter delay. It is most effective for systems that have higher dynamics and lower communications data rates. The IMX-5 uses Bortz for angular rates (which yield rotation from the previous pose) and full dual gyro and accelerometer integration for change in body velocities from the previous pose. The PIMU is NOT integrated from each axis separately.

13.3.3 IMU Bias Repeatability (Turn-on to Turn-on Bias)

The initial bias will be different for each power up of the IMU due to signal processing initial conditions and physical properties. A more repeatable bias allows for better tuning of INS parameters and faster estimate of the bias, whereas a more variable initial turn-on bias causes more difficult and longer INS convergence startup time.

13.3.4 IMU Bias Stability (In-Run Bias)

Describes the amount of bias change during any one run-time following power on. This change is caused by temperature, time, and mechanical stress. The INS navigation filter estimates the IMU biases in order to improve the state estimate. The IMU bias stability directly impacts the accuracy of the INS output.

13.3.5 Random Walk

The IMU sensors measure a signal as well as noise or error, described as a stochastic process. During IMU integration in the INS, sensor noise is accumulated and produces a random walk or drift on the final solution. Random walk has a direct effect on the accuracy of the INS output.

13.3.6 Sensor Orthogonality (Cross-Axis Alignment Error)

The three axis gyro and accelerometer sensors found in an IMU have measurement axes at 90 degrees from each other, maximizing the observability of the system. In practice, these sensing axes in a three axis sensor are not perfectly at 90 degrees

of each other, or misaligned slightly due to manufacturing imperfection. This misalignment results in integration error in the INS and impacts accuracy. To correct for cross-axis alignment error, the IMU is calibrated during manufacturing in a controlled motion environment.

13.4 IMU Specifications

13.4.1 IMU Noise Specification Conversion to Standard Deviation

The following calculations convert the noise specifications from the IMX-5 inertial measurement unit (IMU) datasheet into usable standard deviation values for simulating sensor noise at a sampling rate of 100 Hz. IMUs typically provide specifications for gyroscope and accelerometer noise in terms of "Angular Random Walk" (ARW) and "Velocity Random Walk" (VRW), expressed per $\sqrt{\text{hours}}$. These values represent the rate at which random walk (drift) accumulates over time. To model this noise accurately in simulations, we need to translate the datasheet specifications into standard deviations that correspond to the chosen sampling rate (100 Hz, or 0.01 seconds per sample). This involves converting the ARW and VRW values from per $\sqrt{\text{hour}}$ to per $\sqrt{\text{second}}$ and then adjusting them based on the sampling interval, yielding noise characteristics that realistically represent the IMU's behavior in a simulated environment.

Given IMU specifications for the **IMX-5**:

- **Gyro Angular Random Walk (ARW):** $0.16 \text{ } \circ / \sqrt{\text{hr}}$
- **Accelerometer Velocity Random Walk (VRW):** $0.02 \text{ m/s} / \sqrt{\text{hr}}$
- **Sampling Rate:** 100 Hz (which corresponds to a time interval, Δt , of 0.01 seconds)

Time Conversion Factor

Since the random walk values are given per $\sqrt{\text{hr}}$, we need to convert from hours to seconds. 1 hour is 3600 seconds, so: To convert the noise specifications from per $\sqrt{\text{hr}}$ to per $\sqrt{\text{s}}$, divide by 60.

1. Gyroscope Noise ($^\circ$ and $^\circ/\text{s}$)

Convert the **Gyro Angular Random Walk (ARW)** to per $\sqrt{\text{s}}$:

Now, to get the **angle drift** at a 100 Hz sampling rate, multiply by the square root of the time interval: So, the **angle drift standard deviation at 100 Hz** is approximately **0.000267 $^\circ$** .

To get the **angular rate noise** at a 100 Hz sampling rate, divide ARW by the square root of the time interval:

2. Accelerometer Noise (m/s and m/s^2)

VELOCITY DRIFT STANDARD DEVIATION (M/S)

Convert **VRW** from per $\sqrt{\text{hr}}$ to per $\sqrt{\text{s}}$:

Now, multiply by the square root of the time interval to get the standard deviation at 100 Hz in terms of velocity: So, the **velocity drift standard deviation at 100 Hz** is approximately **0.0000333 m/s**.

ACCELEROMETER STANDARD DEVIATION IN TERMS OF ACCELERATION (M/S^2)

To express the accelerometer noise as standard deviation in terms of acceleration, divide the VRW (converted per $\sqrt{\text{s}}$) by the square root of the time interval: Thus, the **accelerometer noise standard deviation in terms of acceleration at 100 Hz** is approximately **0.00333 m/s^2** .

Summary of Results:

- **Angle Drift Standard Deviation at 100 Hz:** **0.000267 $^\circ$** (denoted as σ_{angle})
- **Gyro Angular Rate Noise Standard Deviation at 100 Hz:** **0.0267 $^\circ/\text{s}$** (denoted as σ_{gyro})
- **Velocity Drift Standard Deviation at 100 Hz:** **0.0000333 m/s**
- **Acceleration Noise Standard Deviation at 100 Hz:** **0.00333 m/s^2**

These values represent the Gaussian noise standard deviations for each sensor at 100 Hz sampling rate.

13.5 Interference Considerations

Electrical interference or noise can be coupled into the Inertial Sense module in the form of electromagnetic interference (EMI) through the air or electrically conducted through wiring. Sources for interference include:

- EMI at the GPS antenna.
- EMI at the IMX module.
- EMI conducted through the power supply or I/O lines.

Common sources for noise and interference are digital lines, USB 3.x, noisy power supplies, etc.

13.5.1 Detecting Interference

To detect if interference is being coupled into the Inertial Sense sensor module, it can be compared with a stock EVB demo unit to compare noise figures. This is done by using the following steps. If both steps pass, there is no noise being coupled into the module. Optionally connect multiple sensor modules can be connected to the EvalTool in parallel to compare noise.

1. **Evaluate the IMU sensor** - Make sure the unit is stationary (on a table or non-moving surface) and not seeing any vibrations. Watch the standard deviation columns labeled " σ " in the Sensors tab of the EvalTool. This shows the noise level over the past 5 seconds, which means the device needs to be completely stable for 5 seconds to be accurate. Compare this figure between the integrated sensor module and EVB demo unit.
2. **Evaluate GPS sensitivity** - In clear view of the sky, monitor the satellite signal strength through the `DID_GPS_NAV.cnoMax` and `DID_GPS_NAV.cnoMean` fields in the EvalTool "Data Sets" tab or in the EvalTool "GPS" tab. See that the strongest (largest) CNO values are roughly the same between the integrated sensor module and the EVB demo unit.

13.5.2 Interference Mitigation

The best solution is to stop the EMI (emitted) or conducted noise at its source. If it is not possible to completely eliminate the source, the following methods should be considered depending on the cause of interference:

- **GPS antenna location** - Position the GPS antenna at the top of the vehicle, clear of obstructions and away from noise sources such as motors, processors, USB cables, digital devices, etc. USB 3.x typically generates quite a bit of EMI and interferes with the GPS. Added shielding and/or signal [inline USB filters](#) can be added USB 3.x to reduce EMI and mitigate GPS interference. Symptoms of GPS interference are poor GPS CNO signal strength, long times to lock, slip out of lock, etc.
- **GPS antenna ground plane** - Adding a 2"-3" diameter metallic ground plane below the GPS antenna will improve CNO noise ratio and improve sensitivity. This can help in noisy environments. You can use any scrap metal or PCB to test the concept by simply placing it below the GPS antenna (no electrical grounding required). The ground plane can have holes to reduce the weight and aerodynamic effects.



- **Shielding around the Inertial Sense module** - This can further prevent EMI from being absorbed by potentially GPS sensitive circuitry on the module.
- **Digital signals** - Making sure best practices for electrical current return paths for both common mode and differential mode signals can be key for this. Customers have seen GPS interference caused by USB 3.x and have resolved the issues using shielding and [inline USB filters](#).
- **Power supply filtering** - This may be necessary on systems with significant digital noise. LC filters or similar filters can be added inline between the power supply and the IMX supply input (Vcc). Common switching mode/buck voltage regulators should be fine for use with the IMX module and not require additional filtering.

Please contact us at support@inertialsense.com if further support is needed.

13.5.3 Magnetic Interference

Magnetic interference may impact IMX magnetometer performance if surrounded by steel or ferrous material or near motors, motor drivers, or other electronics that cause EMI. This interference can be observed in the magnetometer output, magnetometer status, and INS heading. Make sure all components are fixed in location during this test. While powering and actuating the various interference sources, observe the following:

- **Magnetometer Output** should remain constant and not deviate. (EvalTool Sensors tab)
- **Magnetometer Status** should remain good and not indicate interference. (EvalTool INS tab, "Mag used" green = good, yellow = interference)
- **INS Heading** (yaw) estimate should not drift or change direction. (EvalTool INS tab, "Yaw")

If any of these items are affected during the test, the system may result in incorrect magnetometer and heading values.

13.5.4 Mechanical Vibration

The system accuracy may degrade in the presence of mechanical vibrations that exceed 3 g of acceleration. Empirical data shows degradation at approximately 100 - 150 Hz. Adding **vibration isolation** to the mount may be necessary to reduce the vibrations seen by the product and to improve accuracy.

13.5.5 Temperature Sensitivity

The system is designed to compensate for the effects of temperature drift, which can be found in typical operation. However, rapid hardware temperature changes can result in degraded accuracy of the IMU calibration, GPS position, and INS estimate. Rapid temperature change can be caused by direct exposure to wind, sun, and other elements.

13.6 Magnetometer

The magnetometer is used to estimate heading when the system is in any of the following conditions:

1. is in AHRS mode
2. has no GPS fix
3. has GPS fix and constant velocity (non-accelerating motion)

To have accurate heading under these conditions, the magnetometer must be calibrated. The system allows for two types of modes for recalibration, external initiated and automatically initiated re-calibration. Regardless of the recalibration mode, a slower online background calibration runs that continuously improves the magnetometer calibration to handle local magnetic environment changes. All magnetometer calibration is stored in flash memory and available on bootup.

13.6.1 Disable Magnetometer Updates

Magnetometer fusion into the INS and AHRS filter can be disabled by setting bit `SYS_CFG_BITS_DISABLE_MAGNETOMETER_FUSION` (0x00001000) of `DID_FLASH_CONFIG.sysCfgBits`.

13.6.2 Magnetometer Recalibration

Occasionally the magnetometer will require a complete recalibration, replacing the old calibration with an entirely new calibration. This is accomplished either through external or automatic initiated recalibration. Use of the different modes is generally governed by the particular use case for the end customer and is intended to allow for the most flexibility in an integrated product design.

External Recalibration

External magnetometer recalibration allows the most flexibility in determining when an end user will need to recalibrate the system. This control over the timing of the recalibration is critical for many use cases and allows product designers to implement their desired workflows for customers. Further there are use cases where automatic recalibration is not possible because the quality of the magnetometer calibration is not observable. Such use cases would include AHRS operation, extended periods without motion or no GNSS fix. External magnetometer recalibration, as the name suggests is triggered by an external command from the application managing the IMX hardware. The IMX provides a set of status messages indicating the quality of the magnetometer calibration and leaves the timing and implementation of a recalibration up to the product designer. Specifically, `INS_STATUS_MAG_INTERFERENCE_OR_BAD_CAL` is an indication of the quality of the magnetometer calibration (see [system status flags](#) for details).

During the calibration process, the system should be clear of steel, iron, magnets, or other ferrous materials (i.e. steel desks, tables, building structures). The IMX should be attached to the system in which it is operating and rotated together during the calibration process. The following is the

Force magnetometer recalibration procedure:

1. Set `DID_MAG_CAL.recalCmd` to either: * `MAG_CAL_STATE_MULTI_AXIS` (0) for Multi-Axis which is more accurate and requires 360° rotation about two different axes. * `MAG_CAL_STATE_SINGLE_AXIS` (1) for Single-Axis which is less accurate and requires 360° rotation about one axis.
2. Rotate the system accordingly.

Recalibration completion is indicated by either:

1. `INS_STATUS_MAG_RECALIBRATING` bit of the `insStatus` word set to zero. The `insStatus` word is found in standard INS output messages (`DID_INS_1`, `DID_INS_2`, `DID_INS_3`, and `DID_INS_4`).
2. `DID_MAG_CAL.progress` is 100.

Recalibration progress is indicated as a percentage (0-100%) is indicated can be observed from variable `DID_MAG_CAL.progress`. The recalibration process can be canceled and the prior calibration restored anytime by setting `DID_MAG_CAL.enMagRecal = MAG_RECAL_MODE_ABORT` (101).

The “Mag used” indicator in the EvalTool INS tab will be green when magnetometer data is being fused into the solution, black when not being fused into the solution, and red during recalibrating.

Example code:

```
#include "com_manager.h"
// Set DID_MAG_CAL.enMagRecal = 0 for multi-axis recalibration
int32_t value = MAG_RECAL_MODE_MULTI_AXIS;
sendDataComManager(0, DID_MAG_CAL, &value, 4, offsetof(mag_cal_t, enMagRecal));
// Enable broadcast of DID_MAG_CAL.progress every 100ms to observe the percent complete
sendDataComManager(0, DID_MAG_CAL, 0, sizeof(mag_cal_t), 100);
```

Automatic Recalibration

Automatic magnetometer recalibration is useful for systems where user intervention to start external calibration is not convenient or practical. In this mode, the solution will determine that the system needs to be recalibrated and will attempt to do so while in normal operation. In the period while the system is recalibrating, the uncalibrated magnetometer data is used to prevent the INS heading from drifting but it does not provide heading measurements to the state estimator. This feature is enabled by setting bit `SYS_CFG_BITS_AUTO_MAG_RECAL` (0x00000004) of `DID_FLASH_CONFIG.sysCfgBits` non-volatile word.

```
// Enable automatic magnetometer calibration.
DID_FLASH_CONFIG.sysCfgBits |= SYS_CFG_BITS_AUTO_MAG_RECAL;
// Disable automatic magnetometer calibration.
DID_FLASH_CONFIG.sysCfgBits &= ~SYS_CFG_BITS_AUTO_MAG_RECAL;
```

13.6.3 Magnetometer Continuous Calibration

To mitigate the need for recalibration (completely replace calibration data), continuous calibration improves the magnetometer calibration slowly over time. Continuous calibration always runs in the background.

13.6.4 Magnetometer Calibration Settings

The magnetometer calibration algorithm can produce higher quality calibrations when data more data is collected across multiple axes of rotation. However, there are use cases where data collection beyond a single axis is impractical if not impossible. To address this issue there is a setting in the flash to configure the data requirement threshold for magnetometer calibration. The available settings include:

- Single Axis Calibration – This setting requires a full rotation in the yaw axis (relative to earth) to determine the calibration. Additional data that is collected via motion on other axes is used but not required. Once a full rotation is completed the calibration is calculated and the online continuous calibration is started.
- Multi Axis Calibration – This setting requires data to be collected across at least two axes, where one is the yaw axis. This calibration mode does not have any specific angular rotational requirements in any given axes, but it does require that data has been collected across a sufficient angular span. There is an indicator (**mag_cal_threshold_complete**) in the `DID_SYS_PARAMS` message that relates the total percent of the required threshold that has been collected. As more data is collected this value will increment to 100% at which point the calibration will be calculated and the online continuous calibration will continue to run

```
/*! Magnetometer recalibration. 0 = multi-axis, 1 = single-axis */
SYS_CFG_BITS_MAG_RECAL_MODE_MASK = (int)0x00000700,
SYS_CFG_BITS_MAG_RECAL_MODE_OFFSET = 8,
```

14. User Manual PDF

This document is provided to allow users to capture a snapshot of our current documentation. **The PDF is an automatically generated printout of the current online documents so there are known link and image sizing issues.** We encourage use the online documentation which is maintained for customer accessibility.

[Download PDF](#)

15. Frequently Asked Questions


15.1 What is a Tactical Grade IMU?

An Inertial Measurement Unit (IMU) is industry qualified as "Tactical Grade" when the In Run Bias Stability (IRBS) of the gyroscopes is between 0.5 deg/hour and 5 deg/hour. The IRBS represents the IMU stability during benign conditions (i.e. ideal integration time, stable temperature, and no inertial motion).


IEEE-STD-952-1997 defines IRBS as the minima on the Allan Variance curve. The following plots identify the Allan Variance representation of four IMX-5 tactical grade IMUs (serial numbers 60071, 60079, 60112, and 60114).

Allan Variance: PQR - 20220914_152814


Gyro P (deg/hr), ARW: $0.204 \text{ deg}/\sqrt{\text{hr}}$, BI: 1.65 deg/hr



Gyro Q (deg/hr), ARW: $0.16 \text{ deg}/\sqrt{\text{hr}}$, BI: 1.21 deg/hr



Gyro R (deg/hr), ARW: $0.135 \text{ deg}/\sqrt{\text{hr}}$, BI: 1.62 deg/hr



15.2 Why the name change from uINS to IMX?

The name **IMX** means inertial measurement device with extensible capabilities. IMX is a derivative of the acronym **IMU**. Our flagship product was named the **uINS** which means miniature Inertial Navigation System (INS). This name has helped others to

recognize the inertial navigation functionality. However, we felt that a more generic name would better cover all of the various functionality and capabilities contained in the **IMX**, namely:

- Tactical grade Inertial Measurement Unit (IMU)
- Barometer and magnetometer sensors
- Vertical Reference Unit (VRU)
- Attitude Heading Reference System (AHRS)
- GNSS aided Inertial Navigation System (GNSS-INS or GPS-INS)
- RTK-GNSS aided INS
- Dual-GNSS (GPS compassing) aided INS
- Ground vehicle Dead Reckoning system

15.3 What is Inertial Navigation?

Inertial navigation is a technique of estimating position, velocity, and orientation (roll, pitch, heading) by integrating IMU inertial motion data from gyros and accelerometers to continuously calculate the dead reckoning position. The inertial sensors are supplemented with other sensors such as GPS, altimeter, and magnetometer. Inertial navigation is commonly used on moving vehicles such as mobile robots, ships, aircraft, submarines, guided missiles, and spacecraft.

15.4 What does an Inertial Navigation System (INS) offer over GPS alone?

Dead Reckoning - An inertial navigation system (INS) integrates the IMU data to dead reckon (estimate position and velocity) between GPS updates and during GPS outage.

Higher Data Rates - Typical GPS receivers data rates vary from 1Hz to 20Hz whereas INS systems like the IMX have data rates up to 1KHz.

Signal Conditioning - An INS filters out noise in the GPS data and provides a smoother, more continuous data stream.

Orientation Data - An INS is capable of observing the orientation (roll, pitch, and heading) of the system regardless of the motion or direction of travel. This is because of how an INS fuses inertial data with GPS data. A GPS with one antenna can measure direction of travel (ground track heading) but cannot estimate vehicle roll, pitch, or heading.

15.5 Our Sensors - IMU vs AHRS vs INS

Inertial Measurement Unit (IMU) - Uses gyros and accelerometers to measure angular rate and linear acceleration.

Attitude Heading Reference System (AHRS) - Adds sensor fusion to IMU and magnetometer output to estimate orientation or roll, pitch, and heading.

Inertial Navigation System (INS) - Adds sensor fusion to IMU, GPS, magnetometer, and barometer data to estimate orientation, velocity, and position.

15.5.1 I have my own GPS system and just need raw motion data, which sensor is for me?

If you have your own filters in place and need raw data for measuring motion, then the **IMU** is the best option. The IMU provides raw, calibrated data for temperature, 3D acceleration (accelerometer), 3D magnetic field (magnetometer), and 3D rate of turn.

15.5.2 Which sensor will also provide attitude (roll/pitch/yaw) and heading data?

The **AHRS** sensor has all the capabilities of the IMU plus data on roll, pitch, and yaw. This sensor uses algorithms to fuse raw data from the IMU with the Earth's gravity to provide orientation and is perfect for a robotic arm or indoor floor cleaner.

I need geographic positional data. Which sensor contains a GPS?

If the AHRS doesn't get you what you need, packaging this with one or more GPS sensors will give you the geographic positional data you need. Like the AHRS, your sensor or should provide some sort of "sensor fusion" by combining all the data from each of these sensors to give a more accurate and holistic view of your rover's state.

What do I need to get started?

We recommend beginning with some sort of Development Kit. Ours comes with all of the necessary components to simplify testing and integration: the sensor you selected, the needed cable and antennas for connectivity, the firmware & software, and 3-5 hrs of complementary engineering support from a team of Inertial Sense engineers.

Additionally, Inertial Sense provides customers with a custom datalogger, called the EvalTool. An easy to use data logging software to test and troubleshoot your new sensor is **essential** to your sensor integration experience.

15.6 How long can the IMX dead reckoning estimate position without GPS?

The IMX inertial navigation integrates the IMU data to dead reckoning position and velocity estimation between GPS updates and for a short period of time during GPS outages. This dead reckoning is designed to filter out GPS noise and provide cleaner faster updates than are available via GPS alone. The IMX dead-reckons, or estimates position and velocity, between GPS updates and through brief GPS outages. However, it is not designed for extended position navigation without GPS aiding. Dead reckoning is disabled after 7 seconds of GPS outage in order to constrain position and velocity drift. The amount of position drift during dead reckoning can vary based on several factors, including system runtime, motion experienced, and bias stability.

15.7 Can the IMX estimate position without GPS?

IMX can estimate the position for extended periods of time without GPS for ground vehicle dead reckoning applications only (see [Ground Vehicle Dead Reckoning](#)). When in standard mode (not ground vehicle dead reckoning) GPS is required to provide initial position estimation and to aid in IMU bias estimation. The IMX can dead reckon (estimate position without GPS) for brief periods of time. However, the quality of dead reckoning is a function of IMU bias estimation, which improves while the GPS is aiding the INS.

15.8 How does the IMX estimate roll/pitch during airborne coordinate turns (acceleration only in the Z axis and not in the X and Y axes)?

Using acceleration alone will incorrectly indicate the platform is level. GPS informs the IMX extended Kalman filter (EKF) about any motion the system experiences and as a result the EKF can distinguish between acceleration due to motion and gravity. Without a GPS (in AHRS mode) the IMX EKF can only assume the direction of gravity equals the average direction of acceleration measured slowly over time. The IMX can estimate roll/pitch under accelerated conditions during a coordinated turn because gyro integration prevents attitude drift over short term and level coordinate turns are cyclical allowing the average gravity for an entire heading rotation to be observed. However, the IMX AHRS solution under accelerated conditions (moving) will have degraded attitude accuracy. The IMX solution is more accurate when aided by GPS.

15.9 How does vibration affect navigation accuracy?

The IMX accuracy may degrade in the presence of mechanical vibrations that exceed 3g of acceleration. Empirical data shows degradation at approximately 100 - 150 Hz. Adding vibration isolation to the mount may be necessary to reduce the vibrations seen by the product and to improve accuracy.

15.10 Can the IMX operate underwater?

The IMX can only dead reckon for short periods of time and in general requires GPS to provide position and velocity data. The GPS antenna must be above the water surface in order for the GPS to function properly. It is ideal that the GPS antenna be fixed relative to the IMX (IMU) module in order to maintain precision when moving faster than 2 m/s or 0.8 m/s². However, the GPS antenna may be tethered above the IMX, where the GPS antenna is floating on the water surface and the IMX is below the water

surface. System position will reflect the GPS antenna position and attitude (roll, pitch, heading) will reflect the IMX module orientation.

15.11 Can the IMX operate at >4g acceleration?

Typical L1 GPS receivers lose fix above 4g acceleration because the doppler variation starts to get too large and the receiver may become unstable or not be able to get/keep a fix. Additionally, the acceleration begins to affect the stability of the GPS XTAL oscillator.

On the IMX, the GPS will regain fix within seconds after acceleration drops below 4g. The IMX will track the velocity and position using inertial navigation for up to 5 seconds of GPS outage. As long as GPS outage is below 5 seconds, the IMX should be able to track position through a launch.

15.12 Customer Support

Have other questions or needs? Please email us at support@inertialsense.com.

16. Troubleshooting

16.1 Firmware Troubleshooting

Please email support@inertialsense.com for assistance or to provide feedback on this user guide.

16.1.1 Data doesn't look right

If the EvalTool or SDK are from a different release from the firmware on the unit, there may be communication protocol related issues. It's best to keep both the software and firmware in sync with each other. The EvalTool should flag a protocol mismatch in the settings tab.

16.1.2 Bootloader Not Responding

Check the following:

- The input supply is at 3.3V and clean without noise.
- The serial connection is grounded (no floating grounds).
- The serial wires between the uINS module and the next active device (buffer, converter, or processor) are not longer than 1 meter when bootloading firmware.
- Reset or power cycle the IMX and promptly run the firmware update within 30 seconds of reset. A known issue in the IMX-5.0 bootloader version v6g and prior versions that disables all UARTS if no handshake is received within 50 second following startup. Resetting the IMX will re-enable UARTs for 50 seconds.

16.1.3 Bootloader Update fails first time

If updating the bootloader firmware and using the USB direct connection on the IMX module (pins 1 and 2) or the EVB-2 (EVB USB connector), the serial port number will change when the device switches from application mode to Bootloader Update mode. This is expected and requires reselecting the new serial port and running the Bootloader Update process a second time.

16.1.4 System in AHRS mode despite GPS messages being received

If attempting to enter NAV mode but the system reports AHRS despite GPS data being received, then assure your units are not set to Rover RTK mode. This will override your ability to lock in GPS Nav mode.

16.1.5 "IMX-5 Bricked" System Recovery

Assert chip erase pin high (3.3V) while booting (power cycle or reset) to erase all flash memory and place IMX into ROM bootloader (DFU) mode.

Note: the IMX bootloader will timeout and disable all UARTS (not USB) after 30 seconds if the sync handshake is not received. This will render the IMX unresponsive over UART. To prevent this, do not interrupt the standard firmware update process. To recover the IMX, reset the IMX and then re-apply the firmware update within 30 seconds of reset. <https://docs.inertialsense.com/user-manual/reference/bootloader/#known-issues>

Note: Following chip erase: Update firmware using standard procedure including app and bootloader firmware images. Upload IMU calibration.

16.1.6 "GPX-1 and IMX-5.1 Bricked" System Recovery

Assert boot mode pin high (3.3V) while booting (power cycle or reset) to put the device into bootloader mode. Inertial Sense customer support is required to facilitate bootloader communications with this device.

16.1.7 "uINS Bricked" System Recovery

There are different reasons a system may appear unresponsive and not communicate. The following sections describe how to recover a system from these states.

Attention

The ONLY indicator that the bootloader is running is the fading cyan module LED. NO communications will appear in the EvalTool or CLTool. **Attempt to update the firmware before performing a [chip erase](#).**

Attention

Hardware v3.1.3 and firmware IS_uINS-3_v1.2.1.0_b287_2017-09-17_103826.hex and older will not communicate and require following these instructions to be recovered. Do NOT use the [chip erase](#) procedure for this scenario.

Stuck in Bootloader Mode

In some cases, the bootloader may fail to completely update firmware. This is indicated by the fading cyan status LED on the IMX module. This can happen if older bootloader firmware is on the uINS and firmware version 1.7.1 is uploaded. If this happens, the system will appear to be unresponsive in the EvalTool. The following process can be used to recover the system to a working state:

If the **bootloader is running**, identified with the fading cyan color LED on the uINS module, following these steps:

1. **Ensure uINS Firmware is Running** - (*This step is not necessary if the uINS firmware is running and the EvalTool is communicating with the uINS*). Select the device serial port and update the firmware using [1.6.4](#) or earlier. If the bootloader is running, version information will not appear in the EvalTool. The following bootloader update step will not work unless the EvalTool is communicating with the uINS firmware.
2. **Update the Bootloader** - Use the EvalTool "Update Bootloader" button in the Settings tab to upload the latest [bootloader firmware](#). If it has a fading cyan color on the uINS module, the bootloader is running and ready for new firmware to be loaded. **The bootloader can only be updated using serial0 or the native USB connection.**
3. **Update the Firmware** - Use the EvalTool "Update Firmware" button to upload the [latest uINS firmware](#).

If neither the bootloader or the uINS firmware are running, identified with the solid or no LED status on the uINS module, please [contacts us](#).

Recovery for Firmware v1.2.1.0

Hardware v3.1.3 and newer and firmware IS_uINS-3_v1.2.1.0_b287_2017-09-17_103826.hex and older result in a system that runs but will not communicate properly. This older firmware was not designed for the newer hardware and consequently runs the processor at a slower speed, which alters all of the predefined baud rates to non-standard irregular baud rates. A symptom of this problem is the LED flashing to indicate the processor activity and the module never communicates properly.

The following steps are provided to recover communications with the system.

1. Install and run the [hotfix release 1.1.3 EvalTool](#).
2. Select the special baud rate **560,000** in the EvalTool and open the serial port.
3. Update the firmware using any version **newer than** IS_uINS-3_v1.2.1.0_b287_2017-09-17_103826.hex.

The latest EvalTool, CLTool, SDK, and firmware can be used once the firmware has been updated on the module.

16.1.8 Troubleshooting with EvalTool

Units Not Connecting

In the case that your units do not connect properly to the EvalTool, verify:

1. The baud rate is the same that you previously had when the Com Ports last opened correctly.
2. The LED on the unit is not showing solid white, flashing white, or solid red. These mean a failure occurred in loading the bootloader (see User Guide for full LED descriptions).
3. If you are using a USB3.0 connection, the com port might take longer to show up than with USB2.0
4. Check your computer's Device Manager to see if your unit shows up there. If it doesn't show up, you may have an FTDI driver issue.
 - a. If you suspect you don't have the FTDI driver installed on your Windows computer, use the following links to download the driver: - Executable for the FTDI USB driver: - <https://ftdichip.com/wp-content/uploads/2023/09/CDM-v2.12.36.4-WHQL-Certified.zip> - Drives without executable. - <http://www.ftdichip.com/Drivers/D2XX.htm>

16.1.9 Downgrading uINS to 1.8.x Firmware

The following steps can be used to downgrade the uINS firmware to version 1.8.x (or older):

1. Ensure the uINS is running 1.9.x (or newer) firmware.
2. Send the system commands `SYS_CMD_MANF_UNLOCK` and `SYS_CMD_MANF_DOWNGRADE_CALIBRATION` to the uINS to downgrade the IMU calibration and put the system into bootloader update mode. This can be done using the EvalTool, cltool, or SDK .
 - a. **EvalTool** (version 1.9.1 or later): Use the firmware "**Downgrade**" button (EvalTool -> Settings -> General -> Factory -> Downgrade).
 - b. **cltool** (version 1.10 or later): Use option `-sysCmd=1357924682` to send the downgrade command:

```
./cltool -c /dev/ttyACM0 -sysCmd=1357924682
```

cltool alternate method: use option `-edit 7` to edit the `DID_SYS_CMD` and send the downgrade command:

```
./cltool -c /dev/ttyACM0 -edit 7
```

Use `w` and `s` to move the cursor up or down (arrow keys do not work) and enter to submit the new value. The `invCommand` value is the bitwise inverse of the command and is required to validate the command. The `command` value will change to zero when the IMX accepts the `command` and `invCommand` values.

Send manufacture unlock command:

```
command = 1122334455
invCommand = 3172632840
```

Send downgrade command:

```
command = 1357924682
invCommand = 2937042613
```

3. Verify the uINS has reboot into bootloader update mode. The host serial port will disappear and reappear. The uINS will NOT support normal DID binary or NMEA communications in this mode, but will be ready to update the bootloader.
4. Update the bootloader and firmware using the 1.8.x EvalTool, cltool, or SDK. Be sure to use the bootloader v5d (or older) with the 1.8.x firmware.

Chip Erase Downgrade

The above process using the `SYS_CMD_MANF_DOWNGRADE_CALIBRATION` command is recommended as it prevents the need to reload the IMU calibration onto the uINS. However, an alternative method to downgrade uINS to 1.8.x firmware is as follows:

1. Chip erase the uINS.
2. Load v5b (or older) bootloader and 1.8.x (or older) firmware using the 1.8.x EvalTool, cltool, or SDK.
3. Restore the IMU calibration.

16.1.10 1.7.6 Bug RTK Base GPS Raw work around

If you are having base raw errors on your Rover, in the bottom right of the Evaltool, or a climbing Differential Age, in Data Sets `DID_GPS1_RTK_REL`, you maybe having this bug. Try this workaround.

1. Go-to settings tab, open the Base serial COM port.
2. Go-to Data Logs tab, under RCM Presets dropdown select PPD.
3. **NOTE:** You must leave the comport open on the Base.
4. Check your Rover to see if its still getting raw errors messages.

16.2 Chip Erase

Please email support@inertialsense.com for assistance or to provide feedback on this user guide.

Steps for Chip-Erase Recovery

Warning


The CHIP ERASE (Reserved (CE) pin 17) erases all flash memory including firmware, settings and calibration. CHIP ERASE should only be used as a last resort. This step should ONLY be used if the steps for [Stuck in Bootloader Mode](#) fail and there is NO other method to recover communications.

Important

Please notify support@inertialsense.com if this step is necessary so that we can keep track of cause of failures and provide you any necessary support.


IMX CHIP ERASE PAD

On the IMX-5, CHIP ERASE is enabled if +3.3V (available on pin 22) is applied to the chip erase (CE) pin 17 during boot up from power cycle or reset.



Connect +3.3V to pin 17 (CE) while power cycling the IMX to chip erase IMX.


EVB-2 CHIP ERASE PADS



**Short R25 pads together to chip erase uINS.
Short R53 pads together to chip erase EVB-2.**

RUGGED CHIP ERASE PADS

The chip erase pads on the Rugged-3 are a set of 0402 SMT pads with the label "ERASE". Shorting these pads together will apply +3.3V to the IMX chip erase pin 17. The power must be cycled while shorting these pads in order to apply chip erase to the IMX-5.



Short "ERASE" pads together and reset to chip erase.

RESTORE FIRMWARE

1. **Power on system**

2. **Record your IMX Serial Number** - If you can read the serial number, record it for reference. On older firmware versions the serial number will be erased. New firmware versions store the serial number in a location that chip erase won't touch.

3. **Chip Erase IMX** - Assert Chip Erase (Reserved (CE) pin 17) on the IMX longer than 100ms by connecting to +3.3V. +3.3V is available on pin 2 of all EVB headers. **Warning!!!** - CHIP ERASE erases all flash memory (including firmware, settings, and calibration) and should only be used as a last resort. This step should ONLY be used if there is NO other method to recover communications.

4. **Reset the system**

5. **Enable EvalTool Internal Mode** - This exposes the "Manufacturing" tab used to upload calibration data.

6. **Restore the application and bootloader firmware** - Use the "Update Firmware" button in the EvalTool Settings tab to load the [bootloader firmware](#) and [IMX firmware](#).

ENABLE EVALTOOL INTERNAL MODE

EvalTool internal mode is used to access the EvalTool Manufacturing tab, used to restore serial numbers and calibration data.

1. Close the EvalTool so it isn't running.

2. Using a text editor, change the value of "DBGINT" to 99 (i.e. "DBGINT": 99,) in settings file: C:\Users\[USERNAME]\Documents\Inertial Sense\settings.json.

3. Restart EvalTool and verify "[INTERNAL MODE]" is in the title bar.

RESTORE SENSOR CALIBRATION

[Contact InertialSense](#) and provide your unit serial number to request the sensor calibration that corresponds with your unit. Use the EvalTool to upload the sensor calibration onto your unit.

1. Ensure the EvalTool is in [Internal Mode](#) which provides access the Manufacturing tab.

2. Ensure unit is communicating with EvalTool.

3. Upload calibration data: EvalTool -> Manufacturing Tab -> "Load" button next to "System Test" button.

4. Verify "TC Pts" which is the number of calibration points located just below the "Load" button changes from "0,0" to two numbers larger than 12 (i.e. "18,18").

5. Reset the unit.

6. **Run "Built-In Test"** - Verify the built-in test passes by pressing the "Built-In Test" button in the EvalTool INS tab.

7. **Verify IMU output** - Place the unit on a flat level surface. Using the EvalTool Sensor tab, verify that the gyro rates are near zero, the accelerometer X and Y axes are near zero, and accelerometer Z axis is near -9.8m/s^2 for gravity.

16.3 IMX Firmware Troubleshooting


16.3.1 Antenna Baseline

Separation between GNSS antennas (or baseline distance) impacts the accuracy and fix time of the solution. Typical Dual GNSS heading fix time is 60-90 seconds using a 1 meter baseline. Baseline distances shorter than 1 meter will impact both heading accuracy and time to fix. However, having a short baseline of 0.35m should not cause an extremely long fix time.

ITEM TO TEST: Try increasing the antenna baseline to 0.5m or greater during initial testing.

16.3.2 Satellite CNO Strength, RFI and EMI

What is the satellite CNO (signal strength) level? The mean CNO would ideally be above 38-40. Anything lower could indicate the presence of RF interference (RFI) or electromagnetic interference (EMI). You can see this in the EvalTool GPS tab or the DID_GPS1_POS message.



ITEM TO TEST: Try powering off portions of the system while running the IMX. You may even try running the IMX independently to a separate computer to monitor the system so you can completely power off your system with the IMX still running. Pay close attention to the GPS CNO during each change.

16.3.3 USB Interface

USB-3 has been known to interfere with wireless and GNSS systems. It is the most common source of interference that has been experienced. Properly shielded cables or signal filters can address this.

ITEM TO TEST: Disable USB-3, digital busses, or various switching supplies and observe the satellite CNO level. CNO mean should be near or above 40 dB/Hz.

16.3.4 Antenna Ground Planes

The ground planes should be adequately sized. Larger ground planes help but are generally not the root cause of poor performance. Separate and common ground planes are both acceptable.

ITEM TO TEST: Try doubling the ground plane below the antenna. A simple sheet of metal placed below the antenna is fine. This is also not likely the root cause but worth testing.

16.3.5 Antenna Cable Ground Loops

In come cases the GNSS antenna cable can form an electrical loop and cause interfere.

ITEM TO TEST: Try to ensure cables never loop back or are bundled. If possible shorten cables to smallest required length. Monitor GPS CNO before and after.


16.3.6 Local Interference

In some cases we have seen object in close proximity to the GNSS antennas act as a multi-path surface, reflect GNSS signals onto the GNSS antennas. Ensure no objects are near the antennas above the plane of the antennas.

16.3.7 Antenna Orientation

A more accurate heading can be achieved if the GNSS antennas have the same antenna orientation (point the same way). You should consider rotating one or both GNSS antennas so the coax cable exit in the same direction on each antennas.

Mismatch



BAD

